Projects 7 and 15

GOAL:

Create a diagram style monitoring screen showing a schematic representation of the entire system and displaying process values on the diagram where they originate.

SUMMARY:

Now we're going to flex our HMI muscles a little bit. First, we're going to create our schematic. And then, we're going to put in our displays / indicators. That's the easy part.

Our Operator wants to see FLOW. So we want to show (somehow) where the water is flowing… and in which directions. We also want to show which output devices are energized and which are deenergized. Yep – animations, boys and girls… animations. We also want to show basic system status information here.

So this screen is going to be incredibly useful. It'll be a diagram of the system as well as a real-time monitor showing things coming on, shutting off, water flow changing directions and etc. It's going to be the hallmark of our HMI!

TAG USAGE:

B3:4/5	BACKWASH_PENDING	Backwash Cycle Pending
B3:4/6	BACKWASH_RUNNING	Backwash Running
F8:3	DIFF_PRES	Differential Pressure
B3:0/0	FS1	Flow Switch FS-1
F8:2	LT1_SV	Level Transmitter LT-1 (0-100 %) Scaled Value
B3:0/7	P1	Pump P-1 Bit
F8:0	PT1_SV	Pressure Transmitter PT-1 (0-20 psi) Scaled Value
F8:1	PT2_SV	Pressure Transmitter PT-2 (0-20 psi) Scaled Value
B3:0/1	SV1	Solenoid Valve SV-1 Bit
B3:0/2	SV2	Solenoid Valve SV-2 Bit
B3:0/3	SV3	Solenoid Valve SV-3 Bit
B3:0/4	SV4	Solenoid Valve SV-4 Bit
B3:0/5	SV5	Solenoid Valve SV-5 Bit
B3:0/6	SV6	Solenoid Valve SV-6 Bit
B3:3/8	SYS_RUNNING	System Running