Address	Instruction		Туре		Field	ds		Machine Language		
0x1000 L7:	lw x6,	-4 (x9)	I	imm _{11:0} 11111111	L1100	rs1 01001	f3 010	rd 00110	op 0000011	FFC4A303
0x1004	sw x6,	8 (x9)	S	imm _{11:5}	rs2 00110		f3 010	imm_{4:0} 01000	op 0100011	0064A423
0x1008	or x4,	x5, x6	R	funct7 0000000	rs2 00110	rs1 00101	f3 110	rd 00100	op 0110011	0062E233
0x100C	beq x4,	x4, L7	В	imm _{12,10:5} 1111111	rs2 00100	rs1 00100	f3 000	imm_{4:1,11} 10101	op 1100011	FE420AE3