Windows:

Arduino IDE:

- 1. Download supported version from : https://www.arduino.cc/en/Main/Software
- 2. Install in default directory.

Linux:

Arduino IDE:

1. Download supported version from : https://www.arduino.cc/en/Main/Software