

TR 2432 Temperature Monitor

Display





Temperature Switch Menu Items

Program [Display Units) first to avoid rogramming errors.
SPH	Setpoint 1	
-PI	Resetpoint 1	
001	Output function	
	Hola Hola Fola Fola	Hysteresis mode: normally open Hysteresis mode: normally closed Field mode: normally open Field mode: normally closed
	Analog output	
		0-10 V
		4-20 mA
AEP ASP	Analog start point Analog end point	
Modd	Measurement Mode	
	3 44	3 wire RTD (Pt100 or Pt1000)
	<u> </u>	2 or 4 wire RTD (Pt100 or Pt1000)
		(continued) —

(unctions – Press Set, then Mode/Enter ugh the Enhanced Functions options	
	Memory locations for Max / Min temp.	
COF, CAL	Calibration offset, Calibration reset	
d511,dr11	Delay time for switching outputs	
FOUL, FOUR	Fault status of Output 1, Output 2	
P-n PnP,nPn J.S. Display units	PNP output, NPN output S Display updated 50, 200, or 600 milliseconds, respectively	
<u> </u>	Same as above with display rotated 180°	
Display dead	ctivated	
Display units		
	°Celsius, °Fahrenheit	