spirax Sarco

TI-S02-03

ST Issue 10

FT14 Ball Float Steam Trap (Screwed)

Description

The FT14 is an SG iron bodied ball float steam trap having stainless steel working internals and integral automatic air venting facility. The FT14 can be maintained without disturbing the pipework.

Available types

FT14 (R-L)	Horizontal connections with flow from right to left
FT14 (L-R)	Horizontal connections with flow from left to right
FT14V	Vertical connections with flow downwards

Capsule

The BP99/32 capsule which is used in the FT14 is suitable for use on 150°C superheat @ 0 bar g and 50°C superheat @ 32 bar g.

Optional extras

A manually adjustable needle valve (designated 'C' on the nomenclature i.e. FT14-C) can be fitted to the trap. This option provides a steam lock release (SLR) feature in addition to the standard air vent. For further information please consult Spirax Sarco.

The FT14 has the option of an **integral strainer screen** (designated 'X' on the nomenclature i.e. **FT14-X**).

Standards

This product fully complies with the requirements of the European Pressure Equipment Directive 97/23/EC.


Certification

This product is available with a manufacturers' Typical Test Report. **Note:** All certification/inspection requirements must be stated at the time of order placement.

Sizes and pipe connections


1/2", 3/4" and 1" screwed BSP or NPT.


Pressure/temperature limits (ISO 6552)



The product **must not** be used in this region.

	·		•	
Body design conditions			PN16	
PMA	Maximum allowable pres	16 bar g @ 100°C		
TMA	Maximum allowable temp	perature	250°C @ 13 bar g	
Minimum allowable temperature			-10°C	
РМО	Maximum operating pressure for saturated steam service 14 to			
TMO	Maximum operating temp	250°C @ 13 bar g		
Minimum operating temperature			0°C	
	Maximum	FT14-4.5	4.5 bar	
Δ PMX	differential	FT14-10	10 bar	
	pressure	FT14-14	14 bar	
Designed for a maximum cold hydraulic test pressure of 24 bar g				






Materials

	No.	Part	Material				
*	1	Body	SG iron DIN 1693 GGG 40				
	2	Cover bolts	Steel BS 3692 Gr.8.8				
	3	Cover gasket	Reinforced exfoliated graphite				
	4	Cover	SG iron DIN 1693 GGG 40				
	5	Valve seat	Stainless steel BS 970 431 S29				
	6	Valve seat gasket	Stainless steel BS 1449 409 S19				
	7	Pivot frame assembly screws	Stainless steel BS 6105 CI A2-70				
	8	Ball float and lever	Stainless steel BS 1449 304 S16				
	10	Pivot frame	Stainless steel BS 1449 304 S16				
	11	Pivot pin	Stainless steel				
*	12	Erosion deflector (1" only)	Stainless steel BS 970 431 S29				
	17	Air vent assembly	Stainless steel				
	18	Air vent gasket	Stainless steel BS 1449 409 S19				
	19	SLR assembly	Stainless steel BS 970 303 S21				
	20	SLR gasket	Stainless steel BS 1449 304 S16				
	21	SLR seal	Graphite				
	28	Valve spring (1" only)	Stainless steel BS 2056 302 S26				
*	Note: Item 12 is pressed into item 1 (1" only)						

* Note: Item 12 is pressed into item 1 (1" only).

Capacities




Capacities shown above are based on condensate at saturation temperature. When discharging sub-cooled condensate the air vent provides extra capacity. Under start-up conditions when the condensate is cold the internal thermostatic air vent will be open and provides additional capacity to the main valve. On 4.5 bar units this will provide a minimum of 50% increased capacity above the hot condensate figures shown. On 10 and 14 bar units this will be a minimum increase of 100% on the published capacity. The following table gives the minimum additional cold water capacities from the air vent.

ΔP (bar)	0.5	1	2	3	4.5	7	10	14
	Minimum additional cold water capacity (kg/h)							
½" and ¾"	70	140	250	380	560	870	1130	1500
1"	120	240	360	500	640	920	1220	1500

Dimensions/weights (approximate) in mm and kg

Size	Α	В	B1	С	D	E Withdrawal distance	F	Weight
1/2"	121	107	96	67	147	105	30	2.9
3/4"	121	107	96	67	147	105	30	2.9
1"	145	107	117	75	166	110	23	4.0



Safety information, installation and maintenance

For full details see the Installation and Maintenance Instructions (IM-S02-13) supplied with the product.

Installation note:

The FT14 must be installed with the direction of flow as indicated on the body, and with the float arm in a horizontal plain so that it rises and falls vertically. If required the flow orientation can be changed on site.

Disposal

This product is recyclable. No ecological hazard is anticipated with the disposal of this product providing due care is taken.

How to order

Example: 1 off Spirax Sarco 1/2" FT14-4.5 (R-L) ball float steam trap with screwed BSP connections and integral air vent.

Spare parts

The spare parts available are shown in solid outline. Parts drawn in broken line are not supplied as spares.

Available spares

Main valve assembly with float	3, 5, 6, 7 (2 off), 8, 10, 11, 28 (1" only)
Air vent assembly	3, 17, 18
Steam lock release and air vent assembly	3, 17, 18, 19, 20, 21
Cover gasket (packet of 3)	3
Maintenance kit	3, 5, 6, 7 (2 off), 8, 10, 11, 17, 18, 28 (1" only)

How to order spares

Always order spares by using the description given in the column headed 'Available spares' and state the size, type of trap and pressure range.

Example: 1 - Main valve assembly for a Spirax Sarco ½" FT14-10 ball float steam trap.

