## **Production Supporting Systems in Factories**

ระบบสนับสนุนการผลิตในโรงงานอุตสาหกรรม

## **Mobile Sensor**

Android only, no iPhone, sorry

# Install F Droid / termux

- Install F Droid
  - Goto https://f-droid.org
  - Install F-Droid
- Install software from F-Droid
  - Install termux
  - o Install termux:API

## Install node-red

- In termux window
  - apt update
  - o **apt** upgrade
  - o pkg install termux-api
  - pkg install coreutils nodejs
- Install node-red
  - o mom install -g pnpm
  - 🔾 🥅 pnpm setup *(ให้ปิดแบบ Exit แล้วเปิดใหม่)*
  - o pnpm install -g node-red

#### Start node-red

- In termux window
  - o node-red

#### Misc

- See ip address of mobile phone from termux
  - ■ ifconfig
- Test connection from powershell
  - test-netconnection x.x.x.x -port 1880


#### **Sensors**

- termux-sensor -1
- termux-sensor -s <<Sensor Name>>
- termux-sensor -a (all sensors)
- termux-sensor -c (clean up)


# Flashlight

- termux-torch on
- termux-torch off

# **Inspecting sensors**



# Obtaining sensor values




#### function node (Acceleration)

```
const sensor_name = "LSM6DSO Acceleration Sensor"; // Change here
const payload = msg.payload;
const values = payload[sensor_name].values;
const output_value = Math.sqrt(
  values[0] ** 2 + values[1] ** 2 + values[2] ** 2
); // Modify here
msg.payload = output_value;
return msg;
```


### function node (Lux)

```
const sensor_name = "TMD4910 Uncalibrated lux Sensor"; // Change here
const payload = msg.payload;
const values = payload[sensor_name].values;
const output = values[0]; // Modify here
msg.payload = output;
return msg;
```

# exec node (do not forget)



# Resetting/stopping sensors



# Controlling flashlight

