


Production Supporting Systems in Factories

ระบบสนับสนุนการผลิตในโรงงานอุตสาหกรรม


Context (Advanced)

Counter with Reset Button

Flow




Initial Setup



Random Data Function Node

```
const rand = Math.random();  
msg.payload = Math.round(rand * 100) / 100;  
return msg;
```


Gauge Setup



The screenshot displays the 'Gauge Setup' interface. On the left, a canvas shows a 'gauge' component (highlighted with a red box) and a 'set flow.counter' component. On the right, the configuration panel for the 'gauge' component is shown. The 'Type' is set to 'Half Gauge' and the 'Style' is 'Needle'. The 'Value' is set to 'msg. payload'. The 'Limits' section shows a range from 'min. 0' to 'max. 1', highlighted with a red box. The 'Segments' section shows three segments: a green segment at 0, a yellow segment at 0.4, and a red segment at 0.7, all highlighted with a red box.

Segment Color	Value	Label
Green	0	Label
Yellow	0.4	Label
Red	0.7	Label


Switch node



Increment Counter (Function) Node

```
const curCounter = flow.get("counter") ?? 0;  
flow.set("counter", curCounter + 1);  
msg.payload = curCounter + 1;  
return msg;
```

Text Node Setup




button node


The screenshot shows the Node-RED web interface. On the left, a 'button' node (light blue with a hand icon) labeled 'Reset' is highlighted with a red rectangle. It is connected to a 'set flow.counter' node (yellow with a double arrow icon). Above the 'button' node is a 'gauge' node (light blue with a circular arrow icon). On the right, the configuration panel for the 'button' node is visible. It includes fields for 'Label' (set to 'Reset') and 'Class' (set to 'Optional CSS class name(s)'). Below these are three checkboxes: 'Enable pointerdown event' (unchecked), 'Enable pointerup event' (unchecked), and 'Enable click event' (checked). The 'Payload' field is highlighted with a red rectangle and contains a dropdown menu with 'a_z' selected. At the bottom, there is a checkbox for 'Always Send:'.

- Notice no payload is set here.


change node



Cool-Trick with Complete Node



Complete Node Setup



- No more confusing connections!