```
CONST robtarget
Inicio:=[[547.330665099,0,451.64730631],[0.190808996,0,0.981627183,0],[0,0,0,0],
[9E+09,9E+09,9E+09,9E+09,9E+09]];
    CONST robtarget
Target 20:=[[581.212,116.935,200],[0.010103539,-0.044970151,-0.998937134,0.00045
4841],[0,0,0,0],[9E+09,9E+09,9E+09,9E+09,9E+09]];
    CONST robtarget
Target_70:=[[381.212,116.935,200],[0.010103539,-0.044970151,-0.998937134,0.00045
4841],[0,0,0,0],[9E+09,9E+09,9E+09,9E+09,9E+09,9E+09]];
    CONST robtarget
Target_60:=[[581.212,16.935,200],[0.010103539,-0.044970151,-0.998937134,0.000454
841], [0, -1, 0, 0], [9E+09, 9E+09, 9E+09, 9E+09, 9E+09]];
    CONST robtarget
Target_50:=[[381.212,16.935,200],[0.010103539,-0.044970151,-0.998937134,0.000454
841],[0,-1,0,0],[9E+09,9E+09,9E+09,9E+09,9E+09]];
    CONST robtarget
Target_30:=[[581.212,-83.065,200],[0.010103539,-0.044970151,-0.998937134,0.00045
4841],[-1,0,-1,0],[9E+09,9E+09,9E+09,9E+09,9E+09,9E+09]];
    CONST robtarget
Target 40:=[[381.212,-83.065,200],[0.010103539,-0.044970151,-0.998937134,0.00045
4841],[-1,0,-1,0],[9E+09,9E+09,9E+09,9E+09,9E+09,9E+09]];
    VAR num Numero;
    VAR num X;
    PROC main()
        Inicio:
        TPErase;
        TPReadNum Numero, "Selecciona 1 para escribir IN o selecciona 2 para
ecribir una NI";
        TPErase;
        IF Numero=1 THEN
            X:=0;
            Path_I;
            Path N;
            GOTO Inicio;
        ENDIF
        IF Numero=2 THEN
            X:=200;
            Path_I;
            X:=-100;
            Path N;
            GOTO Inicio;
        ENDIF
    ENDPROC
    PROC Path N()
        MoveL Inicio, v1000, z100, MyTool\WObj:=wobj0;
        MoveL Offs(Target_20,0,X,0),v1000,z0,MyTool\WObj:=WO_CAJA;
```

MODULE Module1

```
MoveL Offs(Target_70,0,X,0),v1000,z0,MyTool\WObj:=WO_CAJA;
MoveL Offs(Target_60,0,X,0),v1000,z0,MyTool\WObj:=WO_CAJA;
MoveL Offs(Target_50,0,X,0),v1000,z0,MyTool\WObj:=WO_CAJA;
MoveL Inicio,v1000,z100,MyTool\WObj:=wobj0;
ENDPROC

PROC Path_I()
    MoveL Inicio,v1000,z100,MyTool\WObj:=wobj0;
    MoveL Offs(Target_30,0,X,0),v1000,z0,MyTool\WObj:=WO_CAJA;
    MoveL Offs(Target_40,0,X,0),v1000,z0,MyTool\WObj:=WO_CAJA;
    MoveL Inicio,v1000,z100,MyTool\WObj:=wobj0;
ENDPROC
```

ENDMODULE