

JUL 05, 2023

Preparation of Artificial Urine

 $alow^1$

¹University of Edinburgh



alow

ABSTRACT

A method for producing artificial urine as a media for bacterial experiments

MATERIALS

OPEN ACCESS

dx.doi.org/10.17504/protocol s.io.kxygx3exzg8j/v1

Protocol Citation: alow 2023. Preparation of Artificial Urine. protocols.io https://dx.doi.org/10.17504/p rotocols.io.kxygx3exzg8j/v1

License: This is an open access protocol distributed under the terms of the Creative Commons Attribution License, which permits unrestricted use, distribution, and reproduction in any medium, provided the original author and source are credited

Protocol status: Working We use this protocol and it's working

Created: Jul 05, 2023

Last Modified: Jul 05, 2023

PROTOCOL integer ID:

84532

A	В	С	D	E	F
Formula	Name	Mass (g) per 100 mL	CAS number	Catalogue code	Manufacturer
Na2SO4	Sodium sulphat e	0.17			
Na3C6H5O 7.2H2O	Tri- sodium citrate	0.072			
C4H7N3O	Creatini ne	0.081	60-27-5	K5225680	Sigma
CH4N2O	Urea	1.5	57-13-6	15604-1Kg	Sigma
KCI	Potassi um chloride	0.230 8			
NaCl	Sodium chloride	0.175 6			
CaCl2	Calcium chloride anhydro us	0.018 5	10043- 52-4	C1016-500G	Sigma

A	В	С	D	E	F
NH4CI	Ammon ium chloride	0.126 6			
K2C2O4.H 2O	Potassi um oxalate	0.003 5	607-007- 00-3	G0425-250G	Honeywell
MgSO4.7H 20	Magnes ium sulphat e	0.108 2	10034- 99-8	M2773-500G	Sigma
NaH2PO4. 2H2O	Sodium dihydro gen orthoph osphate dihydrat e	0.291	13472- 35-0		
Na2HPO4. 2H2O	Sodium phosph ate monoba sic dihydrat e	0.083	10028- 24-7	71645-1Kg	Sigma
	Bacterio logical Peptone	0.2		LP0037	Oxoid
	Yeast Extract	0.001		70161-100g	Fluka
	Ultrapur e water				

Table 1: Reagents required

1 Take twelve 50 mL tubes and label with sufficient information. There are 12 reagents (Table 1 in Materials) which require plastic tube storage so you can label these 1 to 12 but missing out

Weight out the chemical powders to the labelled tubes as described in table 2.

А	В	С	D
Reag ent ID	Formula	Name	Recommended Stock Preparation
1	Na2SO4	Sodium sulphate	8.5g in 50mL water (X100)
2	Na3C6H 507.2H2 0	Tri-sodium citrate	3.6g in 50mL water (X100)
3	C4H7N3 0	Creatinine	4.05g in 50mL water (X100) do not chill
4	CH4N2O	Urea	(15g per 100mL) 22.5g in 150mL water (X10) made fresh on the day of combining reagents. Endothermic, warm to 37C to prevent cooling the mixture upon addition and causing other salts to precipitate Calculate how much required on the day.
5	KCI Potassium chloride		11.54g in 50mL water (X100)
6	NaCl	Sodium chloride	8.78g in 50mL water (X100)
7	CaCl2	Calcium chloride anhydrous	0.925g in 50mL water (X100) caution - alkali
8	NH4Cl Ammonium chloride		6.33g in 50mL water (X100)
9	K2C2O4. H2O	Potassium oxalate	2 steps: dissolve 1.75g in 50mL water (X1000) then transfer 5mL to a new tube and make up to 50mL with water for X100
10	MgS04. 7H20	Magnesium sulphate	5.41g in 50mL water (X100)
11	NaH2P0 4.2H20	Sodium dihydrogen orthophosphate dihydrate	14.56g in 50mL water (X100)
12	Na2HPO 4.2H2O	Sodium phosphate monobasic dihydrate	4.155g in 50mL water (X100)
13		Bacteriological Peptone	(2g per 100mL) 9g in 450mL water in a glass bottle (X10) and autoclaved.
14		Yeast Extract	0.18g in 100mL water (X100) autoclave

Table 2

3 Add 40-45 mL ultrapure water to the powders and give them time to go fully into solution. It may be necessary to warm some chemicals.

- Depending upon what volume of AU you want to prepare, you will need to calculate how much of reagent 4 (Urea) to make. For 1L AU, you need 100 mL of the 10X reagents so you may want to prepare 1.5 times the volumes in order to be able to accurately transfer 100 mL. Urea should be prepared in a glass bottle of sufficient size for the volume being made. After dissolving the powder and making up to the final volume with ultrapure water, warm up the urea, or use prewarmed water to dissolve. Due to the endothermic nature of urea dissolving, the liquid becomes sufficiently cold such that it also cools down the mixture of reagents after it is added and will cause reagent 9 to precipitate. Once reagent 9 precipitates out of solution, it is very difficult to reverse the reaction so you will not get a true AU solution and you will need to begin mixing again! However, urea also breaks down with heat to form isocyanates which may be detrimental to bacteria so it is recommended to avoid unnecessary heating.
- The media components, reagents 13 and 14, can be prepared in glass bottles and autoclaved. Note, the final AU will be filter sterilized since not all reagents are sufficiently heat stable to be sterilized by autoclaving. So it is not essential to autoclave the Peptone or YE but if you plan to keep these media components more than the working day, you should autoclave them and prepare them in glass bottles.
- 6 Top up the 12 plastic tubes to exactly 50 mL each with more ultrapure water.
- 7 For reagent 9, Potassium oxalate, transfer 5 mL of the now ready 1000X into a new 50 mL tube and top up to 50 mL to produce the 100X stock.
- 8 Take ten 10mL stripettes (which can be labelled and reused if the packaging is retained).
- Being transferring each of the reagents into a 1L beaker or 1L measuring cylinder, one at a time in the order that they appear in the list. (It should work in any order but it can help to prevent precipitation if the order is followed.) Use a stripette to transfer 10 mL for the 100X reagents. Add reagent 9, Potassium oxalate DROPWISE to help avoid precipitation. It will also help to prevent any precipitation if you add in 100-200 mL ultrapure water at the start.
- 10 Transfer 100 mL of the 10X reagents.

11 Use a Bunsen with the media components (reagents 13 and 14) to maintain sterility of the stocks. 12 After addition of all 14 reagents, top up to 1L with ultrapure water and mix well. 13 Aliquot the AU as desired and freeze for storage longer than 2 days, otherwise keep at 4°C when not in use. 14 AU contains some reagents which cannot be autoclaved, so the final solution must be filter sterilized using a 0.2 um filter before being used in an experiment. 15 Disposal: AU can be flushed down the sink with plenty water. AU that has been used to grow bacteria or harbours phages must be collected into an autoclavable container.