

Apr 19, 2024



BAF Protocol 008 Metabolomics: Soluble Metabolite Extraction

DOI

dx.doi.org/10.17504/protocols.io.yxmvmex5ng3p/v1

Nicholas Sherman¹

¹University of Virginia Biomolecular Analysis Facility Core



Taylor Pierce

Taylor _{UVA}





DOI: dx.doi.org/10.17504/protocols.io.yxmvmex5ng3p/v1

Protocol Citation: Nicholas Sherman 2024. BAF_Protocol_008 Metabolomics: Soluble Metabolite Extraction. protocols.io https://dx.doi.org/10.17504/protocols.io.yxmvmex5ng3p/v1

License: This is an open access protocol distributed under the terms of the Creative Commons Attribution License, which permits unrestricted use, distribution, and reproduction in any medium, provided the original author and source are credited

Protocol status: Working We use this protocol and it's

working

Created: April 15, 2024

Last Modified: April 19, 2024

Protocol Integer ID: 98212

Keywords: mass spectrometry, metabolomics, aqueous soluble molecules, sample prep, extraction

Abstract

This is a standard metabolite sample prep using chloroform/methanol and keeping the soluble (aqueous) phase. This method will produce a clean sample free of most lipids and very hydrophobic molecules. The samples are ready for MS analysis or storage dry at -80C.



Guidelines

Make sure some type of normalization is considered before starting - dry weight, cell number, etc - so equal amounts of material can be injected into the MS. This can be done by counting the same number of cells into each sample tube or weighing the same amount of tissue/stool into each tube or if larger differences you may adjust the extraction volume to account of the differences.

Materials

Microtubes 1.5 mL - SEAL-RITE® 1.5 ML MICROCENTRIFUGE TUBES color: natural, USA Scientific

Reinforced tubes 2 mL- with screw caps and 0-rings, Fisherbrand™, White/Opaque, part number 5-340-162.

Stainless steel balls - OMNI International 2.4mm Metal Bead Media 500g SKU 19-640

Pipette tips - Fisherbrand[™], yellow, part number: 02-681-151.

Water - Fisher chemical, W64, Optima LC/MS

FA - Fisher chemical, A117-50, Formic Acid, Optima LC/MS

Methanol - Fisher chemical, A456-212, Methanol, Optima LC/MS

Chloroform - Millipore sigma, CX1050P-1, Chloroform, HPLC grade

2 to 20 µL Micropipette - Gilson™ F144056MT

20 to 200 µL Micropipette - Gilson™ F144058MT

100 to 1000 µL Micropipette - Gilson™ F144059MT

VWR Analog Vortex mixer - CAT No: 58816-121

Thermo Scientific™ integrated Speedvac Concentrator CAT No: SPD1030-115

Eppendorf 5415D Digital Centrifuge

Thermo Scientific™ Thermal Mixer with blocks, Block, 24 x 2.0mL microtubes, CAT No: 13687713

Fisherbrand™ bead Mill 24 homogenizer CAT No: 15-340-163

Autosampler vials - SureSTART™ 6ERV11-03PPC Vial 0.3mL CLR PP SNP CON

Vial caps - SureSTART™ 6ARC11ST10R Cap snap 11mm orange polyethylene



Liquid Samples: Urine, Plasma, Cell Media		
1	To each sample containing 100 uL add 750 μL of -20°C cold Chloroform:methanol (2:1) mixture and vortex	1m
2	Shake tubes vigorously for 30 min at 4°C in temperature temperature-controlled thermal shaker	30m
3	Add 400 µL of water, shake vigorously, and centrifuge for 10 min at 10000 rpm for phase separation.	11m
4	Recover the top aq. methanolic phase as metabolite mixture and transfer to Eppendorf tube.	1m
5	Dry the soluble metabolite samples under vacuum for 3-4 h. Store at -80°C until ready for LC-MS(/MS) analysis.	3h
6	*Note: save the lower phase if you need to extract lipids. Go for BAF_Protocol_009.	
7	Before running, reconstitute samples in 100 µL of 0.1% Formic acid in water containing 100X diluted Metabolomics QReSS heavy labeled standards. (https://www.isotope.com/userfiles/files/assetLibrary/MET_RSCH_QReSS.pdf)	2m
8	Prepare a QC sample with 10 μL of each sample and transfer 50 uL of each sample to autosampler vials	5m
9	Injection volume of each sample: 10 μL	
Samples that need disruption/lysis: Tissue, Stools, Cell pellets		10m
10	Place the sample into reinforced tubes: frozen tissue slice or lyophilized stools. For cell pellets: mix well with 50-100 uL of water transfer solution and suspended cells to reinforced tubes.	5m
11	To each sample add 5 stainless steel balls, 750 μL of -20 C cold Chloroform:methanol (2:1) mixture	2m
12	Disrupt cells/tissues with Fisher Bead Mill 24 (speed: 5m/s, time: 20 sec, number of cycle: 3, dwell/pause between runs: 10 sec)	3m



13 Follow steps #2 to #9.