



Version 1 ▼

Oct 15, 2020

Calibrating a pH pmeter V.1

PMAT0001

1 Works for me

This protocol is published without a DOI.

LKC Translational Neuro

PMAT0001

ABSTRACT

Step-by-step instructions on calibrating a pH meter

PROTOCOL CITATION

PMAT0001 2020. Calibrating a pH pmeter. **protocols.io** https://protocols.io/view/calibrating-a-ph-pmeter-bng2mbye

LICENSE

This is an open access protocol distributed under the terms of the Creative Commons Attribution License, which permits unrestricted use, distribution, and reproduction in any medium, provided the original author and source are credited

CREATED

Oct 15, 2020

LAST MODIFIED

Oct 15, 2020

PROTOCOL INTEGER ID

43258

MATERIALS

NAME	CATALOG #	VENDOR
Water refers to sterilized deionized water		
Potassium Chloride	P9541	Sigma Aldrich
HyperSep™ SLE Cartridge (pH 7), 20g/60mL	60109-20000-60-7	Thermo Fisher
Orion™ pH 4.01 Buffer, Individual Use, Pink, 25 Pouches, pH 4.01 Buffer, Color Coded Pink, 25 Pouches	910425	Thermo Fisher
nH meter		

DISCLAIMER:

DISCLAIMER - FOR INFORMATIONAL PURPOSES ONLY; USE AT YOUR OWN RISK

The protocol content here is for informational purposes only and does not constitute legal, medical, clinical, or safety advice, or otherwise; content added to protocols.io is not peer reviewed and may not have undergone a formal approval of any kind. Information presented in this protocol should not substitute for independent professional judgment, advice, diagnosis, or treatment. Any action you take or refrain from taking using or relying upon the information presented here is strictly at your own risk. You agree that neither the Company nor any of the authors, contributors, administrators, or anyone else associated with protocols.io, can be held responsible for your use of the information contained in or linked to this protocol or any of our Sites/Apps and Services.

ABSTRACT

Step-by-step instructions on calibrating a pH meter

Main ste	ps	
1	Press "Cal"	
2	Press "✔\"	
3	Dip in pH 4	
4	Press "✔\"	
5	Rinse pH meter	
6	Dip in pH 7	
7	Press "✔\"	
8	Dip into sample; Note percentage purity as well	
Important notes		
	- When liquid level falls way below the "hole" at the top, replenish with some KCI - After finishing experiments for the day, rinse pH meter, secure top with parafilm and put in KCI (parafilm to the KCI	

storage as well)