

APR 11, 2024

OPEN BACCESS



DOI:

dx.doi.org/10.17504/protocols.io.k xygxymdwl8j/v1

Protocol Citation: Emilio Cirri, Hannah Knaudt, Domenico Di Fraia, Nadine Pömpner, Norman Rahnis, Ivonne Heinze, Alessandro Ori, Therese Dau 2024. Automated BioID sample preparation. protocols.io https://dx.doi.org/10.17504/protoc ols.io.kxygxymdwl8j/v1

MANUSCRIPT CITATION:

Cirri, E., Knaudt, H., Fraia, D. Di, Pömpner, N., Rahnis, N., Heinze, I., Ori, A., & Dau, T. (2023). Automated workflow for BioID improves reproducibility and identification of protein-protein interactions. BioRxiv, 2023.09.08.556804. https://doi.org/10.1101/2023.09.08.556804

Automated BioID sample preparation

Emilio Cirri¹, Hannah Knaudt¹, Domenico Di Fraia¹, Nadine Pömpner¹, Norman Rahnis¹, Ivonne Heinze¹, Alessandro Ori¹, Therese Dau¹

¹Leibniz Institute on Aging - Fritz Lipmann Institute (FLI), Jena, Germany



Emilio Cirri Leibniz Institute on Aging - FLI Jena

ABSTRACT

We introduce an automated workflow for proximity dependent biotinylation on a liquid handler to process up to 96 samples at a time,combined with shorter liquid chromatography gradients and data-independent acquisition to increase analysis throughput and enable reproducible protein quantitation

PROTOCOL REFERENCES

Bartolome, A.; Heiby, J. C.; Fraia, D. D.; Heinze, I.; Knaudt, H.; Späth, E.; Omrani, O.; Minetti, A.; Hofmann, M.; Kirkpatrick, J. M.; Dau, T.; Ori, A. ProteasomelD: Quantitative Mapping of Proteasome Interactomes and Substrates for in Vitro and in Vivo Studies, 2024. https://doi.org/10.7554/elife.93256.1.

protocols.io

License: This is an open access protocol distributed under the terms of the Creative Commons Attribution License, which permits unrestricted use, distribution, and reproduction in any medium, provided the original author and source are credited

Protocol status: Working We use this protocol and it's working

Created: Apr 05, 2024

Last Modified: Apr 11, 2024

PROTOCOL integer ID: 97832

Keywords: BioID, proteomics, proximity labeled, automation

MATERIALS

Sulfo-NHS-Acetate (Thermo Fisher)

- LysC (Cell Signaling)
- · Trypsin (MS grade) (Thermo Fisher)
- Aprotinin (Carl Roth)
- · Leupeptin (Carl Roth)
- Turbonuclease (MoBiTec GmbH)
- Trizma base (Sigma-Aldrich)
- · Ammonium Bicarbonate (Sigma-Aldrich)
- · HEPES (Sigma-Aldrich)
- NaCl (Sigma-Aldrich)
- · EDTA (Sigma-Aldrich)
- EGTA (Sigma-Aldrich)
- Triton X-100 (Sigma-Aldrich)
- SDS (Sigma-Aldrich)
- Acetonitrile (Biosolve)
- Trifluoroacetic acid (Sigma-Aldrich)
- · Methanol (Biosolve)
- · Formic Acid (Sigma-Aldrich)

Buffers

- PBS
- **Lysis buffer**: 50 mM Tris, 150 mM NaCl, 1 mM EDTA, 1 mM EGTA, 1% Triton, 0.1% SDS,

 $1.5 \mu M$

aprotinin, 10 µM leupeptin, 250U Turbonuclease

- **Acetylation buffer:** 10 mM sulfo-NHS acetate
- Wash buffer: 50 mM AmBic, pH 8.3
- **Digest buffer:** 0.5 µg LysC in 50 mM AmBic
- Elution buffer: 10% TFA in ACN
 Maintenance buffers: 20% ACN

General concept

Proximity dependent biotinylation (BioID) is an important method to study protein-protein interactions in cells, for which an expanding number of applications has been proposed. The laborious and time consuming sample processing has limited project sizes so far. Here, we introduce an automated workflow on a liquid handler to process up to 96 samples at a time. The automation does not only allow higher sample numbers to be processed in parallel, but also improves reproducibility and lowers the minimal sample input. Furthermore, we combined automated sample processing with shorter liquid chromatography gradients and data-independent acquisition to increase analysis throughput and enable reproducible protein quantitation

across a large number of samples. We successfully applied this workflow to optimize the detection of proteasome substrates by proximity-dependent labeling.

Abbreviations

2

ACN - Acetonitrile,

AmBic - Ammonium Bicarbonate,

DIA - Data Independent

Acquisition,

DMEM - Dulbecco's Modified Eagle

Medium,

EDTA – Ethylene Diamine

Tetraacetic Acid,

EGTA - (Ethylene Glycol-bis(β-aminoethyl

ether)-N,N,N',N'-Tetraacetic Acid,

FBS - Fetal Bovine Serum,

HEPES -

4-(2-hydroxyethyl)-1-piperazineethanesulfonic acid,

PBS - Phosphate-Buffered Saline,

RT - Room Temperature,

SDS - Sodium Dodecyl Sulfate,

TFA - Trifluoroacetic acid

Reagents

- 3 Sulfo-NHS-Acetate (Thermo Fisher)
 - LysC (Cell Signaling)
 - · Trypsin (MS grade) (Thermo Fisher)
 - · Aprotinin (Carl Roth)
 - Leupeptin (Carl Roth)
 - · Turbonuclease (MoBiTec GmbH)
 - · Trizma base (Sigma-Aldrich)
 - · Ammonium Bicarbonate (Sigma-Aldrich)
 - · HEPES (Sigma-Aldrich)
 - · NaCl (Sigma-Aldrich)
 - · EDTA (Sigma-Aldrich)
 - · EGTA (Sigma-Aldrich)
 - · Triton X-100 (Sigma-Aldrich)
 - · SDS (Sigma-Aldrich)
 - · Acetonitrile (Biosolve)

protocols.io

- · Trifluoroacetic acid (Sigma-Aldrich)
- · Methanol (Biosolve)
- · Formic Acid (Sigma-Aldrich)

Buffers

- PBS
- **Lysis buffer**: 50 mM Tris, 150 mM NaCl, 1 mM EDTA, 1 mM EGTA, 1% Triton, 0.1% SDS, 1.5 μ M aprotinin, 10 μ M leupeptin, 250U Turbonuclease
- **Acetylation buffer:** 10 mM sulfo-NHS acetate
- Wash buffer: 50 mM AmBic, pH 8.3
- **Digest buffer:** 0.5 μg LysC in 50 mM AmBic
- Elution buffer: 10% TFA in ACNMaintenance buffers: 20% ACN

Procedure

4 Expression of fusion proteins

4.1 <u>Cell culture</u>

- Day 1: Seed 1.5 Mio cells per P150 plate
- Day 2: Induce expression of BirA construct by adding Tetracycline 1:1000
- Tetracycline stock: 1 mg/ml in Ethanol
- Day 3: Add 50 μM of Biotin (in water)
- Day 4: Collect cells

4.2 Collection of cells

- Wash cells 2x with RT PBS + Ca/Mg
- Add Trypsin and incubate 7 minutes at RT or till cells start to detach
- Add 2x DMEM with 5% FBS and pipet cells carefully off
- Spin 5 min, 500g at 4°C
- Remove supernatant and
- Resuspend cells in 10 ml cold PBS
- Count the cells (1:5 -1:10 dilution)
- Prepare tubes with 4 Mio cells each
- Spin 5 min, 500g at 4°C

- - Snap freeze samples in liquid nitrogen and store at -20°C

4.3 <u>Preparing the Lysates</u>

- Resuspend the pellet of 20 Mio cells in 1.25 ml of Lysis buffer in a 15ml falcon tube (scale accordingly to amount of cells)
- Lyse the cells by rotating the falcon tube for 1h, 15rpm at 4°C
- Transfer to 1.5 ml tube.

Remove supernatant

• Sonicate the sample 10x 30sec on/off in Bioruptor at 4°C

Note

No visible aggregates should be there, otherwise sonicate more

- Spin the samples 30min, 4°C, 17000g
- Keep supernatant

Operate Agilent Bravo Automated Liquid Handling Platform

5 <u>Starting operations</u>

Start Bravo AssayMAP using the pre-set "System startup" under "Utility library"

2. Acetylation of cartridges (>72 min)



- Open pre-set "On-cartridge reaction" under "App library"
- Add the following labware and buffers to the

appropriate places:

- #3 Equilibration & Chase Buffer: 320 μl PBS
- #4 Reagent: 50 μl acetylation buffer

Note

Stop after equilibration and add only immediately before acetylation step

- #5 Wash Buffer 1: 300 μl BioID lysis buffer
- #7 Flow Through: empty plate for waste collection

- Set program steps:
- Check "Initial Syringe Wash"
- Check "Equilibrate":
- Volume: 200 μl, Flow Rate: 10 μl/min, Wash Cycles: 1
- Check "Reaction":
- Volume: 6µl, Wash cycles: 1
- Temperature: 25°C, Duration: 30 min, Reaction Chase: Volume: 100 μl, Flow rate: 10 μl/min
- Check "Cup Wash 1":
- Volume: 25 µl, Cycles: 2
- Check "Internal Cartridge Wash 1":
- Volume: 200 μl, Flow rate: 20 μl/min
- Uncheck everything else

5.2 <u>Loading of samples (opt.)</u>

•

This is optional and depends on the amount of input.

Needs to be repeated as many times as needed.

- Stay with pre-set "On-cartridge reaction" under "App library"
- Add the following labware and buffers to the appropriate places:
- #3 Equilibration & Chase Buffer: 250 μl sample
- #5 Wash Buffer 1: 250 μl sample
- #6 Wash Buffer 2: 250 μl sample
- #7 Flow Through: empty plate to collect flow through
- #8 Elution & Syringe Wash buffer: 250 µl sample
- #9 Eluate collection: empty plate to collect flow through
- Set program steps:
- Check "Equilibrate":
- Volume: 250 μl, Flow Rate: 10 μl/min, Wash Cycles: 0
- Check "Collect Flow Through"
- Check "Internal Cartridge Wash 1"
- Volume: 250 μl, Flow Rate: 10 μl/min, Wash Cycles: 0
- Check "Collect Flow Through"
- Check "Internal Cartridge Wash 2"
- Volume: 250 μl, Flow Rate: 10 μl/min, Wash Cycles: 0
- Check "Collect Flow Through"
- Check "Eluate"
- Volume: 250 μl, Flow Rate: 10 μl/min, Wash Cycles: 0
- Uncheck everything else

g protocois.io

- 5.3 <u>Loading of samples including first wash (>60 min)</u>
 - Stay with pre-set "On-cartridge reaction" under "App library"
 - Add the following labware and buffers to the appropriate places
 - #5 Wash Buffer 2: 250 μl samples
 - #6 Wash Buffer 2: 250 μl samples
 - #7 Flow Through: empty plate to collect flow through
 - #8 Elution & Syringe Wash Buffer: 250 μl lysis buffer
 - #9 Elutate collection: empty plate to collect waste (BioID lysis buffer)
 - Set program steps:
 - Check "Internal Cartridge Wash 1"
 - Volume: 250 μl, Flow Rate: 10 μl/min, Wash Cycles: 1
 - Check "Collect Flow Through"
 - Check "Internal Cartridge Wash 2"
 - Volume: 250 μl, Flow Rate: 10 μl/min, Wash Cycles: 1
 - Check "Collect Flow Through"
 - Check "Eluate"
 - Volume: 200 μl, Flow Rate: 20 μl/min, Wash Cycles: 1
 - Uncheck everything else

5.4 Washing steps (26 min)

- Stay with pre-set "On-cartridge reaction" under "App library"
- Add the following labware and buffers to the appropriate places:
- o #5 Wash Buffer 1: 320 µl wash buffer
- o #6 Wash Buffer 2: 200 µl wash buffer
- Set program steps:
- Check "Cup Wash 1":
- Volume: 25 µl, Cycles: 2
- Check "Internal Cartridge Wash 1"
- Volume: 250 μl, Flow Rate: 30 μl/min, Wash Cycles: 1
- Check "Cup Wash 2":
- Volume: 25 µl, Cycles: 2
- Check "Internal Cartridge Wash 2"
- Volume: 125 μl, Flow Rate: 10 μl/min, Wash Cycles: 1
- Uncheck everything else

5.5 <u>LysC digestion and first (mild) elution (>128 min)</u>

- Stay with pre-set "On-cartridge reaction" under "App library"
- Add the following buffers to the appropriate places:
- #4 Reagent: 30 μl digest buffer NB: always make fresh and vortex

- o #5 Wash Buffer 1: 100 μl wash buffer
- #6 Wash Buffer 2: 100 μl wash buffer
- #7 Flow Through: empty plate to collect elution
- Set program steps:
- Check "Reaction":
- Volume: 6 µl, Wash Cycles: 1
- Temperature: 45°C, Duration: 120 min, Reaction Chase: Volume: 0 μl, Flow rate: 0 μl/min
- Check "Internal Cartridge Wash 1"
- Volume: 25 μl, Flow Rate: 10 μl/min, Wash Cycles: 1
- Check "Collect Flow Through"
- Check "Internal Cartridge Wash 2"
- Volume: 50 μl, Flow Rate: 10 μl/min, Wash Cycles: 1
- Check "Collect Flow Through"
- Uncheck everything else
- Transfer flow through (plate #7) into tubes for further digestion with trypsin.

5.6 <u>Highly acidic elution (>10 min)</u>

- Stay with pre-set "On-cartridge reaction" under "App library"
- Add the following labware and buffers to the appropriate places:
- #3 Equilibration & Chase Buffer: 100 μl elution buffer.

Note

Always make fresh buffer and vortex

- #5 Wash Buffer 1: 100 μl elution buffer
- #6 Wash Buffer 2: 200 μl maintenance buffer
- #7 Flow through: empty plate to collect elution
- o #8 Stringent Syringe Wash Buffer: 200 μl maintenance buffer
- Set program steps:
- Check "Equilibrate":
- Volume: 15 μl, Flow Rate: 90 μl/min, Wash Cycles: 1
- Check "Collect Flow Through"
- Check "Internal Cartridge Wash 1"
- Volume: 15 μl, Flow Rate: 90 μl/min, Wash Cycles: 1
- Check "Collect Flow Through"
- Check "Cup Wash 2":
- Volume: 25 µl, Cycles: 2

- o Check "Internal Cartridge Wash 2"
- Volume: 50 μl, Flow Rate: 10 μl/min, Wash Cycles: 1
- Check "Stringent Syringe Wash"
- Volume: 50 μl, Flow Rate: 5 μl/min, Wash Cycles: 1
- Check "Final Syringe Wash"
- Wash Cycles: 3
- Uncheck everything else
- Transfer flow through (plate #7) into tubes for furtherdigest with trypsin.

5.7 Shut down the robot after the enrichment

• Shut down the Bravo AssayMAP using the pre-set "System shutdown" under "Utility library"

Trypsin digest

6 For first mild elutions:

- Add 0.5 μg of trypsin
- Digest o/n, 37 °C, 500rpm

7 For highly acidic elutions:

- Speed-vac the samples until dry
- Resuspend in 50 µl of 50 mM HEPES
- Check the pH it needs to be pH 6-8 for Trypsin to work. If not re-buffer with sodium hydroxide
- Add 0.5 μg of trypsin
- Digest o/n, 37 °C, 500rpm

Clean up

- Acidify with 10 % TFA. Check pH, it should be <3, if not add more 10 % TFA
 - For both Ambic and ACN elutions, perform **OASIS** clean up according to manufacturer's instructions
 - Store dried peptides until use