



Aug 18, 2021

♠ High Throughput Semi-Automated SARS-CoV-2 Library Preparation Protocol for Ion Torrent Sequencing using Opentrons, New England Biolabs Kit, and ARTIC Primers V.2

Elias Dahdouh¹, Fernando Lázaro Perona², María Rodríguez Tejedor¹, Rubén Cáceres Sánchez², Iván Bloise Sánchez², Jesús Mingorance¹

¹Hospital Universitario La Paz, Molecular Microbiology Group, IdiPAZ, Madrid, Spain;

²Hospital Universitario La Paz, Department of Microbiology and Parasitology, Madrid, Spain

1 Works for me Share

dx.doi.org/10.17504/protocols.io.bxdppi5n

Coronavirus Method Development Community

Elias Dahdouh

DISCLAIMER

DISCLAIMER - FOR INFORMATIONAL PURPOSES ONLY; USE AT YOUR OWN RISK

The protocol content here is for informational purposes only and does not constitute legal, medical, clinical, or safety advice, or otherwise; content added to protocols.io is not peer reviewed and may not have undergone a formal approval of any kind. Information presented in this protocol should not substitute for independent professional judgment, advice, diagnosis, or treatment. Any action you take or refrain from taking using or relying upon the information presented here is strictly at your own risk. You agree that neither the Company nor any of the authors, contributors, administrators, or anyone else associated with protocols.io, can be held responsible for your use of the information contained in or linked to this protocol or any of our Sites/Apps and Services.

ABSTRACT

This protocol is for the preparation of libraries for 96 samples of SARS-CoV-2 using the New England Biolabs NEBNext[®]Fast DNA Library Prep Set for Ion Torrent™ kit, ARTIC primer pools, the Ion Express Barcodes, and sequencing through Ion Torrent. The library preparation is semi-automated with the open source Opentrons robot. The volumes, concentrations, cycling conditions, and Opentrons protocols have been optimized through a series of experiments and are currently being used at our lab on a weekly basis. The samples used for this protocol were extracted after being obtained from nasopharyngeal swabs, placed in viral transport medium, and mixed 1:1 with AVL buffer (Qiagen). It is advisable to perform a screening for the samples before starting the library preparation by RT-qPCR and select the samples that have Ct values below 30.

DO

dx.doi.org/10.17504/protocols.io.bxdppi5n

PROTOCOL CITATION

Elias Dahdouh, Fernando Lázaro Perona, María Rodríguez Tejedor, Rubén Cáceres Sánchez, Iván Bloise Sánchez, Jesús Mingorance 2021. High Throughput Semi-Automated SARS-CoV-2 Library Preparation Protocol for Ion Torrent Sequencing using Opentrons, New England Biolabs Kit, and ARTIC Primers.

protocols.io

https://dx.doi.org/10.17504/protocols.io.bxdppi5n

Version created by Elias Dahdouh

protocols.io

08/18/2021

Citation: Elias Dahdouh, Fernando Lázaro Perona, MarÃÂa RodrÃÂguez Tejedor, Rubén Cáceres Sánchez, Iván Bloise Sánchez, Jesðs Mingorance (08/18/2021). High Throughput Semi-Automated SARS-CoV-2 Library Preparation Protocol for Ion Torrent Sequencing using Opentrons, New England Biolabs Kit, and ARTIC Primers. https://dx.doi.org/10.17504/protocols.io.bxdppi5n

KEYWORDS

SARS-CoV-2, Next Generation Sequencing, Low Cost, Opentrons, Semi-automation, NebNext, Ion Torrent

LICENSE

This is an open access protocol distributed under the terms of the Creative Commons Attribution License, which permits unrestricted use, distribution, and reproduction in any medium, provided the original author and source are credited

CREATED

Aug 16, 2021

LAST MODIFIED

Aug 18, 2021

PROTOCOL INTEGER ID

52367

GUIDFLINES

General guidelines that apply to the entire preparations, unless explicitely said otherwise:

- 1. It is preferable to pre-screen the samples with RT-qPCR and only include the samples that have Ct values below 30
- 2. All the reagents, samples, and master mixes should remain on ice unless explicitly indicated otherwise
- 3. Mixing the reagents and samples thoroughly is crucial in every step
- 4. It is recommended to separate the workstations and working areas into pre-PCR and post-PCR
- 5. Compatibility of the plastic material should be checked before running the OT-2 protocols
- 6. Exact positions on the deck should be used with the OT-2 (make sure if a mold is needed for the 96-well plate or not. General rule is that the mold is always used with the temperature module and is not used in the 3 protocols where the Mag-Bind Magnetic Bead purification is done)
- 7. In order to check the deck design for the OT-2 protocols, reagents needed, and positions, use the following link and import the respective protocol: https://designer.opentrons.com/ then go to the "Design" tab, select "Starting Deck State", and click on the "Names and Liquids" for each labware after mousing over them
- 8. Calibrate the OT-2 workstations every time you load a new protocol
- 9. It is important to use the exact material and conditions specified since any change in reagents does not guarantee good results
- 10. If OT-2 is not available, then the use of multi-channel pipettes and a magnet for 96-well plates can greatly reduce the hands-on time needed for the library preparations
- 11. Unless otherwise indicated, the timing for each step is estimated considering the OT-2 protocols will be used. These times might vary if the steps are done manually

The labware used in the OT-2 protocols are the following:

- BioRad 96-well plates (with or without the 96-well aluminum mold, depending on the protocol)
- NEST 12-well, 15mL reagent reservoirs
- NEST 2mL screwcap polypropylene tubes with the respective aluminum block
- Opentrons 96 filter tip rack 20µL
- Opentrons 96 filter tip rack 200µL

WARNING: If any of these material were substituted with another brand, the OT-2 protocols need to be changed accordingly using the protocol designer (https://designer.opentrons.com/) since otherwise the difference in the dimensions of the labware will cause the OT-2 protocol to fail. In all cases, it is highly recommended to have a trial run using nuclease-free water for all the OT-2 protocols before using them with actual samples and reagents in order to check that all the material and labware is compatible.

DISCLAMER: The volumes, concentrations, and cycling conditions in this protocol are different from those recommended by the manufacturers. Though we have tested these conditions and found them to be adequate, we cannot guarantee the results that the manufacturers can guarantee using their preset protocols. Moreover, this protocol is to be solely used for research purposes.

MATERIALS TEXT

The equipment needed for this protocol are:

- 1. P10, P20, P200, and P1000 single channel pipettes
- 2. P10, P20, and P200 multi-channel pipettes
- 3. Thermal cycler (make sure that it is compatible with the 96-well plate used with OT-2)
- 4. 96-well plate benchtop centrifuge
- 5. 96-well plate magnet (if the OT-2 with the magnetic module is not used)
- 6. Ion Chef™ System
- 7. Ion GeneStudio™ S5 System
- 8. Qubit Fluorometer (can be replaced with any other fluorometer)
- 9. Opentrons OT-2 with the following:
 - P20 GEN-2 single channel pipette (to be installed on the left side)
 - P300 GEN-2 multi-channel pippette (to be installed on the right side)
 - 24-well aluminum block
 - 96-well aluminum block
 - Magnetic module (to be installed for the protocols in which it is needed)
 - Temperature module (to be installed for the protocols in which it is needed)
 - Any PC/laptop with Windows, MAC, or Linux installed, connected to OT-2 with the relative Opentrons App installed

The material and reagents needed for this protocol (for each 96-well plate library preparation) are:

- 1. Extracted nucleic acids containing SARS-CoV-2 RNA
- 2. SuperScript IV VILO Master Mix (Thermo Fisher Scientific) 50 reactions x 2
- 3. NEBNext[®]Fast DNA Library Prep Set for Ion Torrent™ (New England Biolabs) 50 reactions x 1
- 4. hCoV-2019/nCoV-2019 Version 3 Amplicon Set Primer Pools (ARTIC) x 1 (each pool) (IDT)
- 5. Ion Xpress Barcode Sets from 1 to 96 (Thermo Fisher Scientific) (can be replaced with less barcodes that could be reused **only if** the samples will be loaded on separate chips)
- 6. Ion 510™ & Ion 520™ & Ion 530™ Kit Chef that contains the Ion Chef reagents, supplies, and S5 initialization reagents (Thermo Fisher Scientific) x 2 sets
- 7. Ion 530™ Chip Kit (containing 8 chips) (Thermo Fisher Scientific) x 1
- 8. Mag-Bind® Total Pure NGS magnetic beads 500mL (Omega Biotek) x 1
- 9. Qubit dsDNA BR (Broad Sensitivity) or HS (High Sensitivity) Assay kit and tubes (if another fluorometer is used then these should be replaced accordingly) 100 assays x 1 and 100 tubes
- 10. Nuclease-free water x 500mL
- 11. Ethanol (Molecular Biology Grade) x 500mL
- 12. TE buffer (provided with the library preparation kit) and/or any commercial Elution Buffer (50mL)
- 13. 10µL (x 6), 20µL (x 7), 200µL (x 18), and 1000µL (x 1) filtered nuclease-free tip racks
- 14. 20µL (x 7), and 200µL (x 18) filtered nuclease-free tip racks compatible with the Opentrons OT-2 (amounts can be substracted from the above tips if the OT-2 will be used in all the steps where it can be used)
- 15. 96-well plates compatible with the OT-2 system and thermal cycler, with sealing film (for storing the plates and running the thermal cycling protocols) x 12
- 16. 2mL polypropylene tubes compatible with OT-2 x 16
- 17. 12-well, 15mL reagent reservoirs compatible with OT-2 x 3
- 18. Reagent reservoirs for manual dispensation of the Master Mixes and reagents needed for the purification steps with a multi-channel pipette x 16

DISCLAIMER:

DISCLAIMER - FOR INFORMATIONAL PURPOSES ONLY; USE AT YOUR OWN RISK

The protocol content here is for informational purposes only and does not constitute legal, medical, clinical, or safety advice, or otherwise; content added to <u>protocols.io</u> is not peer reviewed and may not have undergone a formal approval of any kind. Information presented in this protocol should not substitute for independent professional judgment, advice, diagnosis, or treatment. Any action you take or refrain from taking using or relying upon the information presented here is strictly at your own risk. You agree that neither the Company nor any of the authors, contributors, administrators, or anyone else associated with <u>protocols.io</u>, can be held responsible for your use of the information contained in or linked to this protocol or any of our Sites/Apps and Services.

Citation: Elias Dahdouh, Fernando Lázaro Perona, MarÃÂa RodrÃÂguez Tejedor, Rubén Cáceres Sánchez, Iván Bloise Sánchez, Jesðs Mingorance (08/18/2021). High Throughput Semi-Automated SARS-CoV-2 Library Preparation Protocol for Ion Torrent Sequencing using Opentrons, New England Biolabs Kit, and ARTIC Primers. https://dx.doi.org/10.17504/protocols.io.bxdppi5n

Preparation of cDNA using VILO from Thermo Fisher 1h 45m For each sample dispense 7µL of the extracted nucleic acids to the respective wells in the 96-well plate (Plate 1) NOTE: All the calculations from here until the end of the protocol are done for 96 samples + 4 samples to account for pipetting errors 5m Prepare the following master mix (VILO master mix): 5X VILO Reaction Mix: 200μL 10X SuperScript Enzyme Mix: 100μL NOTE: The 5X VILO Reaction Mix should be at room temperature 40 minutes before being used 30m Dispense 3µL of the VILO master mix in each well of Plate 1 3 **NOTE:** The OT-2 can perform this step using the following protocol: (i) VILO Master Mix Dispensation for 96 Samples.json Seal **Plate 1**, perform a quick spin and place it in the thermal cycler for cDNA synthesis with the following thermal program: 42°C for 30 minutes 85°C for 5 minutes hold at 4°C SAFE POINT: the cDNA samples can be stored at -20°C Amplification of the SARS-CoV-2 genome using the Primer Pools from ARTIC 4h 35m 10m Prepare two Master Mixes (one for each primer pool) containing: NEBNext Q5 Hot Start Master Mix (BLUE cap): 500μL

■ Pool A OR B (ARTIC): 250µL

NOTE: The NEBNext Q5 Hot Start Master Mix should be at room temperature 40 minutes before being used

6 Dispense 7.5µL of **each** master mix into a new 96-well plate

40m

NOTE: The OT-2 can perform this step using the following protocol:

Pool Master Mix Dispensation for 96 Samples.json (can run the same protocol twice, once for the Master Mix of Pool A and a second time for the Master Mix of Pool B, without having to re-calibrate in-between the two runs)

- 7 Add 2.5µL of cDNA from **Plate 1** to the respective wells in both plates (where one plate contains the Master Mix with Pool A and the second plate contains the Master Mix for Pool B)
- 8 Seal the 96-well plates with Pools A and B, perform a quick spin to them, and place them in the thermal cycler(s) for PCR amplification with the following program:
 - 98°C for 1 minute
 - 25 or 30* cycles of:
 - 98°C for 15 seconds

Citation: Elias Dahdouh, Fernando Lázaro Perona, MarÃÂa RodrÃÂguez Tejedor, Rubén Cáceres Sánchez, Iván Bloise Sánchez, Jesðs Mingorance (08/18/2021). High Throughput Semi-Automated SARS-CoV-2 Library Preparation Protocol for Ion Torrent Sequencing using Opentrons, New England Biolabs Kit, and ARTIC Primers. https://dx.doi.org/10.17504/protocols.io.bxdppi5n

- 65°C for 5 minutes
- hold at 4°C

*The number of cycles should be adjusted according to the original Ct values of the samples where 25 cycles are recommended for samples with Ct values between 15 and 28, and 30 cycles are recommended for samples with Ct values > 28 (although it is not recommended to include samples with Ct values > 30)

Mix $10\mu L$ of the PCR product from the plate of Pool A with $10\mu L$ of the PCR product from the plate of Pool B in a new 96-well plate (Plate 2) (use of a multi-channel pipette is highly recommended)

NOTE: From here on, the samples must be managed in a post-PCR area

	SAFE POINT: the samples can be stored at -20°C					
Post-P	Post-PCR Purification with Magnetic Beads 1h 28m					
10	NOTE: This entire section, minus Step 22, can be performed by OT-2 in 54 minutes using the following protocol:					
	Post Pool Amplification Ampure Beads Purification for 20uL (96 Samples).json					
	Follow Steps 11 to 21 only if performing this section manually (use of a multi-channel pipette is highly recommended). Otherwise, load the above protocol in OT-2 so that it can perform these steps automatically.					
11	Add 36µL (1.8X) of Magnetic Beads to the samples in Plate 2 and mix thoroughly					
11	Add oop (1.5%) of Magnetio Beads to the samples in Face 2 and mix thoroagmy					
12	Incubate 5 minutes at room temperature 5m					
13	Place the plate on a magnet and wait 2 minutes for the solution to clear					
14	Remove and discard the supernatant 10m					
15	Add 180µL freshly prepared 70% ethanol					
16	Gently pipette the ethanol up and down 4 times and then remove and discard it					
17	Leave the plate at room temperature for 2 minutes (manually remove excess ethanol without disturbing the pellet if 2m needed)					
	NOTE: Do not let the pellet over-dry resulting in a dark brown-black color since this would lead to irreversible binding of the DNA and inability to elute the DNA					
18	Remove the plate from the magnet, add 25µL of elution buffer (or TE buffer), and mix thoroughly					

protocols.io 08/18/2021 6

Citation: Elias Dahdouh, Fernando LÃÂ;zaro Perona, MarÃÂa RodrÃÂguez Tejedor, Rubén CÃÂ;ceres SÃÂ;nchez, IvÃÂ;n Bloise SÃÂ;nchez, Jesðs Mingorance (08/18/2021). High Throughput Semi-Automated SARS-CoV-2 Library Preparation Protocol for Ion Torrent Sequencing using Opentrons, New England Biolabs Kit, and ARTIC Primers. https://dx.doi.org/10.17504/protocols.io.bxdppi5n

2m Incubate at room temperature for 2 minutes 19 2m Place the plate on the magnet and wait for 2 minutes for the solution to clear 20 10m Transfer 20µL of the supernatant to a new 96-well plate (**Plate 3**) 21 10m Transfer 10µL of all the sample in Plate 3 to a new Plate (Plate 4) 22 NOTE: This step needs to be performed even if the Opentrons protocol was used. For the next step, you will only be needing 10µL of the mixed and purified amplicons (the remaining 10µL can be stored at -20°C) SAFE POINT: Both plates can be be stored at -20°C End Repair using the New England Biolabs Kit 1h 25m 5m Prepare the following End Repair Master Mix: 23 Nuclease-free water: 1550μL • NEBNext End Repair Reaction Buffer (GREEN cap): 300μL NEBNext End Repair Enzyme Mix (GREEN cap): 150μL 45m 74 Mix 20μL of the End Repair Master Mix with the 10μL of the mixed amplicons in Plate 4 • NOTE: The OT-2 can perform this step using the following protocol: M End Repair Master Mix Dispensation for 96 Samples.json (IMPORTANT: For this OT-2 protocol, the total volume of the Master Mix has to be divided into 2 tubes where each tube will have a final volume of 1000µL) 35m 25 Seal **Plate 4**, perform a quick spin and place it in the thermal cycler for end-repair with the following program: 25°C for 20 minutes 70°C for 10 minutes hold at 4°C Ion Express Adaptor and Barcode Ligation 2h 55m 1h 10m Prepare the Barcode Mixes 26 NOTE: This section considers that the barcodes 1 to 96 are being used. However, it can be adjusted to use barcodes 1 to 48 for the first 48 samples in the 96-well plate and re-use the same barcodes for the second half of the plate, as long as the samples are sequenced separately. Also, barcodes 1 to 24 can be used for four sets of 24 samples in the 96-well plates as long as the samples are to be sequenced separately. 5m Prepare the following P1 Adapter Master Mix: 26.1 Nuclease-free water: 400µL P1 adapter: 200μL

26.2 Dispense $6\mu L$ of the P1 Adapter Master Mix in a new 96-well plate **NOTE:** The OT-2 can perform this step using the following protocol: M Adapter P1 Master Mix Dispensation for 96 Samples.json Add 2µL of each barcode to a well in the 96-well plate where each well should contain a different 26.3 harcode NOTE: the plate contains Barcode Mixes for three runs. They can be stored at -20°C 5m Prepare the following Barcode Ligation Master Mix: 27 ■ Nuclease-free water: 900µL T4 DNA Ligase Buffer for Ion Torrent (RED cap): 500μL Bst 2.0 WarmStart DNA Polymerase (RED cap): 50μL 45m Add 14.5µL of the Barcode Ligation Master Mix to each well of Plate 4 28 **NOTE:** The OT-2 can perform this step using the following protocol: Barcode Ligation Master Mix Dispensation for 96 Samples.json (IMPORTANT: For this OT-2 protocol, the total volume of the Master Mix has to be divided into 2 tubes where each tube will have a final volume of 725µL) Add $2.5\mu L$ of the Barcode Mix from the Barcode-Containing 96-well plate to the respective wells of **Plate 4** (use of a second 29 multi-channel pipette is highly recommended) 20m Add 3µL of the T4 DNA Ligase (RED cap) to each well of Plate 4 30 NOTE: It is important to add the reagents in this specific order (Master Mix first, then barcodes, and lastly the DNA ligase) Seal **Plate 4**, perform a quick spin and place it in the thermal cycler to perform ligation with the following program: 25m 31 25°C for 15 minutes 65°C for 5 minutes hold at 4°C SAFE POINT: the samples can be stored at -20°C Post- Barcode Purification with Magnetic Beads 1h 18m 32 NOTE: This entire section can be performed by OT-2 in 54 minutes using the following protocol: **§** FIRST Ampure Beads Purification for 96 Samples.json Follow Steps 33 to 43 only if performing this section manually (use of a multi-channel pipette is highly recommended). Otherwise, load the above protocol in OT-2 so that it can perform these steps automatically. 15m Add 90µL (1.8X) of Magnetic Beads to the samples in Plate 4 and mix thoroughly 33 5m 34 Incubate 5 minutes at room temperature

20m

m protocols.io 08/18/2021

Citation: Elias Dahdouh, Fernando LÃÂ;zaro Perona, MarÃÂa RodrÃÂquez Tejedor, Rubén CÃÂ;ceres SÃÂ;nchez, IvÃÂ;n Bloise SÃÂ;nchez, Jesðs Mingorance

35	Place the plate on a magnet and wait 2 minutes for the solution to clear	2m
36	Remove and discard the supernatant	10m
37	Add 180μL freshly prepared 70% ethanol	5m
38	Gently pipette the ethanol up and down 4 times and then remove and discard it	10m
39	Leave the plate at room temperature for 2 minutes (manually remove excess ethanol without disturbing the pelle needed)	if ^{2m}
	NOTE: Do not let the pellet over-dry resulting in a dark brown-black color since this would lead to irreversible bind the DNA and inability to elute the DNA	ng of
40	Remove the plate from the magnet, add 25µL of elution buffer (or TE buffer), and mix thoroughly	15m
41	Incubate at room temperature for 2 minutes	2m
42	Place the plate on the magnet and wait for 2 minutes for the solution to clear	2m
43	Transfer 20µL of the supernatant to a new 96-well plate (Plate 5)	10m
	SAFE POINT: the samples can be stored at -20°C	
ibrary	y Amplification 1h 5m	F
44	Prepare the following Master Mix:	5m
	■ NEBNext Q5 Hot Start Master Mix (BLUE cap): 2000µL ■ NEBNext DNA Library Primers (BLUE cap): 180µL	
	NOTE: The NEBNext Q5 Hot Start Master Mix should be at room temperature 40 minutes before being used	
45	Add 20µL of this Master Mix to each sample in Plate 5	45m
	NOTE: The OT-2 can perform this step using the following protocol:	
	U Library Amplification Master Mix Dispensation for 96 Samples.json (IMPORTANT: For this OT-	_

Citation: Elias Dahdouh, Fernando Lázaro Perona, MarÃÂa RodrÃÂguez Tejedor, RubÃÁ®n Cáceres Sánchez, IvÃÁ¡n Bloise Sánchez, Jesðs Mingorance (08/18/2021). High Throughput Semi-Automated SARS-CoV-2 Library Preparation Protocol for Ion Torrent Sequencing using Opentrons, New England Biolabs Kit, and ARTIC Primers. https://dx.doi.org/10.17504/protocols.io.bxdppi5n

Seal Plate 5, perform a quick spin and place it in the thermal cycler for PCR amplification with the following pro 98°C for 30 seconds 7 cycles of: 98°C for 10 seconds 58°C for 30 seconds 72°C for 30 seconds 72°C for 5 minutes hold at 4°C	15m gram:
NOTE: This entire section can be performed by OT-2 in 54 minutes using the following protocol: SECOND Ampure Beads Purification for 96 Samples.json (if this and the previous purifications with magnetic beads are performed on the same day, then the same reservoir well can be re-used for the second purification). Follow Steps 48 to 58 only if performing this section manually (use of a multi-channel pipette is highly recommendation).	
Add 36µL (0.9X) of Magnetic Beads to the samples in Plate 5 and mix thoroughly	15m
Incubate 5 minutes at room temperature	5m
Place the plate on a magnet and wait 2 minutes for the solution to clear	2m
Remove and discard the supernatant	10m
Add 180µL freshly prepared 70% ethanol	5m
Gently pipette the ethanol up and down 4 times and then remove and discard it	10m
	■ 98°C for 30 seconds ■ 7 cycles of:

 $Leave the plate at room temperature for 2 minutes (manually remove excess ethanol without disturbing the pellet if {2m} and {2m} are the plate at room temperature for 2 minutes (manually remove excess ethanol without disturbing the pellet if {2m} are the plate at room temperature for 2 minutes (manually remove excess ethanol without disturbing the pellet if {2m} are the plate at room temperature for 2 minutes (manually remove excess ethanol without disturbing the pellet if {2m} are the plate at room temperature for 2 minutes (manually remove excess ethanol without disturbing the pellet if {2m} are the plate at room temperature for 2 minutes (manually remove excess ethanol without disturbing the pellet if {2m} are the plate at room temperature for 2 minutes (manually remove excess ethanol without disturbing the pellet if {2m} are the pel$

NOTE: Do not let the pellet over-dry resulting in a dark brown-black color since this would lead to irreversible binding of

54

ARTIC Primers. https://dx.doi.org/10.17504/protocols.io.bxdppi5n

Citation: Elias Dahdouh, Fernando Lázaro Perona, MarÃÂa RodrÃÂguez Tejedor, Rubén Cáceres Sánchez, Iván Bloise Sánchez, Jesðs Mingorance (08/18/2021). High Throughput Semi-Automated SARS-CoV-2 Library Preparation Protocol for Ion Torrent Sequencing using Opentrons, New England Biolabs Kit, and

	the DNA and inability of eluting the DNA	
55	Remove the plate from the magnet, add $30\mu L$ of elution buffer (or TE buffer), and mix thoroughly	5m
56	Incubate at room temperature for 2 minutes	2m
57	Place the plate on the magnet and wait for 2 minutes for the solution to clear	2m
58	Transfer 25µL of the supernatant to a new 96-well plate (Plate 6) SAFE POINT: the libraries can be stored at -20°C	0m
. :	Outstifferships Newsylineships and Outstanding Outstanding	
	Quantification, Normalization and Sequencing 2d 5h 20m Overtify the complex in the Plate 6 using either the Bread Banga (RR) or the High Separitivity (US) kit and Oubit	2h
59	Quantify the samples in the Plate 6 using either the Broad Range (BR) or the High Sensitivity (HS) kit and Qubit Fluorometer (Thermo Fisher), or any other compatible kit and machine at your disposal	
	NOTE: Make sure that the output is in ng/mL and that it is adjusted to the original concentration in the sample	
60	Normalize the samples' concentrations to 24ng/mL (equivalent to 100pM) by mixing the calculated sample amount with elution buffer (TE) to a final volume of 100µL in a new 96-well plate (Plate 7)	0m t
	NOTE: The final volume of the normalized sample can be adjusted if the sample volume to be added is too large or small, as long as the final volume of the normalized sample is more than $10\mu L$	too
61	Create the pools for sequencing mixing $10\mu L$ from each normalized sample in a polypropylene tube. Four pools of samples each may be prepared from the 96 samples.	0m 24
	NOTES: 1. According to our experience 20 to 30 samples may be included in a 530 Chip with good coverage and depth. If a larger or a smaller chip is to be used then the number of samples to be included in a single pool should be adjust accordingly 2. Always be sure not to mix samples with the same barcode in the same pool	
62	Use 25µL from each pool in order to load the Ion Chef with 530 Chips. Two pools can be simultaneously loaded in to different chips using the same Ion Chef reagents.	:0m VO
	 NOTES: For Steps 62 to 64, follow the manufacturer's instructions in order to load the Ion Chef and sequence with the Ion system The Ion Chef Reagents need to be at room temperature 45 minutes before being used Change the templating protocol to 400bp while planning the run since the average amplicon length using the AR primer pools is 320bp 	
63	Initialize the Ion S5 system using the S5 solutions	0m
	NOTES: 1. The Ion S5 Reagents need to be at room temperature 45 minutes before being used 2. One initialization can be used to sequence two 530 Chips if the number of flows is selected to be 550 (without the	ne

need to wash in-between the two chips)

Sequence the chips one after the other using the lon S5 system

2d

NOTES:

64

- 1. On day 1, load the Ion Chef with two pools and initialize the S5 in the afternoon
- 2. On day 2, load the first chip in the morning and then directly load the second chip after it (keep the second chip in the membrane protector at 4°C and remove it to room temperature 45 minutes before sequencing)
- 3. On day 2, load the Ion Chef with the other two pools and re-initialize the S5 in the afternoon after it has finished sequencing the first 2 chips
- 4. On day 3, load the first chip in the morning and then directly load the second chip after it (keep the second chip in the membrane protector at 4°C and remove it to room temperature 45 minutes before sequencing)
- 5. Keep the Ion S5 system on after it finishes sequencing and until it processes all the data.