

Jul 25, 2024



HEP-TILE: HBV whole genome sequencing (nanopore protocol)



Forked from ARTIC SARS-CoV-2 sequencing protocol v4 (LSK114)

DOI

dx.doi.org/10.17504/protocols.io.5jyl82bedl2w/v1

Sheila Lumley¹, Chris Kent², Josh Quick², Philippa Matthews³

¹University of Oxford; ²University of Birmingham; ³The Francis Crick Institute

ARTIC



Sheila Lumley

University of Oxford

OPEN ACCESS



DOI: dx.doi.org/10.17504/protocols.io.5jyl82bedl2w/v1

Protocol Citation: Sheila Lumley, Chris Kent, Josh Quick, Philippa Matthews 2024. HEP-TILE: HBV whole genome sequencing (nanopore protocol). **protocols.io** https://dx.doi.org/10.17504/protocols.io.5jyl82bedl2w/v1

Manuscript citation:

Whole genome sequencing of hepatitis B virus (HBV) using tiled amplicon (HEP-TILE) and probe-based enrichment on Illumina and Nanopore platforms. Lumley et al. 2024

License: This is an open access protocol distributed under the terms of the <u>Creative Commons Attribution License</u>, which permits unrestricted use, distribution, and reproduction in any medium, provided the original author and source are credited

Protocol status: Working
We use this protocol and it's

working

Created: April 09, 2024

Last Modified: July 25, 2024

Protocol Integer ID: 102752

Keywords: hepatitis b virus, whole genome sequencing, HBV, tiled amplicon, nanopore sequencing



Funders Acknowledgement:

Wellcome trust

Grant ID: 102176/B/13/Z

Abstract

This protocol describes the HEP-TILE tiled amplicon protocol for whole genome sequencing of Hepatitis B virus (HBV) on the nanopore MinION.

We developed a pan-genotypic (genotypes A-J) HBV scheme using an early version of PrimalScheme3, a web-based primer design tool for developing multiplex primer schemes. PrimalScheme3 is a successor to PrimalScheme, with a number of changes made to enable us to generate an overlapping (tiled) amplicon scheme which covered the circular HBV genome, utilising a number of discrete primers at each position to handle intraspecies diversity.

Primer sequences are here: https://github.com/quick-lab/primerschemes/blob/main/primerschemes/hbv/600/v2.1.0/primer.bed

The amplicons can also be fragmented and sequenced on Illumina platforms.



Materials

A	В	С
Component	Supplier	Part number
HEP-TILE primers hbv/600/v2.1.0	IDT	See links below
Q5 Hot Start High-Fidelity 2X Master Mix	NEB	M0494
Nuclease-free water (100 mL)	NEB	B1500
SPRI-select beads	Beckman	B23318
Ethanol		
NEBNext Ultra II End Repair/dA-tailing module	NEB	E7546
Blunt/TA Ligase Master Mix	NEB	M0367
NEBNext Quick Ligation Module	NEB	E6056S
Native Barcoding Kit 24 V14 or	ONT	SQK-NBD114.24
Native Barcoding Kit 96 V14	ONT	SQK-NBD114.96
Native Barcoding Auxiliary Kit V14 (optional)	ONT	EXP-NBA114
Short Fragment Buffer Expansion Kit (optional)	ONT	EXP-SFB001
Flow Cell Priming Kit (optional)	ONT	EXP-FLP004
Flow Cell Wash Kit (optional)	ONT	EXP-WSH004
R10.4.1 flow cells	ONT	FLO-MIN114
Bovine serum albumin (50mg/ml)	Invitrogen	
AMPure XP beads	Beckman	A63881
Qubit dsDNA HS Assay Kit	Thermo	Q32854

Order oligos listed here individually:

https://github.com/quick-lab/primerschemes/tree/main/primerschemes/hbv/600/v2.1.0

Before start

Prepare between 11 and 95 DNA samples plus 1 negative control using this protocol.



Sample preparation

Prepare between 11 and 95 DNA samples plus 1 negative control of nuclease-free water per library. If previously frozen, mix by briefly vortexing and pulse spin to collect liquid. Keep samples on ice at all times.

Note

A positive control can also be included which may be a the NIBSC HBV control or high-titre clinical sample which can be diluted. This can help monitor run performance.

Primer pool preparation

- 2 If making up primer pools from individual oligos fully resuspend lyophilised oligos in 1xTE to a concentration of [M] 100 micromolar (µM), vortex thoroughly and spin down.
- 3 Sort all odd regions primers into one or more tube racks. Add \perp 5 µL of each odd region primer to a 🚨 1.5 mL Eppendorf tube labelled "Pool 1 ([M] 100 micromolar (µM))". Repeat the process for all even region primers for Pool 2. These are your [M] 100 micromolar (µM) stocks of each primer pool.

Note

Primers should be diluted and pooled in the mastermix cabinet which should be cleaned with decontamination wipes and UV sterilised before and after use.

Note

For more information see Figure 2 in;

Quick, J. et al. Multiplex PCR method for MinION and Illumina seguencing of Zika and other virus genomes directly from clinical samples. Nat Protoc 12, 1261–1276 (2017). https://doi.org/10.1038/nprot.2017.066



4 Dilute [M] 100 micromolar (µM) pools 1:10 in molecular grade water, to generate [M] 10 micromolar (µM) primer stocks.

Note

Primers are used at a final concentration of [M] 15 nanomolar (nM) per primer. In this case hbv/600/v2.1.0 pools have 69 primers in pool 1 and 63 primers in pool 2. so the requirement is ~ Δ 2.5 μL primer pool ([M] 10 micromolar (μM)) per Δ 25 μL reaction.

Note

Make up multiple 4 100 μL aliquots of [M] 10 micromolar (μM) primer dilutions and freeze them in case of degradation or contamination.

Multiplex PCR

5 Set up the two PCR reactions per sample as follows in strip-tubes or plates. Gently mix by pipetting and pulse spin the tube to collect liquid at the bottom of the tube.

A	В	С
Component	Reaction 1	Reaction 2
Q5 Hot Start High-Fidelity 2X Master Mix	12.5 µL	12.5 µL
V3 Pool 1 (10μM)	2.5 µL	0 μL
V3 Pool 2 (10μM)	0 μL	2.5 µL
Nuclease-free water	7.5 µL	7.5 µL
Total	22.5 µL	22.5 μL



To prevent pre-PCR contamination the mastermix for each pool should be made up in the mastermix cabinet which should should be cleaned with decontamination wipes and UV sterilised before and after use and aliquoted into PCR strip-tubes/plate

6 Add A 2.5 µL cDNA to each of the PCR reactions, gently mix by pipetting and pulse spin the tube to collect liquid at the bottom of the tube.

Note

Up to 🚨 10 µL DNA can be added to each PCR reaction (in place of nuclease-free water) to improve amplification of low titre samples. As a guide for VL:

- > 5 log10 IU/ml use 2.5ul
- 3-4 log10 IU/ml use 5ul
- < 3 log10 IU/ml use 10ul

PCR reactions can be performed in duplicate for very low viral load samples.

Note

DNA should be added in the **DNA/sample addition** cabinet which should should be cleaned with decontamination wipes and UV sterilised before and after use.

7 Set-up the following program on the thermal cycler:

Step	Temperature	Time	Cycles
Heat Activation	\$ 98 °C	© 00:00:30	1
Denaturation	₽ 98 °C	© 00:00:15	35
Annealing	å 65 °C	③ 00:05:00	35
Hold	4 °C	Indefinite	1



Bead clean up

8 Label strip-tubes/plate and combine the following volumes of each PCR reaction for Δ 25 μL each sample:

A	В
Component	Volume
Pool 1 PCR reaction	25 μL
Pool 2 PCR reaction	25 μL
Total	50 μL

Note

Amplicons should be added in the **post-PCR** cabinet which should be cleaned with decontamination wipes and UV sterilised before and after use.

- 9 Add Δ 40 μL SPRI beads to Δ 50 μL pooled PCR product for an 0.8x clean up.

 Gently mix and incubate for 00:05:00 at room temperature
- 9.1 Place on a magnetic rack and incubate for 00:02:00 or until the beads have pelletted and supernatant is completely clear. Remove and discard the supernatant.
- 9.2 Perform an ethanol wash: add <u>A 100 µL</u> of room temperature 70% ethanol to bathe the pellet, carefully remove and discard ethanol being careful not to touch the bead pellet.
- 9.3 Repeat the ethanol wash (step 9.2)
- 9.4 Pulse centrifuge to collect and remove residual ethanol, remove excess with a P10 pipette, it is very important all is removed.
- 9.5 With the tube lid open, air dry for 1-2 minutes, or until the pellet loses its shine. Do not over-dry.



- 9.6 Re-suspend pellet in 🚨 20 µL H20, mix gently and incubate for 2 minutes at room temperature
- 9.7 Place on magetic rack, transfer the supernatant to clean labelled tubes
- 9.8 Quantify using a Qubit or Quantus.

End preparation

10 In a new PCR strip-tube/plate set up the following reaction for each sample, normalising to 80ng amplicon DNA input per sample:

10.1

A	В
Component	Volume
Clean PCR product from previous step	Up to 8.3 ul
Ultra II end prep reaction buffer	1.2ul
Ultra II end prep enzyme mix	0.5ul
Nuclease-free water	to a total of 1 Oul
Total	10ul

Note

Make a master mix of end-preparation reagents and nuclease-free water and aliquot into strip-tube/plate to improve reproducability.

10.2 Incubate at room temperature for (5) 00:15:00 Incubate at **\$** 65 °C for **(*)** 00:15:00 Incubate on ice for 00:01:00



Native barcoding

11 In a new PCR strip-tube/plate set up the following reaction for each sample:

11.1

A	В
Component	Volume
End-preparation reaction mixture	1 ul
NBXX barcode	1.25 ul
Blunt/TA Ligase master mix	5 ul
Nuclease-free water	2.75 ul
Total	10 ul

Note

Use one native barcode per sample. Use 12 or more barcodes per library or there will be insufficient total material to achieve good yields.

11.2 Incubate at room temperature for 00:20:00

20m

11.3 Add EDTA and mix thoroughly

A	В
EDTA cap colour	Volume per well
For clear cap EDTA	1ul
For blue cap EDTA	2ul

Note

NB. EDTA concentration varies by cap colour supplied by ONT



Alternatively a 65C heat step can be used to inactivate the ligase - see ONT version of protocol.

11.4 In a new 1.5ml Eppendorf tube pull all one-pot barcoding reactions together.

Note If processing 12-24 samples pool all \perp 10 μ L from each native barcoding reaction. if processing 48 samples pool $~\underline{\mbox{\sc L}}~5~\mu\mbox{\sc L}~$ from each native barcoding reaction. If processing 96 samples pool $\Delta 2.5 \mu$ from each native barcoding reaction so as not to exceed a pool volume of 🚨 240 µL which would make the clean-up volume too large.

- 11.5 Determine volume of pooled barcoded samples, add an equal volume of water
- 11.6 Add ampure beads (supplied with ONT kit) for a 1.5x clean up. If very large volume split between 2 tubes

Example:

A	В
Component	Example volumes
Pooled barcoded samples	240 ul
Water	240 ul
Beads	720 ul

Note

NB. 0.4x clean up in ONT protocol was leading to loss of whole library.

11.7	Mix by vortexing and pulse centrifuge to collect all liquid at the bottom of the tube. Incubate for 00:05:00 at room temperature.	5m
11.8	Place on magnetic rack and incubate for 00:02:00 or until the beads have pelleted and the supernatant is completely clear. Carefully remove and discard the supernatant, being careful not to touch the bead pellet.	2m
11.9	Add $\ \ \ \ \ \ \ \ \ \ \ \ \ $	
11.10	Repeat step 11.9 to perform a second SFB wash. Pulse centrifuge and remove any residual SFB.	
	Note	
	You do not need to allow to air dry with SFB washes.	
11.11	Add $\ \ \ \ \ \ \ \ \ \ \ \ \ $	
	Note	
	Only perform 1x 70% ethanol wash	
11.12	Pulse centrifuge to collect all liquid at the bottom of the tube and carefully remove as much residual ethanol as possible using a P10 pipette.	
11.13	With the tube lid open incubate for 00:01:00 or until the pellet loses it's shine (if the pellet dries completely it will crack and become difficult to resuspend).	1m
11.14	\bigcirc 00:02:00 Re-suspend pellet in $\boxed{\bot}$ 31 µL nuclease free water, mix gently by either	4m
	flicking or pipetting and incubate for 00:02:00	



- 11.15 Place on magnet and transfer sample to a clean 1.5 mL Eppendorf tube ensuring no beads are transferred into this tube.
 - 12 Quantify $\perp 1 \mu$ of the barcoded amplicons using a fluorometer such as a Qubit or Quantus. Concentration will vary depending on number and Ct of samples and but you need about △ 30 ng total at this stage to achieve maximum run yield.

Adaptor ligation

- 13 Set up the following Native Adapter (NA) ligation and clean-up with SFB.
- 14 In a new 1.5ml eppendorf or PCR tube set up the following adapter ligation reaction

A	В
Component	Volume
Barcoded amplicon pool	30 ul
NEBNext quick ligation reaction buffer (5X)	10 ul
Adaptor mix (NA)	5 ul
Quick T4 DNA ligase	5 ul
Total	50 ul

14.1 Incubate at room temperature for (5) 00:20:00

- 15 Perform a bead clean up.
- 15.1 Add 50ul ampure beads (supplied with ONT kit) to the sample tube. Mix by vortexing and pulse centrifuge to collect all liquid at the bottom of the tube. Incubate for 00:05:00 at room temperature.



- 15.2 Place on magnetic rack and incubate for 00:02:00 or until the beads have pelleted and the supernatant is completely clear. Carefully remove and discard the supernatant, being careful not to touch the bead pellet.
- 15.3 Add 250 µL SFB and resuspend beads completely by pipette mixing. Pulse centrifuge to collect all liquid at the bottom of the tube and place on the magnet. Remove supernatant and discard.
- 15.4 Repeat step 15.3 to perform a second SFB wash. Pulse centrifuge and remove any residual SFB.

You do not need to allow to air dry with SFB washes.

- 15.5 Re-suspend pellet in \perp 15 μ L EB (ONT), mix gently by either flicking or pipetting and incubate for \bigcirc 00:02:00
- 15.6 Place on magnet and transfer sample to a clean 1.5 mL Eppendorf tube ensuring no beads are transferred into this tube.
- 16 Quantify the final library using a fluorometer such as a Qubit or Quatus.

Note

Note

Final library can be now be stored at 4 °C for up to a week if needed otherwise proceed directly to MinION sequencing.



Flow cell check and priming

- 17 Refer to ONT documentation for images explaining how to check, prime and load flow cell.
- 18 Complete a flow cell check open Minknow user interface, plug in MinION to laptop, open the MinION lid and slide the flow cell under the clip. Press down firmly on the flow cell to ensure correct thermal and electrical contact. Click flow cell check on Minknow interface.
- To prepare the flow cell priming mix, combine the following reagents in the FCF tube and mix by inverting the tube and pipette mix at room temperature:

A	В
Component	Volume
Flow cell flush (FCF)	1170 ul
Bovine serum albumin (BSA) at 50mg/ml	5 ul
Flow cell tether (FCT)	30 ul
Final volume in FCF tube	1205 ul

- 19.1 Slide the flow cell priming port cover clockwise to open the priming port
- 19.2 After opening the priming port, set a P1000 pipette to 200ul, insert the tip into the priming port, turn the wheel until the dial shows 220-230ul, to draw back 20-30ul or until you can see a small volume of buffer entering the pipette tip.
- 19.3 Visually check that there is continuous buffer from the priming port across the sensor array.
- 19.4 Load Δ 800 μL of the priming mix into the flow cell via the priming port, avoiding the introduction of air bubbles. Wait for five minutes. During this time prepare the library for loading by following the steps below.

MinION sequencing

Thoroughly mix the contents of the library beads by pipetting, it is vial that they are mixed immediately before use.



From experience we have successfully loaded 20ng library

In a new 1.5ml Eppendorf DNA LoBind tube, prepare the library for loading as follows (NB load the library onto flow cell immediately after adding SB and LIB because the fuel in the buffer will start to be consumed by the adapter):

А	В
Reagent	Volume
Sequencing buffer (SB)	37.5 ul
Library beads (LIB) mixed immediately before use	25.5 ul
DNA library + H2O	12 ul
Total	75 ul

- 22 Complete flow cell priming: lift the spot on sample port cover, load Δ 200 μL of the priming mix into the flow cell priming port (not the SpotON sample port), avoiding the introduction of air bubbles
- 23 Mix the prepared library gently by pipetting just prior to loading
- Add half of the library (~37.5ul) to the flow cell via the SpotON sample port in a dropwise fashion. Ensure each drop flows into the port before adding the next. Resuspend beads/library and add the 2nd half in a dropwise fashion.
- Gently replace the SpotON sample port cover, making sure the bung enters the SpotON port and close the priming port.
- Place the light shield onto the flow cell. And close the device lid.
- 27 Start the sequencing run using MinKnow.



If using live basecalling, turn on double-ended barcoding in the basecalling settings.

Protocol references

Pre-print coming soon: Whole genome sequencing of hepatitis B virus (HBV) using tiled amplicon (HEP-TILE) and probebased enrichment on Illumina and Nanopore platforms. Lumley et al. 2024