

Oct 16, 2024

Quantitation of aliphatic acids from lignin-derived streams by HPLC-RID

DOI

dx.doi.org/10.17504/protocols.io.rm7vzxrn2gx1/v1

Stefan J. Haugen¹, Alexander F. Benson¹, Sean P. Woodworth¹, David Brandner¹, Kelsey J. Ramirez¹, Gregg T. Beckham¹

¹Renewable Resources and Enabling Sciences Center, National Renewable Energy Laboratory, Golden, CO, USA

NREL

Tech. support email: ftlb_analysis@nrel.gov



Alexander F. Benson

Renewable Resources and Enabling Sciences Center, National R...

OPEN ACCESS



DOI: dx.doi.org/10.17504/protocols.io.rm7vzxrn2gx1/v1

Protocol Citation: Stefan J. Haugen, Alexander F. Benson, Sean P. Woodworth, David Brandner, Kelsey J. Ramirez, Gregg T. Beckham 2024. Quantitation of aliphatic acids from lignin-derived streams by HPLC-RID. **protocols.io**

https://dx.doi.org/10.17504/protocols.io.rm7vzxrn2gx1/v1

License: This is an open access protocol distributed under the terms of the **Creative Commons Attribution License**, which permits unrestricted use, distribution, and reproduction in any medium, provided the original author and source are credited

Protocol status: Working
We use this protocol and it's

working

Created: January 10, 2024

Last Modified: October 16, 2024

Protocol Integer ID: 93350

Keywords: lignin-derived streams, aliphatic acids, HPLC-RID, oxalic, malic, malonic, succinic, glycolic, lactic, formic, acetic, propionic



Funders Acknowledgement:
This work was authored by
the National Renewable
Energy Laboratory, operated
by Alliance for Sustainable
Energy, LLC, for the U.S.
Department of Energy (DOE)
under Contract No. DE-AC3608GO28308. This work was
supported by Office of Energy
Efficiency and Renewable
Energy (EERE) and Bioenergy
Technologies Office (BETO).
Grant ID: DE-AC3608GO28308

Disclaimer

This protocol is for research purposes only.

Abstract

An analytical method was developed using high performance liquid chromatography with refractive index detection (HPLC-RID) to quantify the concentrations of aliphatic acids. The analytes quantified were oxalic acid, malic acid, malonic acid, succinic acid, glycolic acid, lactic acid, formic acid, acetic acid, and propionic acid in samples from lignin-derived streams. This method utilized an ion exclusion column to provide chromatographic separation across a 30 minute runtime.

Guidelines

This protocol utilizes an high pressure liquid chromatography equipped with a refractive index detector (HPLC-RID) system manufactured by Agilent Technologies as referenced in 'Materials'. A similar chromatography and detection system can be utilized; however, some parameter nomenclature may deviate depending on the manufacturer.




Materials

Reagents:

- Sulfuric Acid 10N Solution Fisher Scientific Catalog #SA200-1
- Sulfuric Acid, 72% (w/w) Ricca Chemical Company Catalog #R8191600-1A

Standards:





Aliphatics Mix 9 components COA.pdf

The Aliphatics Mix 9 components standard contains the following compounds.

- 1. Oxalic acid
- 2. Malic acid
- 3. Malonic acid
- 4. Succinic acid
- 5. Glycolic acid
- 6. Lactic acid
- 7. Formic acid
- 8. Acetic acid
- 9. Propionic acid

Consumables:

Syringe filters for aqueous matrices



Equipment

syringe filters, 13mm nylon membrane

NAME

syringe filter

TYPE

Cytiva

BRAND

4550

SKU

 $https://www.cytivalifesciences.com/en/us/shop/lab-filtration/syringe-filters-non-sterile/nylon-non-sterile-syringe- \\ \frac{Ll}{NK} filters/acrodisc-syringe-filters-with-nylon-membrane-p-36371$

13mm SPECIFICATIONS

Equipment:

Equipment

Agilent 1260 Infinity II LC System

 NAME

HPLC System

TYPE

Agilent

BRAND

Agilent 1260 Infinity II LC System

SKU

https://www.agilent.com/en/product/liquid-chromatography/hplc-systems/analytical-hplc-systems/1260-infinity-ii-lc-system

LIN K

G7111B Quat Pump, G7167A 1260 Multisampler, G7116A 1260 MCT, G7117C DAD HS, G7162A 1260 SPECIFICATION RID

Column:

Analytical Column



Equipment

Rezex ROA-Organic Acids H+ (8%)

LC Column TYPE

NAME

Phenomenex BRAND

00H-0138-K0

https://www.phenomenex.com

300 x 7.8 mm

Guard Column

Equipment

Rezex ROA-Organic Acid H+ (8%)

LC Guard Column

phenomenex BRAND

03B-0138-K0

https://www.phenomenex.com/

50 x 7.8 mm SPECIFICATIONS



Safety warnings



4 All chemicals used for this procedure are hazardous. Read the Safety Data Sheet (SDS) for all chemicals and follow all applicable chemical handling and waste disposal procedures. Manufacturer specific SDS information can be found by following the CAS numbers of compounds in 'Materials' list.

Sulfuric acid can cause serious chemical burns. See SDS for additional information: https://beta-static.fishersci.com/content/dam/fishersci/en_US/documents/programs/education/regulatorydocuments/sds/chemicals/chemicals-s/S25899.pdf

Before start

All solvents and chemicals used are listed in the 'Materials' section. These are excluded from in-line references to maintain clarity and keep the steps concise.



Preparation of mobile phase and instrument equilibration

1 Mobile phase preparation

■ To make 0.02 N sulfuric acid (0.01 M), dilute 2.0 mL of 10 N sulfuric acid into 1.0 L of 18.2MΩ·cm ultrapure water (UPW).

Note

It is advised to prepare sufficient mobile phase for the entire analysis to reduce the need to add additional mobile phase during an active sequence. Adding mobile phase during an active sequence may cause retention time shifting if the new mobile phase is not identical to the original mobile phase. This method uses roughly 15.0 mL of mobile phase per injection. Calculate how much mobile phase is needed before beginning analysis.

2 Instrument equilibration

- 1. Purge the high performance liquid chromatography (HPLC) instrument with 0.02 N sulfuric acid mobile phase made in step 1. Ensure the instrument is purged through the entire flow path including the detector, before the analytical column is installed.
- 2. Install the Rezex ROA-Organic Acid LC guard column and the Rezex ROA-Organic Acid analytical column to the system. Begin equilibrating the column at a low flow rate of 0.1 mL/min while the column approaches compartment temperature.
- 3. Purge the reference cell of the refractive index detector (RID), leave reference cell purge valve open through the duration of the column equilibration.
- 4. At intervals of at least 10 minutes, increase the flow by 0.2 mL/min until you reach the method flow of 0.5 mL/min.
- 5. Once the system is at method flow rate and the column compartment and the RID reach analysis temperature, close the reference cell purge valve. This typically takes around 30 minutes after method flow rate is reached. A longer purge of the reference cell is not detrimental to the system.
- 6. After the reference cell is closed, wait for the RID signal to stabilize before starting analysis.

Preparation of standards

3 Standards

- Remove aliphatics mix ampule (listed in 'Materials' section) from freezer and allow it to come to room temperature, vortex, and transfer contents of ampule into a 2 mL amber HPLC vial.
- 2. Using this 5 g/L stock mix, follow the table below to create a calibration curve.



Note

Standards should be kept in a freezer capable of maintaining a temperature of -20°C.

3.1 Calibration curve

Calibration curve preparation

Calibration level	Concentration (µg/mL) (ppm)	Volume of aliphatics mix 9 component (µL)	Volume of UPW as diluent (µL)	Total volume (μL)
1	25	100 µL of level 4	900	1000
2	50	100 µL of level 5	900	1000
3	125	25	975	1000
4	250	50	950	1000
5	500	100	900	1000
6	1000	200	800	1000
7	1250	250	750	1000
8	2500	500	500	1000
9	5000	1000	0	1000

Example calibration curve preparation (click to enlarge)

Acidification procedure

4

Note

For alkaline samples or samples containing high molecular weight lignin the following sample acidification should be performed prior to analysis to avoid column fouling. If samples don't meet these criteria, proceed to step 5 below.

An addition of concentrated acid in excess is needed to lower sample pH and remove components that are harmful to the HPLC quard column and analytical column. This allows for better chromatographic results and subsequently better quantitation of aliphatic acids. Acidification is performed by adding 72% sulfuric acid to samples at a proportion of ~3.5% of the total sample volume.

Define volume of sample to be acidified, noting that filtration will retain approximately 30 µL of liquid. Use the equation below to calculate the volume of acid to be added to each sample



respectively. Example: 1.5 mL of sample requires 52.2 µL of 72% sulfuric acid.

(sample volume[μ L]) * (0.035) = (amount of 72% sulfuric acid to be added [μ L])

- 4.1 Add acid at calculated volume to sample in labelled acidification microfuge tube and record sample volume used and vortex thoroughly.
- 4.2 Affix filtration system (0.2 µm nylon) to luer lock syringe. Add sample to syringe, carefully and **slowly** plunge acidified sample through filter to avoid bursting filter membrane into labelled HPLC vial. Samples are now ready for instrument analysis.
- Skip step 5 if acidification procedure was performed. Samples must be filtered through a 0.2 μm or smaller filter prior to injection on the HPLC ('Materials' section includes part numbers for filters).
- 5.1 Samples that are expected to be over the linear range should be diluted to ensure accurate analysis and avoid carryover.

HPLC-RID analysis

Prepare an Agilent 1260 Infinity II LC System according to the following parameters for a total run time of 30 minutes.

Binary pump configuration

Flow rate	0.5 mL/min
Maximum pressure	100 bar
Mobile phase A	0.02N sulfuric acid in H_2 0 (v/v)

Gradient configuration

Time (min)	Composition A (%)	Composition B (%)
0.00	100.00	0.00
30.00	100.00	0.00

Column compartment parameters

Temperature 70 °C

Defined HPLC parameters (click to enlarge)



Reference index configuration

Optical unit temperature

55° C

Signal

>0.2 min (4 s response time) (2.31Hz)

Advanced settings

Analog output 5(%) Attenuation 500000 nRIU Signal Polarity Positive

Automatic zero before analysis On Off Automatic recycling after analysis

Defined HPLC-RID parameters (click to enlarge)

Data analysis and quality control

7 **Data analysis**

 Data analysis completed using Agilent OpenLab CDS, ChemStation Edition version A.01.11.138

7.1 **Calibration curves**


 All compounds must have a correlation coefficient (r²) of 0.995 or greater using a linear calibration fit and ignore the origin.

7.2 Calibration verification standard (CVS)

• A CVS is a standard from the calibration curve that is re-analyzed every 20 or fewer samples to ensure instrument drift remains within the determined acceptance criteria. Acceptable CVS recoveries for this analysis are within 10% of the expected amount. Acceptance criteria may differ between instruments and should be determined experimentally.

Example chromatogram

8



Example chromatogram including elution order of 'Aliphatics Mix 9 components' located in 'Materials'. (click to enlarge)