

Apr 20, 2024 Version 2



Flow Cytometry ECS Surface Antigens V.2

DOI

dx.doi.org/10.17504/protocols.io.dm6gpwq11lzp/v2



Michael Betts¹, Gregory Golden¹

¹University of Pennsylvania

Human Islet Research Ne...



Sandy Beshir

City of Hope





DOI: dx.doi.org/10.17504/protocols.io.dm6gpwq11lzp/v2

Protocol Citation: Michael Betts, Gregory Golden 2024. Flow Cytometry ECS Surface Antigens. protocols.io

https://dx.doi.org/10.17504/protocols.io.dm6gpwq11lzp/v2 Version created by Sandy Beshir

License: This is an open access protocol distributed under the terms of the Creative Commons Attribution License, which permits

unrestricted use, distribution, and reproduction in any medium, provided the original author and source are credited

Protocol status: Working We use this protocol and it's

working

Created: April 20, 2024

Last Modified: April 20, 2024

Protocol Integer ID: 98531

Keywords: extracellular epitope staining (ECS), intra-cellular epitope staining (ICS), HIRN

Funders Acknowledgement:

Grant ID: U01 DK112217



Abstract

High-parameter flow cytometry enables identification and characterization of a wide range of cell populations within a biological sample. Analysis of cell-surface epitopes using a collection of fluorophore-labeled antibodies, or extracellular stain (ECS), sufficiently labels population-identifying markers for further analysis with flow cytometry. Importantly, ECS can be applied to cryo-preserved cell suspensions recovered in tissue culture media, enabling samples to be conveniently analyzed after collection and proper cryopreservation. However, consistent cryopreserved sample recovery and ECS procedures are critical to data comparison across multiple experiments. Herein, we describe a standardized protocol for cryopreserved sample recovery and ECS procedures for cell-surface epitope labeling.



Materials

Materials Required

- 1. 🛭 1x phosphate saline buffer (PBS) Corning 21-031-CM Corning Catalog #21-031-CM
- 2. Sovine serum albumin (BSA) Gemini 700-101P Gemini Bioproducts Catalog #700-101P
- 3. Sodium Azide Fisher Scientific Catalog #S2271-500
- 4. FACS buffer (1xPBS, 10g/L BSA, 1 g/L sodium azide)
- 5. RPMI Corning Catalog #10-040-CM
- **6.** September Fetal calf serum (FCS) **Gemini Bioproducts Catalog #** 900-108
- 8. "R10" medium (RPMI, 10% FCS, 1% penicillin/streptomycin)
- 9. X DNAse I Roche Catalog #04716728001
- 10. Live/Dead fixable Aqua Dead Cell Stain kit Invitrogen Thermo Fisher Catalog #L34966 diluted 1:60 in 1x PBS (prepare fresh each day from DMSO stock)
- 11. Paraformaldehyde (PFA) Electron Microscopy Sciences Catalog #15712-S diluted to 1% in PBS
- 12. Fluorophore-labelled antibodies of choice
- 13. Hemocytometer



Procedure

1 Thawing and Resting

- **a.** Pre-warm R10 media in a 👫 37 °C water bath.
- **b.** Thaw samples in-vial using a \$\mathbb{\mathbb{L}}\$ 37 °C water bath.
- **c.** Add thawed cells to 4 mL of R10, then spin cells at 500 xg for 5 min.
- **d.** Resuspend cell pellet in A 3 mL of R10 and count cells.
- e. Rest cells at least 3 hours (up to overnight) at 2x10⁶ cells/mL in R10 medium + 1 μL/mL DNAse I at 37 °C , 5% CO₂.

Note: during resting, prepare antibody cocktail master mix. Adjust volume of ECS for 4 50 µL per test with FACS buffer.

- **f.** After resting, add PBS up to Δ 15 mL or Δ 50 mL (whichever is closer, rounding up) to cells and transfer to 🚨 15 mL or 🚨 50 mL conical tube.
- g. Spin cells at 500 xg for 5 minutes at room temperature (RT).
- **h.** Resuspend cells in PBS to 1x10⁷ cells/mL and count. If cells are too dilute, re-spin cells and resuspend at $1x10^7$ cells/mL. Transfer \perp 200 mL of cells (2x10⁶ cells) into each well of a Vbottom 96 well plate.

2 Viability and extracellular staining (ECS)

- a. Spin plate at 500 xg for 5 minutes at RT
- **b.** Using a multichannel pipette, carefully remove the supernatant.
- **c.** Using a multichannel pipette, add \perp 45 µL of PBS to well.
- **d.** Add \perp 5 µL of 1:60 Aqua viability dye directly to cell pellet and resuspend cells.



- e. Incubate for 10 minutes at RT in the dark.
- f. Add 🚨 50 µL of ECS antibody cocktail to cells and incubate for 20 minutes at RT in the dark (prepare 1% PFA fixation buffer in the meantime).
- **g.** Add \perp 100 μ L of FACS buffer to each well and spin plate at 500 xg for 5 minutes.
- i. Run samples on flow cytometer.