

FEB 01, 2024

OPEN ACCESS



DOI:

dx.doi.org/10.17504/protocols.io. n92ldmeyol5b/v1

Document Citation: Elena Essel, Matthias Meyer, Merlin Szymanski 2024. UV decontamination of reagents/buffers. protocols.io https://dx.doi.org/10.17504/protoc ols.io.n92ldmeyol5b/v1

License: This is an open access document distributed under the terms of the Creative Commons Attribution License, which permits unrestricted use, distribution, and reproduction in any medium, provided the original author and source are credited

Created: Jan 11, 2024

Last Modified: Feb 01, 2024

UV decontamination of reagents/buffers

Forked from UV decontamination of reagents/buffers

Elena Essel¹, Matthias Meyer², Merlin Szymanski²

¹Department of Evolutionary Genetics, Max Planck Institute for Evolutionary Anthropology, Deutscher Platz 6, D-04103 Leipzig, Germany;

²Max Planck Institute for Evolutionary Anthropology

MPI EVA Ancient DNA Core Unit

Ayinuer



Elena Essel

Department of Evolutionary Genetics, Max Planck Institute fo...

ABSTRACT

Protocol for reducing DNA contamination of reagents and buffers used in the ancient DNA cleanroom by UV treatment.

Change log:

- small formatting edits (20240111, EE)
- small language edits for consistency (20240123, EE)



DOCUMENT integer ID: 93383

Funders Acknowledgement:

Max Planck Society

Note

The effectiveness of UV treatment for DNA decontamination strongly depends on the permeability of material for UV light. Falcon tubes, plastic bottles and regular glass bottles absorb UV light and are therefore poorly suitable for UV-based DNA decontamination. Thus, UV treatment of reagents and buffers should be performed in quartz glass bottles. Perform UV treatment only if indicated in the respective protocols/documents for reagent usage or preparation.

Materials

| Material | Supplier | Cat. no. | Decontamination * |
|---|---|----------|-------------------|
| Quartz glass bottles with plastic screw cap | Quarzglas Komponenten und Service (custom produced) | - | Bleach + UV |
| 250 ml squared plastic bottles | VWR | 391-0629 | - |
| 50 ml Falcon tubes | Greiner Bio-one | 210261 | - |

^{*} See documents in the Appendix for decontamination instructions

Equipment

- UV Crosslinker (e.g., Bio-Link UV Crosslinker, Labortechnik, cat. no. 110.0079)
- aluminum foil (e.g., Roth, cat. no. AA76.1)

Procedure

1. For decontamination of reagents/buffers, pour the reagent/buffer from the stock bottle into a clean quartz glass bottle. Make sure the stock bottle is not touching the quartz glass bottle while pouring.

Note

[Labeling]

Label the quartz glass bottle with the name of the reagent, date (YYYYMMDD) and your initials.

protocols.io

- 2. Close the quartz glass bottle properly to avoid any leaking during UV treatment.
- 3. UV treat the glass bottles in the UV Crosslinker set to 7.000 J (approximate time of irradiation is 40 min).
- 4. Refill the reagent into a bottle that is appropriate for long-term storage (e.g. 50 ml Falcon tube, 250 ml squared bottle).

Note

[Labeling]

Label the storage bottle with the name of the reagent, date (YYYYMMDD), 'UV treated' and your initials.

Note

[Note]

Never store reagents/buffers in the quartz glass bottle, because the lids are not closing tightly. Never pipette out of the quartz glass bottle.

5. Bleach and UV treat the quartz glass bottle following the procedure described in the Appendix before putting it back into the stock.

Appendix

