

DEC 27, 2023

OPEN ACCESS



DOI:

dx.doi.org/10.17504/protocol s.io.kxygx9j1zg8j/v1

Protocol Citation: Angie Chia 2023. Loading a Radseq Library on Nextseq 500. protocols.io https://dx.doi.org/10.17504/p rotocols.io.kxygx9j1zg8j/v1

License: This is an open access protocol distributed under the terms of the Creative Commons

Attribution License, which permits unrestricted use, distribution, and reproduction in any medium, provided the original author and source

are credited

Protocol status: Working We use this protocol and it's working

Created: May 18, 2023

Last Modified: Dec 27,

2023

Coading a Radseq Library on Nextseq 500

Angie

Chia¹




eaglefishgeneticslab Eagle Fish Genetics Lab

ABSTRACT

Protocol to load a Radseq Library on EFGL Nextseq 500


PROTOCOL MATERIALS

¹Eagle Fish Genetics Lab



NextSeq 500 Prep

1 Power cycling & Manual Wash: Perform a manual wash (Post Run Manual Wash), approximately two hours prior to run/or on the morning of run.



1.1 Power cycle NextSeg 500

5m

- 1. Tap on Home, if not already on Home screen
- 2. Select Manage Instrument -> System Shut down Options
- 3. Select Shut Down
- 4. Wait 00:05:00 , before powering back up by pressing on the On button in front of machine
- 5. Enter login credentials once Windows startup has completed.
- 6. Wait for machine to initialize NextSeg software, and displays Home screen once ready.
- 1.2 Perform a Post Run Manual Wash (if a run was completed within the past 2-3 days, OK with quick wash instead)
 - 1. On Home screen, select Perform Wash -> Manual Wash
 - 2. Follow the instructions on NextSeq 500's screen
 - 3. When loading wash buffer tray, be sure to fill position 34 with 0.01% ddH20/TWEEN about 3/4 full
 - 4. Tap on Start to begin wash

Important: If there is a run in place prior to your wash, the waste container has 1.8% formamide. It needs to be disposed of properly into a waste bottle. Similarly, if reagent tray is in the machine, remove formamide container (location 6) and dispose of it properly (zip-loc bag - contaminated waste trash can). All other liquid/solid waste can be disposed of in sink/trash can.

X Tween 20 LabChem Catalog #BP337-100

- 2 Thaw Reagent Tray and Flow Cell It is important that the output of both the reagent tray and flow cell matches i.e. MID/MID or HIGH/HIGH
- 2.1 Retrieve a High-300 output or Mid-300 output Illumina Reagent Tray from the freezer and place in bucket/container of room temperature tap water. Water level should be to the bottom of the reagent tray handle. Let thaw for 01:00:00 in water bath.
- 2.2 Retrieve 1 tube of HT1 buffer from the freezer, and place in a beaker of room temperature tap water to thaw as well.
- 2.3 At the 30 minute mark of reagent tray thaw process, retrieve a matching output flow cell (i.e. MID/MID or HIGH/HIGH) from the fridge. Open flow cell packaging, but leave it in its packaging on bench to let it come to room temperature.

NextSeq Library Prep

5m

- 3 Begin prepping RAD library for loading, only after reagent tray has been thawing for 40 minutes, and flow cell left on bench for 10 minutes.
- **3.1** Prepare **0.2 N** NaOH denature solution. In a new 1.5mL LoBind tube (label tube **0.2**):
 - 1. Add 🛕 10 µL of **1 N** NaOH + 🛕 40 µL of molecular grade lab water
 - 2. Gently vortex, and briefly spin down.
 - 3. Let sit at room temperature.

Sodium Hydroxide 1.0N (1.0M) LabChem Catalog #LC243501

3.2 Add the following components *in order* into a new 1.5mL LoBind tube (label tube **DL**):

5m

- 1. \bot 5 μ L of **0.2 N** NaOH + \bot 5 μ L of **4nM** RAD library do not pump, as this can introduce bubbles
- 2. Vortex gently, spin (5 300 x g, 00:01:00 (using IEC micromax)
- 3. Incubate DL at room temperature for © 00:05:00
- 4. Add Δ 5 μL of **200mM** Tris-HCl pH 7.0 to DL
- 5. Vortex gently and spin down



3.3 To DL tube, add \triangle 985 μ L of HT1 buffer.

If library is not at 4nM, use the equation below to determine the amount of HT1 buffer to add:

$$X = ((5uL*libraryconc.[nM])/(0.020nM)) - 15$$

3.4 Gently vortex DL tube, and spin down. Keep tube in a benchtop cooler.

Library is now at 20pM.

Depending on the output you'll want to achieve for your library, further dilute your library to the desired concentration prior to loading onto reagent tray for sequencing. The table below is an example that our lab uses for Mid/High - 300 cycles output libraries.

Mid or hi Output – 300 cycles		
library conc. [pM]	DL	HT1 buffer (2X)
1.6	104	598
1.8	117	592
2.0	130	585
2.25	146	577
3.25	211	544
3.50	228	536
3.75	244	528
4.00	260	520

HT1 buffer (2X) = adding amount twice

- **4.1** In a new 2.0mL tube (label tube **10**), add the components accordingly to the table above.

 - 2. Keep tube in benchtop cooler till reagent tray is ready to be loaded.

Prep NextSeq reagent tray

- 5 Once reagent tray has been thawing for an hour, remove tray from water bath and wipe dry.
 - 1. Invert reagent tray gently 5 times to mix reagents, and gently tap tray on bench top to collect all liquid to the bottom.
 - 2. Use a 1000µl pipette tip and punch a hole in position 10. Discard tip.
 - 3. Load all A 1300 µL of tube 10 into position 10 of reagent tray.

Loading reagent tray on NextSeq 500

- 6 1. Verify both reagent tray and flow cell output matches.
 - 2. Take a new buffer cartridge
 - 3. Inspect the flow cell by making sure brackets on the back are in place, and flushed. If there's any dirt on top of flow cell, gently remove with a Kimwipe.
- **6.1** On Home screen, select Sequence
 - 1. "Manual" would been pre-selected, tap on Next
- **6.2** Enter Run Parameters:
 - 1. Run Name: Use your library name (e.g. L0012)
 - 2. Library ID: Same as Run Name
 - 3. Check the "Paired end" box
 - 4. Read 1: **150** Index 1: **6** Index 2: **6** Read 2: **150** (index cycles are optional)
 - 5. Tap on Next
- **6.3** Follow the instructions on NextSeq 500's screen to load buffer cartridge and reagent tray for sequencing.

Once all pre-run checks are complete on the machine, the run will start automatically. (Typical High-300 Output run takes ~32 hours, and Mid-300 Output takes ~26 hours)