



## **VERSION 2**

DEC 02, 2022

WORKS FOR ME

1

© Extraction and qPCR of Environmental Surveillance samples for the detection of Salmonella Typhi V.2

COMMENTS 0

DOI

## dx.doi.org/10.17504/protocols.io.8epv5zrw4v1b/v2

<u>Dilip Abraham</u><sup>1</sup>, Nicola Elviss<sup>2</sup>, Nicholas Feasey<sup>3</sup>, <u>Nick Grassly</u><sup>4</sup>, Jacob John<sup>1</sup>, Gagandeep Kang<sup>1</sup>, <u>John Scott Meschke</u><sup>5</sup>, <u>Venkata Raghava Mohan</u><sup>1</sup>, Satheesh Nair<sup>2</sup>, <u>Jonathan Rigby</u><sup>3</sup>, Rajan Srinivasan<sup>1</sup>, <u>Catherine Troman</u><sup>4</sup>, <u>Christopher Uzzell</u><sup>4</sup>, Nicolette Zhou<sup>5</sup>

Typhoid Environmental Surveillance



Catherine Troman

## **DISCLAIMER**

Please note, the author list is in alphabetical order and does not reflect contribution.

## **ABSTRACT**

The following protocol is for use on environmental samples that have been collected by Moore swab or grab sampling methods and processed up to the stage of DNA extraction. The protocol includes DNA extraction and qPCR analysis of the samples to detect three gene targets for identifying Salmonella Typhi, a human faecal indicator (HF183), and a commercial spike-in control.

Generation of standard curves is mentioned in this protocol but is described in more detail in a separate protocol in the Typhoid ES workspace.

DO

dx.doi.org/10.17504/protocols.io.8epv5zrw4v1b/v2



<sup>&</sup>lt;sup>1</sup>Christian Medical College, Vellore, India;

<sup>&</sup>lt;sup>2</sup>UK Health Security Agency;

<sup>&</sup>lt;sup>3</sup>Malawi Liverpool Wellcome Trust Clinical Research Program, Blantyre, Malawi;

<sup>&</sup>lt;sup>4</sup>Imperial College London;

<sup>&</sup>lt;sup>5</sup>University of Washington

#### PROTOCOL CITATION

Dilip Abraham, Nicola Elviss, Nicholas Feasey, Nick Grassly, Jacob John, Gagandeep Kang, John Scott Meschke, Venkata Raghava Mohan, Satheesh Nair, Jonathan Rigby, Rajan Srinivasan, Catherine Troman, Christopher Uzzell, Nicolette Zhou 2022. Extraction and qPCR of Environmental Surveillance samples for the detection of Salmonella Typhi. **protocols.io** <a href="https://dx.doi.org/10.17504/protocols.io.8epv5zrw4v1b/v2">https://dx.doi.org/10.17504/protocols.io.8epv5zrw4v1b/v2</a> Version created by <a href="https://catherine.new.com/catherine.com/catherine.com/catherine.com/catherine.com/catherine.com/catherine.com/catherine.com/catherine.com/catherine.com/catherine.com/catherine.com/catherine.com/catherine.com/catherine.com/catherine.com/catherine.com/catherine.com/catherine.com/catherine.com/catherine.com/catherine.com/catherine.com/catherine.com/catherine.com/catherine.com/catherine.com/catherine.com/catherine.com/catherine.com/catherine.com/catherine.com/catherine.com/catherine.com/catherine.com/catherine.com/catherine.com/catherine.com/catherine.com/catherine.com/catherine.com/catherine.com/catherine.com/catherine.com/catherine.com/catherine.com/catherine.com/catherine.com/catherine.com/catherine.com/catherine.com/catherine.com/catherine.com/catherine.com/catherine.com/catherine.com/catherine.com/catherine.com/catherine.com/catherine.com/catherine.com/catherine.com/catherine.com/catherine.com/catherine.com/catherine.com/catherine.com/catherine.com/catherine.com/catherine.com/catherine.com/catherine.com/catherine.com/catherine.com/catherine.com/catherine.com/catherine.com/catherine.com/catherine.com/catherine.com/catherine.com/catherine.com/catherine.com/catherine.com/catherine.com/catherine.com/catherine.com/catherine.com/catherine.com/catherine.com/catherine.com/catherine.com/catherine.com/catherine.com/catherine.com/catherine.com/catherine.com/catherine.com/catherine.com/catherine.com/catherine.com/catherine.com/catherine.com/catherine.com/catherine.com/catherine.com/catherine.com/catherine.com/catherine.com/

MANUSCRIPT CITATION please remember to cite the following publication along with this protocol

<u>#</u>

Uzzell C, Troman C, Rigby J, Mohan V, John J, Abraham D, Srinivasan R, Nair S, Meschke J, Elviss N, Kang G, Feasey N, Grassly N (2021) Environmental surveillance for *Salmonella* Typhi as a tool to estimate the incidence of typhoid fever in low-income populations. medRxiv, doi: 10.1101/2021.05.21.21257547

## LICENSE

This is an open access protocol distributed under the terms of the <u>Creative Commons</u>

<u>Attribution License</u>, which permits unrestricted use, distribution, and reproduction in any medium, provided the original author and source are credited

**CREATED** 

Nov 09, 2022

LAST MODIFIED

Dec 02, 2022

PROTOCOL INTEGER ID

72533

#### **GUIDELINES**

The qPCR uses fluorescence of Taqman probes for measuring the product, care must be taken to ensure that the fluorescent dyes chosen for the probes are suitable for the machine being used or can be calibrated for use on the machine. If the dyes selected are different from those described in the protocol, make sure that their excitation/emission spectra do not overlap to avoid crossover between targets.

MATERIALS TEXT

- 🔯 QIAamp PowerFecal Pro DNA Kit **Qiagen Catalog #51804**
- Water, nuclease free Contributed by users
- 🔀 qPCR DNA Extraction and Inhibition Control CY5-QXL670 Eurogentec Catalog #RT-SPCC-Q02
- X Takyon Low ROX Probe 2x MasterMix dTTP blue Eurogentec Catalog #UF-LPMT-B0701

Primers and Probes (detailed in protocol)

gBlocks DNA fragments (detailed in protocol)

qPCR machine

96-well plates for gPCR and plate seals

Vortex with tube adapter

1.5ml tubes

DISCLAIMER



2

## **DNA Extraction**

1 For extraction from Moore swabs, empty the contents of a PowerBead tube provided in the extraction kit into the PowerBead tube used for storing the filter.

For the pellet from membrane filtration, resuspend the pellet in 800µl CD1 from the first step of the DNA extraction protocol, then transfer to the PowerBead tube for homogenisation.

For an extraction negative control, carry out the extraction protocol starting with just the CD1 (step2.1) and no sample.

- 2 Carry out the DNA extraction according to the manufacturer's protocol provided with the DNA extraction kit. In brief:
- 2.1 Add 800µl of Solution CD1 to the PowerBead tube and 1ul of validated SPC dilution from the Extraction and Inhibition control kit.
  - 1) Before first use of the SPC, prepare a 1/10th and a 1/100th dilution of the control DNA in pure water and store them on ice
  - 2) Evaluate the non-diluted and the 2 diluted control DNA solutions in separate extractions by adding  $1\mu$ L of control DNA into your reference sample before parallel extractions. Perform the extraction and qPCR and select the dilution factor generating Ct values between 30 and 33
- 2.2 Homogenize using a vortex adapter at maximum speed for up to 10 minutes
- 2.3 Centrifuge the PowerBead tube at 1500 x g, 00:10:00
- 2.4 Transfer the supernatant to a clean Microcentrifuge tube, add 200µl of Solution CD2 then vortex for 5s
- 2.5 Centrifuge at 1500 x g, 00:01:00 and transfer up to 700µl of supernatant to a clean 2ml Microcentrifuge tube, avoiding the pellet

- 2.6 Add 600µl of Solution CD3 and vortex for 5s
- 2.7 Load 650μl onto an MB Spin Column and centrifuge at \$\infty\$ 1500 x g, 00:01:00
- 2.8 Discard the flow-through and repeat until all the lysate has been passed through the spin column
- 2.9 Carefully place the spin column into a clean 2ml collection tube. Avoid splashing any flow-through onto the column
- 2.10 Add 500µl of Solution EA to the spin column and centrifuge at 3 1500 x g, 00:01:00
- 2.11 Discard the flow-through and add 500μl of Solution C5 to the spin column and centrifuge at 15000 x g, 00:01:00
- 2.12 Discard the flow through and place the column in a clean 2ml collection tube
- 2.13 Centrifuge at § 1600 x g, 00:02:00 then place the column in a clean 1.5ml collection tube
- 2.14 Add 50µl of Solution C6 to the center of the filter membrane and let it sit for 1 minute

- 2.15 Centrifuge at § 1500 rpm, 00:01:00 and discard the spin column
- 2.16 The DNA is now ready for qPCR, or storage at -20°C

# **Preparation of Primers and Probes**

3 S. Typhi genes being targeted are staG, tviB, and ttr. Primers and probes have also been included for HF183 human faecal indicator to use as a positive control for faecal contamination in the samples and sample sites.

| А                | В                                                    |
|------------------|------------------------------------------------------|
| Primer/Probe Nam | Sequence (5' -3')                                    |
| staG_F           | CGC GAA GTC AGA GTC GAC ATA G                        |
| staG_R           | AAG ACC TCA ACG CCG ATC AC                           |
| staG_P           | [TAMRA] - CA TTT GTT CTG GAG CAG GCT GAC GG - [BHQ2] |
| ttr_F            | CTC ACC AGG AGA TTA CAA CAT GG                       |
| ttr_R            | AGC TCA GAC CAA AAG TGA CCA TC                       |
| ttr_P            | [FAM] - CA CCG ACG GCG AGA CCG ACT TT - [BHQ1]       |
| tviB_F           | TGT GGT AAA GGA ACT CGG TAA A                        |
| tviB_R           | GAC TTC CGA TAC CGG GAT AAT G                        |
| tviB_P           | [JOE] - TG GAT GCC GAA GAG GTA AGA CGA GA - [BHQ1]   |
| HF183_F          | ATC ATG AGT TCA CAT GTC CG                           |
| HF183_R          | CTT CCT CTC AGA ACC CCT ATC C                        |
| HF183_P          | [FAM] - CT AAT GGA ACG CAT CCC - [BHQ1]              |

Table1: Primer (F or R) and probe (P) sequences. Fluorescent dyes and quenchers are shown in square brackets.

Resuspend the probes and primers in the appropriate volume of nuclease free water to make stock dilutions of each primer at  $20\mu M$  and each probe at  $5\mu M$ .

# **Preparation of Standards**



Using gBlocks gene fragments (IDT) with the target amplicon sequences, a standard curve can be obtained by running a qPCR on a dilution series of the DNA fragments.

This allows determination of potential Ct cut off values to help with determining a positive result in the qPCR with real samples.

A separate protocol for carrying out this experiment is provided in the Typhoid ES workspace.

| A           | В                                                         |
|-------------|-----------------------------------------------------------|
| gene target | gBlocks sequence (5' - 3')                                |
| staG        | CGGCGCGAAGTCAGAGTCGACATAGGCATAGATTTTCAGGCCATACATTAATTTGC  |
| ttr         | GAAACGCTGAACGGACTCACCAGGAGATTACAACATGGCTAATTTAACCCGTCGTC  |
| tviB        | CTTGATTTGACTTCCGATACCGGGATAATGCCATACTCTCGTCTTACCTCTTCGGC/ |
| HF183       | GGGATCATGAGTTCACATGTCCGCATGATTAAAGGTATTTTCCGGTAGACGATGGG  |

Table 2: Sequences used for gBlocks gene fragments. Sequences for the *S*.Typhi targets were taken from the CT18 reference genome (AL513382.1) and the HF183 sequence was taken from a *Bacteroides dorei* 16S rRNA partial gene sequence (MT464394.1). 3 additional bases were added either side of the *staG* and HF183 amplicon sequences. 15 and 8 bases were added to either end of the *ttr* and *tviB* sequences respectively to reach the minimum length for the gBlocks fragment.

## **Quantitative PCR**

- 6 Thaw qPCR reagents and samples on ice and briefly spin down.
- 7 Set up a master mix for the number of samples to be tested plus a negative control and one extra to allow for pipetting error.

If you wish to carry out single-plex reactions for any of the gene targets, input the same amount of the mastermix, target primer and probe, and substitute the remaining volume with nuclease free water.

| A       | В             | С                  |
|---------|---------------|--------------------|
| Reagent | Volume per re | Final Concentratio |
| ttr_F   | 0.25          | 0.2                |
| ttr_R   | 0.25          | 0.2                |
| ttr_P   | 0.5           | 0.1                |

| A                    | В    | С   |
|----------------------|------|-----|
| tviB_F               | 0.5  | 0.4 |
| tviB_R               | 0.5  | 0.4 |
| tviB_P               | 1    | 0.2 |
| staG_F               | 0.5  | 0.4 |
| staG_R               | 0.5  | 0.4 |
| staG_P               | 1    | 0.2 |
| 2x MasterMix with RO | 12.5 | 1x  |
| Nuclease free water  | 2.5  | -   |

Table 3: Mastermix composition for the S. Typhi qPCR

8 Make up another master mix for the HF183 qPCR and internal control

| A                     | В             | С                   |
|-----------------------|---------------|---------------------|
| Reagent               | Volume per re | Final Concentration |
| HF183_F               | 0.5           | 0.4                 |
| HF183_R               | 0.5           | 0.4                 |
| HF183_P               | 1             | 0.2                 |
| 2x MasterMix with RC  | 12.5          | 1x                  |
| 10x Control mix (Euro | 2.5           | 1x                  |
| Nuclease free water   | 3             | -                   |

Table 4: Mastermix composition for the HF183 qPCR

- 9 Aliquot 20µl of mastermix to each required well in a 96-well plate.
- Add 5µl of sample, or 5µl of nuclease free water for negative controls.
- Seal the plate carefully with a plate seal the spin the plate down briefly to gather all reagents at the bottom of the well and remove bubbles.

Load the plate into the real-time PCR machine after setting it up appropriately and carry out cycling using the following conditions:

| Α     | В               | С          |
|-------|-----------------|------------|
| Cycle | Temperature (°C | Duration   |
| 1     | 50              | 2 minutes  |
| 1     | 95              | 2 minutes  |
|       | 95              | 15 seconds |
| 40    | 60              | 30 seconds |
|       | 72              | 30 seconds |

- Once the run is complete assess the normalised Ct values for each gene target for each sample, determining positivity using the cut-off Ct values chosen from running the standards.
- 13.1 If all gene targets have Ct values higher than the cut-off, check the Ct values for the HF183 target and the spike-in control.
  - If the spike-in control is negative or lower than expected this may indicate an issue with PCR inhibition or during DNA extraction
  - If the HF183 is negative and spike-in control was positive, then this may mean that there was no or insufficient faecal contamination in the sample site
- 13.2 If all three targets are positive, then the sample is considered positive for S.Typhi.

If the sample is positive for *ttr* and only one of either *staG* or *tviB*, repeat the target that was negative in a singleplex reaction as this may result in a positive if the target is just very close to the limit of detection.

The following table gives expamples for interpretation of the qPCR results (after singleplex repeats):

| A                | В             | С                         |
|------------------|---------------|---------------------------|
| qPCR result      | Low Ct values | High Ct values            |
| ttr+ staG+ tviB+ | S.Typhi       | S.Typhi (or a more comple |
| ttr+ staG- tviB+ | Mixture (NTS) | Mixture (NTS)             |
| ttr+ staG+ tviB- | Mixture (NTS) | Mixture or S.Typhi where  |