

Apr 20, 2024 Version 2

Human CD34+ cell isolation from fetal liver, and fetal thymus preparation V.2

DOI

dx.doi.org/10.17504/protocols.io.6qpvrdw3ogmk/v2



Austin Chen¹, Mohsen Khosravi-Maharlooei¹, Markus Holzl¹, Nichole Danzl¹, Chris Parks¹, Elizabeth Waffarn¹, Megan Sykes¹

¹Columbia Center for Translational Immunology, Columbia University, New York

Human Islet Research Ne...



Sandy Beshir

City of Hope

OPEN ACCESS



DOI: dx.doi.org/10.17504/protocols.io.6qpvrdw3ogmk/v2

Protocol Citation: Austin Chen, Mohsen Khosravi-Maharlooei, Markus Holzl, Nichole Danzl, Chris Parks, Elizabeth Waffarn, Megan Sykes 2024. Human CD34+ cell isolation from fetal liver, and fetal thymus preparation. **protocols.io**https://dx.doi.org/10.17504/protocols.io.6qpvrdw3ogmk/v2Version created by <a href="mailto:sandy-mailto-sandy-sa

License: This is an open access protocol distributed under the terms of the **Creative Commons Attribution License**, which permits unrestricted use, distribution, and reproduction in any medium, provided the original author and source are credited

Protocol status: Working
We use this protocol and it's

working

Created: April 20, 2024

Last Modified: April 20, 2024

Protocol Integer ID: 98526



Funders Acknowledgement:

NIH

Grant ID: U01 DK123559

Abstract

This protocol details the steps for isolating human CD34+ cells from human fetal liver. It also explains how to prepare human fetal thymus for immediate use or for freezing, as well as the process for thawing. The CD34+ cells are hematopoietic progenitor cells and can be used to generate humanized mice through reconstitution of immune cells via IV injection after bone marrow ablation. These cells can also be used for mixed lymphocyte reaction experiments.

Note

Corresponding Authors

Mohsen Khosravi-Maharlooei

Email: mkm2182@cumc.columbia.edu

Austin Chen

Email: ac4274@cumc.columbia.edu

Tel: 425-283-6900



Materials

Human tissue:

Order human fetal thymus tissue from Advanced Bioscience Resources (Perrin Larton perrin@garlic.com)

Media:

- BM media:
 - ∆ 500 mL 199 Media (Corning 10060CV)
 - ∆ 5 mL 1M Hepes to buffer pH
 - △ 5 mL 1mg/ml (2714 units/mg) DNAse to prevent cell clumping
 - Use 70 um filter with syringe to filter DNAse directly into 199 Media
 - Δ 40 μL 50mg/ml Gentamycin
- MACS buffer:
 - △ 500 mL PBS
 - ∆ 5 g BSA
 - △ 2 mL EDTA 0.5M
 - o De-gas overnight with parafilm around the caps
- AIM-V medium (serum free):
 - o Human serum (for use with AIM-V)
 - o Add DNAse (🚨 125 µL) if using AIM-V rather than BM media
- Liberase™ TM (Roche) 1 WU/mL in BM Medium

Material:

- Sterile forceps, scissors
- △ 10 mL and △ 25 mL pipette tips for pipette aid
- 70 um nylon cell strainer
- Styrofoam box for ice- for CD34 isolation kit
- Histopaque or Percoll (contains small plastic beads that separate materials by density centrifugation)
- → ← 10 cm petri-dish
- ∆ 50 mL Falcon tubes
- DMSO
- Human AB serum
- CD34+ MACS kit (Miltenyi)



Before start

All procedures have to be performed under sterile conditions!



Digestion method for CD34+ isolation

- 1 Start water bath and heat to 37 °C if not already on.
- 2 Spray the fetal organ test tube before putting it into the hood
- 3 Fill beaker w/ 70% EtOH. Soak your tools in this.
- 4 Lay out tools onto petri dish to evaporate the EtOH off of them (EtOH will fix the tissue). Open fetal liver test tube and pour out all contents into a big petri dish.
- 5 Separate the white connective tissue from the rest of the tissue and place onto the lid of the original petri dish. Also remove the gall bladder if present (and discard this).

 - **b.** Remove the gall bladder and as much connective tissue as possible (and the ligaments), as they cannot be digested and would clot the pipette
- 6 Prepare pre-diluted Liberase solution in BM media or AIM-V media) in a 🚨 15 mL Falcon tube:
 - **a.** Add <u>I</u> 5 mL AIM-V medium (or BM media) to a <u>I</u> 50 mL falcon tube will say BM media for rest of protocol, but seems like you can use AIM-V + 10% human serum too.
 - i. Add \perp 125 μ L DNAse **only** if using AIM-V.
 - **b.** Add \perp 200 μ L Liberase (\perp 0.5 mg) found in aliquots.
- Transfer the non-connective tissue liver pieces from the petri dish to a 4 50 mL Falcon tube with 4 5 mL Liberase + BM media.
 - **a.** Take big pieces and cut it into smaller pieces above the 4 50 mL Falcon tube so that the cut pieces drop directly back into the Falcon tube.



- i. This way, you do not need to take more time later to transfer the smaller pieces from the petri dish.
- **b.** Can then use a pipette to transfer the remaining pieces and media from the petri dish back into the 4 50 mL Falcon tube
- i. Don't add this directly to the Liberase. Put into a different falcon tube, centrifuge, aspirate supernatant, and then resuspend with Liberase (or solution already containing Liberase) to avoid diluting the Liberase.
 - ◆ Centrifuge settings: 4 C | 1650 RPM | 3 minutes ♦♦ Discard supernatant by pipetting off the solution
- 8 Vortex this tube for 20 seconds.
- 9 Place in a rack and place in 37 °C water bath. (The rack should already be in the bath)
 - a. Let it sit for 6 minutes.
 - **b.** Vortex for 20 seconds again and pipette up and down with 🔼 10 mL pipette. Then place back in 37 °C water bath for another 6 minutes.
 - i. Repeat this step a few times until you can pipette up and down easily with a 🛮 🗸 5 mL pipette
 - (1). Must spray down with EtOH each time before placing it back into the hood. Return to
 - (2). usually completely digested within 10-15 minutes.
 - ii. The liver should now be disrupted to a single cell solution. The pipette should not clot anymore (except for ligaments, etc).
 - c. At some point, if not done already, also cut up the connective tissue that you reserved for HLA typing and place it into a yellow/blue top container (without media) while the tissue is digesting in the water bath.
- 10 Grab at least two 70 um filters and place 1 on top of 2 new 4 50 mL Falcon tubes.
- 11 Once solution is easily pipettable through A 5 mL pipette and "feels" like a single cell suspension, top off Falcon tube with BM media.




- 12 Transfer

 △ 25 mL of the solution to each new

 △ 50 mL Falcon tube through the 70 um filter. (should have 2 Falcon tubes with filtered \perp 25 mL cells)
- 13 Centrifuge both of these A 50 mL Falcon tubes
 - a. Centrifuge settings: 4 C | 1650 RPM | 3 minutes
- 14 While centrifuging, prepare **four** \perp 50 mL Falcon tubes with \perp 13 mL Histopaque (use a ∆ 10 mL pipette)
- 15 When centrifuge done, aspirate supernatant, then resuspend each pellet in A 50 mL BM media.
- 16 Add \perp 25 mL of cells + BM media to each tube with \perp 13 mL Histopaque (4 total) by slowly dripping the cells onto the top of the Histopaque. Can tilt the tube and support it on any structure for stabilization (e.g. Styrofoam holder for the 🚨 50 mL falcon tubes, a 🚨 50 mL falcon tube holder, etc.)
 - a. Weigh the tubes in the centrifuge containers to make sure they are balanced. Add water into the container if it is not balanced.
 - b. Centrifuge all 4 tubes: if using histopaque: 25 °C | 0 prog | 2000 rpm | 25 minutes, accel: 1, brake: 0
 - **c.** Grab some lunch!
- 17 Collect the buffy coat into two 4 50 mL Falcon tube (each 2 tubes goes into 1 tube) – then fill up the 4 50 mL ube with BM media:
 - a. Use 🚨 10 mL or 🚨 25 mL pipette and suck up the "ring"/layer right above the Histopaque. Will inevitably suck up Histopaque as well, but try to suck up all of the layer right above it.
 - **b.** Collect all of the layer/Histopaque until you get close to the RBCs to make sure you have obtained all of the buffy coat (which contains PBMCs)



Figure 1 Figure 2 PBMCs



- 18 Centrifuge the tubes that you have just collected
 - **a.** 4 C | 1650 RPM | 4 minutes
 - **b.** Discard the supernatant by aspirating with pipette
 - **c.** Optional: RBC Lysis Add 5ml ACK Lysis buffer, incubate 5min RT.



- i. If RBC lysis, wash with BM media, then centrifuge and resuspend in MACS buffer (step 19)
- 19 Resuspend in 4 15 mL MACS buffer.
- 20 Take A 100 µL and add to a 1.5 round bottom blank tube labeled "Pre" for flow cytometry
- 21 Count the cells: do serial dilution to 1:25 dilution factor
 - **a.** \bot 40 μ L Trypan blue + \bot 10 μ L cells (1:5 dilution factor). Then \bot 10 μ L of this combination (1:5 dilution factor) into another \triangle 40 μ L Trypan blue = 1:25 dilution factor

MACS isolation:

- 22 Centrifuge cells 4 C | 1650 RPM | 3-4 minutes
 - a. While centrifuging, grab CD34+ microbeads + FcR blocker (MACS Miltenyi Biotec CD34 Microbread kit)
 - **b.** Calculate volumes needed for addition of FcR Block and Beads
 - 1 volume FcR Block= ____ul (1x volume of beads)
 - 1 volume CD34 microbeads= ____ul (10ul per 10⁷ cells)
 - 8 volumes Macs Buffer= ____ul (8x volume of beads)
 - Max volumes: 200 uL FcR blocker, 200 uL CD34 microbeads, 1.6 mL MACS buffer
 - ◆ Example calculation: for 339.375E6 cells à 33.9E7 cells = □ 339 µL . But since max =

Δ 200 μL , we used
Δ 200 μL CD34+ microbeads,
Δ 200 μL FcR blocker, and △ 200 µL MACS buffer.

- Usually we get around 500E6 cells. For this amount, we don't use 500 uL of beads (it's too much). Usually between 100 to 200 uL is enough.
 - ♦

 Д 150 µL CD34+ beads
 - ♦

 4 150 µL FcR blocker
 - ♦ 🗸 1.2 mL MACs buffer
- 23 Resuspend cells with amount of MACS buffer first.
 - a. Then add FcR blocker (must add FcR blocker before microbeads!!)
 - **b.**Then add CD34 microbeads



- **c.** Pipette up and down
- 24 Incubate for 30 minutes at 4 °C
- 25 Wash cells by adding 5-10ml MACS buffer. Centrifuge cells 1650 RPM, 3-4 min, 4C. Aspirate and discard supernatant.*Important to stick to this centrifuge speed because at higher speeds beads that have NOT bound cells will also be spun down into pellet.
 - **a.** Prepare MACS set up while centrifuging:
 - **b.** LS filter placed into MACS set up "multi stand" with fin tips pointing toward you; place △ 15 mL falcon tube underneath LS filter; place 70 uM filter on top of the LS filter i.Label the falcon tube "CD34-"
 - **c.** a.Add 3 mL MACS to the 70 uM filter + LS filter after you put it together to wet the filter
- 26 Resuspend the sample in 4 1 mL MACS and add this to the MACS filter tube **through the 70** uM filter
- 27 Once liquid has flowed through the filter, wash 3 times with 4 3 mL MACS each
 - **a.** For the first wash, put the $\sqsubseteq 3 \text{ mL}$ into the original $\sqsubseteq 15 \text{ mL}$ tube that held the tissue. Pipette up and down and add to the LS filter
 - **b.** Can then toss the original tissue tube and the 70 uM filter on top of the LS filter
 - **c.** For the next 2 washes, add <u>A</u> 3 mL MACS straight to the LS filter
- 28 Remove the CD34- tube, and switch it with a tube labeled CD34+.
- 29 Remove the LS filter from the magnet, place it over the CD34+ tube, add 5 mL MACS buffer, take the plunger, and force out the CD34+ cells.
- 30 Add \perp 100 μ L of CD34+ and \perp 100 μ L CD34- to separate round bottom, blank tubes for flow cytometry later



- 31 Count the CD34- and CD34+ cells
 - **a.** For CD34-: use 1:125 dilution (12-13 mL)
 - **b.** For CD34+: use 1:25 dilution (5 mL)
- 32 Determine how many vials to freeze
 - a. For CD34+: freeze 2 million per vial. Use AIM-V + 10% HS in 10% DMSO
 - **b.** For CD34-: freeze ~50 million per vial. Use AIM-V + 10% HS in 10% DMSO
- 33 Stain the small aliquots taken before for purity check by flow cytometry:
 - a. hCD3 BV650
 - b. hCD19 APC
 - c. hCD45 PE-CF594
 - d. hCD34 PE
 - e. DAPI
 - f. Human serum as blocker

Alternative: CD34+ isolation by smashing the fetal liver

34 1. Put fetal liver in a petri dish and smash it gently with a sterile plunger of a 3 or 6ml syringe.

Transfer cell suspension into 🚨 50 mL conicals through a 40 um cell strainer

- 2. Place cell suspension on 🚨 14 mL of Histopaque 1.077 of a 🚨 50 mL tube.
- 3. Centrifuge 600 g, 25 min, 25 C, acc 3, break 0
- 4. Collect buffy coats and filter through 40 um cell strainer. Fill up with MACS buffer
- 5. Count cells
- 6. Spin 6 min 400 g, 4 C,
- 7. Resuspend in MaCs buffer according to protocol



8. Perform MACS

Fetal thymus isolation and freezing

- 35 1. Cut thymus in → ← 2 mm 3 big pieces in a petri dish
 - 2. Transfer counted pieces (e.g. 10) into a cryotube. Remove medium
 - 3. Fill up with 🚨 1 mL of cryomedium
 - 4. Let the cells incubate for 5 minutes (DMSO has to diffuse into the tissue in order to mediate cryoprotection)
 - 5. Alternatively, thymus can immediately be transplanted

Thymus thaw

- 36 1. Take vials and transfer them to a 👫 37 °C water bath. Let them sit there for 10 minutes
 - 2. Pour the thymic pieces into 🛴 15 mL BM medium (warm) and let them sit for 10 minutes
 - 3. Before transfer to a new Falcon, vigorously pipette the thymic pieces up and down to remove excess of thymocytes. Transfer the cells to new 🚨 15 mL BM
 - 4. Let the cells sit for 10 minutes. Before transfer into a new falcon, pipette vigorously up and down to remove excess of thymocytes. Transfer the cells to new 🚨 15 mL BM
 - 5. The cells are now ready for transplantation