



Oct 28, 2020

♦ Long Read Viromics Amplification Library Preparation (VirION 2)

In 1 collection

Marie Burris¹, Natalie Solonenko¹, Olivier Zablocki¹, Ben Temperton²

¹The Ohio State University; ²University of Exeter

1 Works for me This protocol is published without a DOI.

Sullivan Lab

Marie Burris

PROTOCOL CITATION

Marie Burris, Natalie Solonenko, Olivier Zablocki, Ben Temperton 2020. Long Read Viromics Amplification Library Preparation (VirION 2). **protocols.io**

https://protocols.io/view/long-read-viromics-amplification-library-preparati-5yug7ww

COLLECTIONS (i)

VirION 2

LICENSE

This is an open access protocol distributed under the terms of the Creative Commons Attribution License, which permits unrestricted use, distribution, and reproduction in any medium, provided the original author and source are credited

CREATED

Jul 29, 2019

LAST MODIFIED

Oct 28, 2020

PROTOCOL INTEGER ID

26356

PARENT PROTOCOLS

Part of collection

VirION 2

GUIDELINES

Use DNA from "preparation of extracted DNA for long read library prep" as starting material for this protocol.

Use DNA LoBind tubes throughout this entire protocol (except for PCR tubes).

⊠ DNA LoBind

Tubes Eppendorf Catalog ##022431021

Sample Concentration

1

Prepare 48 ul of sample to use as input for the next step. Sample should have between 1ng - 100 ng of DNA for reliable library success. See "Preparation of extracted DNA for long-read library prep" concerning preparation of DNA for this protocol.

DNA repair, End repair and dA tailing

- 2 Prepare reaction mix using the following, making enough master mix for the total number of samples you are working with.
 - 3.5 ul NEB Ultra II End Repair/dA Tailing reaction buffer
 - 3 ul NEB Ultra II End Repair/dA Tailing enzyme mix
 - 3.5 ul NEB FFPE DNA repair buffer
 - 2 ul NEB FFPE DNA enzyme mix

■ NEBNext Ultra II End Repair/dA-Tailing Module - 24 rxns New England

Biolabs Catalog #E7546S

⊠NEBNext FFPE DNA Repair Mix - 24 rxns **New England**

Biolabs Catalog #M6630S



We recommend making 0.2 reactions worth of extra master mix to account for pipetting error.

- 2.1 In a PCR tube, add 12 ul master mix to 48 ul DNA from step 1.
- 2.2 Using a thermal cycler, incubate at 25 C for 5 minutes and 65 C for 5 minutes.

8 25 °C © 00:05:00

8 65 °C © 00:05:00

- 2.3 Clean up using AMPure XP beads (1:1 sample:beads) and elute in 31ul nuclease-free water into a 1.5mL tube.
 - See "Ampure Bead Clean up For HMW DNA" protocol.
 - For final elution step, incubate at 8 55 °C ⑤ 00:02:00

Coulter Catalog #A63881

2.4 Use 1ul to assess DNA concentration with Qubit.

Adapter ligation

- 3 Add the following to 30 ul DNA from previous step:
 - 50 ul NEB Blunt/TA ligase
 - 20 ul BCA (from Oxford Nanopore PCR Barcoding Expansion 1-12 kit)

users Catalog #M0367

⊠PCR Barcoding Expansion 1-12 **Contributed by**

users Catalog #EXP-PBC001

3.1 Incubate at room termperature for 10 minutes.

§ Room temperature © 00:10:00

- 3.2 Clean up using AMPure XP beads (1:0.4 sample:beads) and elute in 15ul Nuclease-free water into a PCR tube.
 - See "Ampure Bead Clean up For HMW DNA" protocol.
 - For final elution step, incubate at § 55 °C ⑤ 00:02:00
- 3.3 Use 1ul to assess DNA concentration with Qubit.

PCR Amplification

- 4 Prepare reaction mix using the following from the LA TaKaRa Hot Start kit, making enough master mix for the total number of sample you are working with.
 - 16 ul dNTPs
 - 10 ul 10x reaction buffer
 - 1 ul LA TaKaRa enzyme
 - 66 ul water

⊠LA TaKaRa Hot

Start Takara Catalog #RR042A



4.1 Add 2 ul of your chosen barcode from Oxford Nanopore PCR Barcoding Expansion 1-12 kit to 5 ul of DNA from previous step.



- 4.2 Add 93 ul of master mix to the barcode DNA mix
- 4.3 Use the following thermocycler conditions to amplify the library using minimum of 15 cycles.
 - repeat steps 2-4 of this sub-step 15-25 times
 - 1.) § 94 °C © 00:01:00
 - 2.) § 94 °C © 00:00:30

- 3.) § 62 °C © 00:00:30
- 4.) § 68 °C © 00:16:00 for 20kb
- 5.) § 72 °C © 00:16:00 for 20kb
- 4.4 Clean up using AMPure XP beads (1:0.5 sample:beads) and elute in 20ul Nuclease-free water.
 - See "Ampure Bead Clean up For HMW DNA" protocol.
 - For final elution step, incubate at § 55 °C ⑤ 00:02:00
- 4.5 Check the concentration (we recommend Qubit) and purity (NanoDrop) of your DNA, and run on a Genomic DNA TapeStation to assess library size.
- The amplified libraries should be used as input for the Oxford Nanopore 1D Genomic DNA by Ligation (SQK-LSK109) protocol, beginning with the "DNA repair and end-prep" step. Libraries with different barcodes can be pooled at your desired ratio before beginning. We recommend loading 10 100 fmol of DNA into the flow cell.

⋈ 1D Genomic DNA by Ligation Contributed by

users Catalog #SQK-LSK109