

FEB 02, 2024

# OPEN ACCESS



DOI:

dx.doi.org/10.17504/protocols.io.y xmvm3qn9l3p/v1

Protocol Citation: REDI-NET Consortium 2024. F-3 FECES STORAGE. protocols.io https://dx.doi.org/10.17504/protoc ols.io.yxmvm3qn9l3p/v1

License: This is an open access protocol distributed under the terms of the Creative Commons Attribution License, which permits unrestricted use, distribution, and reproduction in any medium, provided the original author and source are credited

Protocol status: Working We use this protocol and it's working

Created: Nov 17, 2023

## ← F-3 FECES STORAGE

REDI-NET Consortium<sup>1</sup>

<sup>1</sup>REDI-NET Consortium



### **REDI-NET Consortium**

University of Notre Dame, Naval Medical Research Center, Wal...

### **DISCLAIMER**

This work is supported by the US Army Medical Research and Development Command under Contract No.W81XWH-21-C-0001, W81XWH-22-C-0093 and HT9425-23-C-0059. The views, opinions and/or findings contained in this report are those of the author(s) and should not be construed as an official Department of the Army or Navy position, policy or decision unless so designated by other documentation.

#### **ABSTRACT**

This protocol describes feces storage.



Last Modified: Feb 02, 2024

PROTOCOL integer ID: 91112

**Keywords: STORAGE** PROCEDURE FOR UNTREATED SAMPLE, STORAGE PROCEDURE FOR TOTAL NUCLEIC ACID

**Funders Acknowledgement:** 

**USAMRAA** 

Grant ID: HT9425-23-C-0059

**USAMRAA** 

Grant ID: W81XWH-22-C-0093

**USAMRAA** 

Grant ID: W81XWH-21-C-0001

**GUIDELINES** 

### **OBJECTIVE**

To outline steps for properly storing feces samples and nucleic acid samples purified from these samples.

### SUMMARY/SCOPE

The overarching aim of the REDI-NET is to develop a collaborative laboratory network between domestic and international partnering institutions to address disease surveillance needs in order to effectively detect, predict and contain potentially emergent zoonosis. This SOP provides guidance on storage of fecal samples and their purified nucleic acid to preserve their integrity for downstream nucleic acid extraction and/or sequencing library preparation

### MAINTENANCE OF EQUIPMENT

Decontaminate a PCR workstation by keeping the UV light on for 00:15:00





### MATERIALS

## **EQUIPMENT AND MATERIALS**

Note

**NOTE**: If product number is listed, please ensure use of this or equivalent product.

A	В	С
Equipment / Material	Description	Mfg / Product #
−80°C freezer	For sample storage	Locally sourced
Forceps	Clean, stainless	Locally sourced
Ice	To maintain cold chain during sample handling	Locally sourced
96-Well Microfuge tube racks with cover	To hold microplates	Locally sourced
KingFisher™ 96 KF microplate	To store the sample	ThermoFisher, 97002540
PCR Workstation	PCR cabinet with UV light	Locally sourced
Clear Adhesive Film	To seal the KingFisher™ 96 KF microplate	ThermoFisher, 4306311
Adjustable micropipettes	To handle the samples	Locally sourced
Multi-channel micropipettes	8- or 12- channel; to handle the sample	Locally sourced
Nuclease-free filter tips low-retention	To ensure appropriate sample handling	Locally sourced
Nuclease free microfuge tubes	1.5 mL	Locally sourced
Saran wrap	Plastic wrap; to seal rack holding sample	Locally sourced
Permanent markers	To label tubes and microplates	Locally sourced
Data sheet	REDI-NET DCS T-3 Tick Storage	REDI-NET Data Portal

#### SAFETY WARNINGS



### **RISKS AND PERSONAL PROTECTION:**

Gloves should be worn all the time when handling samples.

### STORAGE PROCEDURE FOR UNTREATED SAMPLE

1

#### Note

### NOTES:

- Fecal samples need to be kept on cold chain all the time to prevent RNA degradation. The following procedure will apply only where \$\circ\$ -80 °C storage is feasible.
- If \$\mathbb{E}\$ -80 °C storage is not possible, temporarily store the tick samples in a \$\mathbb{E}\$ -20 °C freezer and follow feces sample processing SOP (REDI-NET SOP F-2 Feces Processing) as soon as possible for total nucleic acid extraction. Subsequently, use a portion of the total nucleic acid and reverse-transcribe RNA into cDNA for \$\mathbb{E}\$ -20 °C storage. To do this, follow the initial steps of the feces sample testing SOP (REDI-NET SOP F-4 Feces Testing) cDNA Synthesis until finishing step 40.

Precool 96-well microfuge tube racks § On ice

- 2 Using preprinted adhesive labels or permanent markers, label 1.5 ml microfuge tubes with unique sample ID.
- Transfer fecal sample into the corresponding pre-labeled 1.5 mL microfuge tubes and put it onto the microfuge tube rack On ice sequentially.
- 4 Once the rack is full or all feces samples have been completed, label the rack with a unique rack ID.
- Close the rack lid tightly, secure with clear Saran wrap and immediately transfer to F-80 °C freezer.

6 Update the freezer inventory so samples can be tracked properly.

## STORAGE PROCEDURE FOR TOTAL NUCLEIC ACID

7



#### Note

### NOTES:

- The following procedure is to properly store total nucleic acid extracted from feces samples (including negative controls) using the KingFisher nucleic acid purification system. The eluted total nucleic acid will be in either 96-well microplate (Flex model) or elution strip (Duo Prime model).
- Total nucleic acid samples need to be kept On ice all the time to minimize RNA degradation.

In the clean PCR workstation, carefully transfer the eluted total nucleic acid to a 96-well PCR microplate, make sure to keep samples in the exact same locations corresponding to the rack where the original blood were stored.

### Note

**IMPORTANT**: Mark the "A1" position of the 96-well microplate to prevent any mistakes on plate orientation.

Oct 2 2024

- 8 Cover the 96-well PCR microplate with adhesive film to prevent spill over or contamination.
- 9 Label the film with a unique plate ID.
- 10 Immediately transfer the 96-well PCR microplate to 3 -80 °C freezer.



11 Update the freezer inventory so samples can be tracked properly.