

CAMbank: cfDNA BCT Field Processing v1

liah G

verbey¹, Krista A Ryon¹, JangKeun Kim¹,

 ${
m hristopher\ E\ Mason^1}$

¹Weill Cornell Medicine

AUG 21, 2023

Eliah G Overbey
Weill Cornell Medicine, BioAstra

ABSTRACT

OPEN ACCESS

Field processing of cfDNA BCTs for the Cornell Aerospace Medicine Biobank (CAMbank).



Instructions for preserving: plasma and RBC Pellets.

MATERIALS

Tube Type: Streck Cell-Free DNA BCT® RUO (Streck: #230470)

Protocol Citation: Eliah G Overbey, Krista A Ryon, JangKeun Kim, Christopher E Mason 2023. CAMbank: cfDNA BCT Field Processing

v1. protocols.io

https://protocols.io/view/cam bank-cfdna-bct-fieldprocessing-v1-cywuxxew

License: This is an open access protocol distributed under the terms of the Creative Commons
Attribution License, which permits unrestricted use, distribution, and reproduction in any medium, provided the original author and source are credited

Protocol status: Working We use this protocol and it's working

Created: Aug 20, 2023

Last Modified: Aug 21,

2023

PROTOCOL integer ID:

86708

Keywords: CAMbank, astronaut, SOMA, cfDNA BCT,

Streck, plasma

Perform Venipuncture

5m

1 After venipuncture, invert the tubes gently 8 to 10 times to fully mix tube anticoagulant with blood sample.

5m

Store the tube upright at room temperature until centrifugation.

Note: The tube stabilizes cell-free DNA for up to 14 days at 6 $^{\circ}$ C to 37 $^{\circ}$ C and CTCs for up to 7 days at 15 $^{\circ}$ C to 30 $^{\circ}$ C.

Centrifuge Settings: Plasma Separation

25m

2 Note: A **swing bucket** centrifuge is required.

Set centrifuge:

acceleration: 9deceleration: 9

temperature: RT

duration: 20 minutes

■ speed: 300xg

22m

3 Place the cfDNA BCTs in the centrifuge.

Place a protective cover over the swing buckets in case of tube leakage.

Start the centrifuge.

Stand by the centrifuge until the centrifuge reaches max speed. Listen for signs of imbalance or compromised tube integrity.

Separate Plasma

7m

4 Carefully remove cfDNA BCTs from the centrifuge and inspect for separation of red blood vs plasma layers.

2m

Transfer cfDNA BCTs to a sanitized laminar flow hood.

5 I

Remove the upper plasma layer and transfer to a new 15mL conical tube. Cap the conical tubes and return to the centrifuge.

5m

Centrifuge Settings: Plasma Purification

15m

6 Note: A **swing bucket** centrifuge is required.

3n

Set centrifuge:

acceleration: 9
deceleration: 9
temperature: RT
duration: 10 minutes

speed: 5000xg

7 Place the conical tubes in the centrifuge.

12m

Place a protective cover over the swing buckets in case of tube leakage.

Start the centrifuge.

Stand by the centrifuge until the centrifuge reaches max speed. Listen for signs of imbalance or compromised tube integrity.

Freeze Red Blood Cell Pellets

5m

8 Recap and freeze the cfDNA tubes to preserve DNA in the red blood cell pellet

5m

Aliquot Plasma

17m

9 Carefully remove conical tubes from centrifuge.

Transfer conical tubes to a sanitized laminar flow hood.

2m

10 Using a P1000, carefully aliquot plasma into 2D barcoded tubes at 500µL each.

Return 2D tubes with plasma to the rack and place in the -80C freezer.

15m