

MAR 22, 2023

OPEN BACCESS

DOI:

dx.doi.org/10.17504/protocol s.io.kqdg39w97g25/v1

External link:

https://www.neb.com/-/media/nebus/files/manuals/m anuale7660.pdf? rev=48c42313dcb64b0dbb1 6c4bfd1563a27

Protocol Citation: Isabel Gautreau, Brianna Stenger 2023. Sequencing SARS-CoV-2 from Animal Samples with NEBNext® ARTIC SARS-CoV-2 Companion Kit . **protocols.io** https://dx.doi.org/10.17504/protocols.io.kqdg39w97g25/v1

License: This is an open access protocol distributed under the terms of the Creative Commons Attribution License, which permits unrestricted use, distribution, and reproduction in any medium, provided the original author and source are credited

Protocol status: Working We use this protocol and it's working

Created: Mar 01, 2023

Last Modified: Mar 22, 2023

Sequencing SARS-CoV-2 from Animal Samples with NEBNext® ARTIC SARS-CoV-2 Companion Kit

Forked from <u>NEBNext® ARTIC SARS-CoV-2 Companion Kit (Oxford Nanopore Technologies®)</u> E7660 -- Express Protocol without PCR Bead Cleanup

Isabel Gautreau¹, Brianna Stenger²

¹New England Biolabs;

²North Dakota State University Veterinary Diagnostic Laboratory

Vet LIRN



megan.miller

DISCLAIMER

DISCLAIMER - FOR INFORMATIONAL PURPOSES ONLY; USE AT YOUR OWN RISK

The protocol content here is for informational purposes only and does not constitute legal, medical, clinical, or safety advice, or otherwise; content added to protocols.io is not peer reviewed and may not have undergone a formal approval of any kind. Information presented in this protocol should not substitute for independent professional judgment, advice, diagnosis, or treatment. Any action you take or refrain from taking using or relying upon the information presented here is strictly at your own risk. You agree that neither the Company nor any of the authors, contributors, administrators, or anyone else associated with protocols.io, can be held responsible for your use of the information contained in or linked to this protocol or any of our Sites/Apps and Services.

PROTOCOL integer ID: 77892

ABSTRACT

Keywords: NEBNext, NEB, ARTIC, SARS-CoV-2, Oxford,

Nanopore, Flongle

This protocol is adapted for animal samples and is based on the methods for the NEBNext® ARTIC SARS-CoV-2 Companion Kit (Oxford Nanopore Technologies®), NEB #E7660S/L 24/96 reactions.

This protocol does not include a cleanup and normalization step for each sample after cDNA synthesis. Performing the cleanup and normalization step creates library pools where the reads for each library are more evenly distributed. Skipping these steps reduces hands on time but may require a longer sequencing run to obtain sufficient coverage for each sample. To obtain more even sample to sample coverage, we recommend normalizing the RNA samples prior to starting the protocol.

Changes in this version:

- Removal of the human primers
- Combining multiple barcoding reactions (step 15 and 21)
- Addition of Loading Flongle Flow Cell section
- Addition of Analysis section

GUIDELINES


Overview

The NEBNext ARTIC SARS-CoV-2 Companion Library Prep Kit (Oxford Nanopore Technologies) contains the enzymes, buffers, beads and oligos required to convert a broad range of total RNA input amounts into targeted, high quality libraries for next-generation sequencing on the Oxford Nanopore platform. Primers targeting the human EDF1 and NEDD8 genes are supplied as optional internal controls. The fast, user-friendly workflow also has minimal hands-on time.

Each kit component must pass rigorous quality control standards, and for each new lot the entire set of reagents is functionally validated together by construction and sequencing of an indexed library on the Oxford Nanopore sequencing platform.

For larger volume requirements, customized and bulk packaging is available by purchasing through the OEM/Bulks department at NEB. Please contact OEM@neb.com for further information.

Figure 1. Workflow demonstrating the use of NEBNext ARTIC SARS-CoV-2 Companion Library Prep Kit for Oxford Nanopore.



MATERIALS

The Library Kit Includes

The volumes provided are sufficient for preparation of up to 24 barcoding reactions (NEB #E7660S, minimum 6 barcoding samples per run for total 4 runs) and 96 barcoding reactions (NEB #E7660L, minimum 24 barcoding samples per run for total 4 runs). If one plans to follow a different protocol, additional reagents can be purchased separately).

Package 1: Store at -20°C.

(lilac) LunaScript® RT SuperMix

(lilac) Q5® Hot Start High-Fidelity 2X Master Mix

(green) NEBNext Ultra II End Prep Enzyme Mix

(green) NEBNext Ultra II End Prep Reaction Buffer

(red) Blunt/TA Ligase Master Mix

(red) NEBNext Quick T4 Ligase

(red) NEBNext Quick Ligation Reaction Buffer

(lilac) NEBNext ARTIC SARS-CoV-2 Primer Mix 1

(lilac) NEBNext ARTIC SARS-CoV-2 Primer Mix 2

(white) Nuclease-free water

Package 2: Store at room temperature. Do not freeze.

NEBNext Sample Purification Beads

Required Materials Not Included

- 80% Ethanol (freshly prepared)
- DNA LoBind Tubes (Eppendorf® #022431021)
- Oxford Nanopore Technologies Native Barcoding Expansion kits 1-12 (EXP-NBD104) and 13-24 (EXP-NBD114)
- Oxford Nanopore Technologies Ligation Sequencing Kit (SQK-LSK109)
- Oxford Nanopore Technologies SFB Expansion Kit (EXP-SFB001)
- Qubit[®] dsDNA HS Assay Kit (Thermo Fisher Scientific, Inc.[®] Q32851)
- Magnetic rack/stand (NEB #S1515, Alpaqua[®], cat. #A001322 or equivalent)
- Thermal cycler
- Vortex Mixer
- Microcentrifuge
- Agilent[®] Bioanalyzer[®] or similar fragment analyzer and associated consumables (#4150 or #4200 TapeStation System)
- DNase RNase free PCR strip tubes (USA Scientific 1402-1708)
- 1.5 ml tube magnet stand (NEB #S1506)

Kit Components

NEB #E7660S Table of Components

A	В	С
NEB#	PRODUCT	VOLUME
E7651A	LunaScript RT SuperMix	0.048 ml
E7652A	Q5 Hot Start High-Fidelity 2X Master Mix	0.30 ml
E7661A	NEBNext Ultra II End Prep Enzyme Mix	0.018 ml
E7662A	NEBNext Ultra II End Prep Reaction Buffer	0.042 ml
E7663A	Blunt/TA Ligase Master Mix	0.24 ml
E7664A	NEBNext Quick T4 DNA Ligase	0.020 ml
E7665A	NEBNext Quick Ligation Reaction Buffer	0.040 ml
E7725A	NEBNext ARTIC SARS-CoV-2 Primer Mix 1	0.042 ml
E7726A	NEBNext ARTIC SARS-CoV-2 Primer Mix 2	0.042 ml
E7727A	NEBNext ARTIC Human Control Primer Pairs	0.007 ml

A	,	В	С
E	7728A	NEBNext ARTIC Human Control Primer Pairs 2	0.007 ml
E	7667A	Nuclease free-Water	1.50 ml
E	7666S	NEBNext Sample Purification Beads	0.872 ml

NEB #E7660L Table of Components

A	В	С
NEB#	PRODUCT	VOLUME
E7651AA	LunaScript RT SuperMix	0.192 ml
E7652AA	Q5 Hot Start High-Fidelity 2X Master Mix	1.2 ml
E7661AA	NEBNext Ultra II End Prep Enzyme Mix	0.072 ml
E7662AA	NEBNext Ultra II End Prep Reaction Buffer	0.168 ml
E7663AA	Blunt/TA Ligase Master Mix	0.96 ml
E7664A	NEBNext Quick T4 DNA Ligase	0.020 ml
E7665A	NEBNext Quick Ligation Reaction Buffer	0.040 ml
E7725AA	NEBNext ARTIC SARS-CoV-2 Primer Mix 1	0.168 ml
E7726AA	NEBNext ARTIC SARS-CoV-2 Primer Mix 2	0.168 ml
E7727A	NEBNext ARTIC Human Control Primer Pairs	0.007 ml
E7728A	NEBNext ARTIC Human Control Primer Pairs 2	0.007 ml
E7667AA	Nuclease free-Water	4.7 ml
E7666L	NEBNext Sample Purification Beads	2.90 ml

NEBNext ARTIC SARS-CoV-2 Primers

NEBNext ARTIC SARS-CoV-2 Primers for SARS-CoV-2 genome amplification are based on hCoV-2019/nCoV-2019 Version 3 (v3) sequences with balanced primer concentrations. Sequence information can be found at:

 $\frac{https://github.com/joshquick/artic-ncov2019/blob/master/primer_schemes/nCoV-2019/V3/nCoV-2019.tsv}{}$

•

Please refer to Safety Data Sheets (SDS) for health and environmental hazards.

This product is intended for research purposes only. This product is not intended to be used for therapeutic or diagnostic purposes in humans or animals.

BEFORE START INSTRUCTIONS

Note: The amount of RNA required for detection depends on the abundance of the RNA of interest. In general, we recommend, using > 10 copies of the (SARS-CoV-2) viral genome as input. In addition, we recommend setting up a no template control reaction and **all reactions are set-up in a hood**.

Note: : If sample Ct is between 12-15, then it is recommended per the <u>nCoV 2019</u> sequencing protocol v3 LoCost to dilute the sample 100-fold in water, if between 15-18 then dilute 10-fold in water. This will reduce the likelihood of PCR inhibition.

cDNA Synthesis



The presence of genomic DNA or carry-over products can interfere with sequencing accuracy, particularly for low copy targets. Therefore, it is important to carry out the appropriate no template control (NTC) reactions to demonstrate that positive reactions are meaningful.

2 Gently mix 10 times by pipetting and spin down the LunaScript RT SuperMix reagents (contains primers). Prepare the cDNA synthesis reaction as described below:

А	В
COMPONENT	VOLUME
RNA Sample*	8 µl
(lilac) LunaScript RT SuperMix	2 μΙ
Total Volume	10 μΙ

^{*}Up to 0.5 µg total RNA can be used in a 10 µl reaction.

3 Flick the tube or pipet up and down 10 times to mix followed by a quick spin.



For no template controls, mix the following components:



A	В
COMPONENT	VOLUME
(white) Nuclease-free Water	8 µI
(lilac) LunaScript RT SuperMix	2 μΙ
Total Volume	10 μΙ

5 Flick the tube or pipet up and down 10 times to mix followed by a quick spin.



Incubate reactions in a thermocycler with lid temperature at 105°C with the following steps:





A	В	С	D
CYCLE STEP	TEMP	TIME	CYCLE
Primer Annealing	25°C	2 minutes	
cDNA Synthesis	55°C	20 minutes	1
Heat Inactivation	95°C	1 minute	

Note

Samples can be stored at \$ -20 °C if they are not used immediately.

Targeted cDNA Amplification



We recommend setting up the cDNA synthesis and cDNA amplification reactions in different rooms to minimize cross-contamination of future reactions.

Gently mix Q5 Hot Start High Fidelity 2X Master Mix 10 times by pipetting and spin down reagents. Prepare the split pool amplification reactions as described below:

For Pool Set A: .

A	В
COMPONENT	VOLUME
cDNA (Step 6)	4.5 µl
(lilac) Q5 Hot Start High-Fidelity 2X Master Mix	6.25 µl
NEBNext ARTIC SARS-CoV-2 Primer Mix 1*	1.75 µl
Total Volume	12.5 µl

For Pool Set B:

A	В
COMPONENT	VOLUME
cDNA (Step 6)	4.5 µl
(lilac) Q5 Hot Start High-Fidelity 2X MM	6.25 µl
NEBNext ARTIC SARS-CoV-2 Primer Mix 2*	1.75 µl
Total Volume	12.5 µl

8 Flick the tubes or pipet up and down 10 times to mix followed by a quick spin.

9 Incubate reactions in a thermocycler** with the following steps:



Α	В	С	D
CYCLE STEP	TEMP	TIME	CYCLES

A	В	С	D	
Initial Denaturation	98°C	30 seconds	1	
Denature	95°C	15 seconds	25	
Annealing/Extension	63°C*	5 minutes	35	
Hold	4°C	∞	1	

^{*} It is very important to set up the annealing and extension temperature to 63°C

Samples can be stored at 4 -20 °C if they are not used immediately.

PCR Reaction Pooling

10

Note

Please note, there is also a protocol that includes a cleanup and normalization step at this point. Performing the cleanup and normalization step creates library pools where the reads for each library are more evenly distributed. These pools will likely achieve sufficient coverage in less run time.

11 For each sample, combine pool A and pool B PCR Reactions.

Note

Samples can be stored at [8 -20 °C] if they are not used immediately.

NEBNext End Prep

Add the following components to a PCR tube (End Prep Reaction and Buffer can be pre-mixed and master mix is stable On ice for 4 hours):



12

^{**} Set heated lid to 105°C.

A	В
COMPONENT	VOLUME
Targeted cDNA Amplicons (Step 11)	1 µl
(white) Nuclease-free water	11.5 µl
(green) NEBNext Ultra II End Prep Reaction Buffer	1.75 μΙ
(green) NEBNext Ultra II End Prep Enzyme Mix	0.75 μΙ
Total Volume	15 µl

13

Flick the tube or pipet up and down 10 times to mix the solution. Perform a quick spin to collect all liquid from the sides of the tube.



Note

It is important to mix well. The presence of a small amount of bubbles will not interfere with performance.

14 Place in a thermocycler, with the heated lid set to $\geq 75^{\circ}$ C, and run the following program:





Note

Barcode Ligation

15 Add the following components directly to a sterile nuclease-free PCR tube:



A	В
COMPONENT	VOLUME
	single

protocols.io |

20m

A	В
(white) Nuclease-free water	6 µl
End-prepped DNA (Previous Step)	1.5 µl
Native Barcode*	2.5 µl
(red) Blunt/TA Ligase Master Mix**	10 µl
Total	20 µl***

- * Native Barcodes are provided in Oxford Nanopore Technologies Native Barcoding Expansion 1-12 (EXP-NBD104) and 13-24 (EXP-NBD114) or 1-96 (EXP-NBD196)
- ** Mix the Blunt/TA Ligase Master Mix by pipetting up and down several times prior to adding to the reaction.
- *** Multiple ligation reactions for a sample with the same barcode can be pooled (see #21) to increase the amount of product for cleanup. Recommend separate tubes for individual 20uL reactions and then combine in step 21. Unsure how a 40uL reaction will respond to the cycling conditions.

16



Flick the tube or pipet up and down 10 times to mix solution. Perform a quick spin to collect all liquid from the sides of the tube.

Note

Caution: The Blunt/TA Ligase Master Mix is very viscous. Care should be taken to ensure adequate mixing of the ligation reaction, as incomplete mixing will result in reduced ligation efficiency. The presence of a small amount of bubbles will not interfere with performance.

17



Incubate at \$\ 25 \circ for \ 00:20:00 \ .

Incubate at \$\ 65 \circ for \ 00:10:00 \ .

Place \$\ 0n ice for \ 00:01:00 \ .

Pool all barcoded samples into one 1.5 ml DNA LoBind Tube.

Cleanup of Barcoded DNA

21m

Note: Use the pooled barcoded DNA samples (from previous step), up to 480 μ l for bead cleanup. Remaining pooled DNA can be stored at \$\\ \begin{array}{c} -20 \cdot \mathbb{C} \end{array}\$.

- Vortex NEBNext Sample Purification Beads to resuspend.
- 21 Add 0.4X resuspended beads to pooled, barcoded samples (Step 20)



There is a maximum of 480uL of pooled samples. So multiple barcoded samples can be pooled. As an example, for seven samples, including four duplicated samples:

40+40+40+20+20+20uL = 220 μL with 88 μL of resuspended Sample Purification beads

Mix well by flicking the tube or pipetting up and down 10 times. Perform a quick spin for 00:00:01 to collect all liquid from the sides of the tube.

22 Incubate samples on bench top for 00:10:00 at 8 Room temperature

10m

- Place the tube on a 1.5 ml magnetic stand (such as NEB S1506) to separate the beads from the supernatant. If necessary, quickly spin the sample to collect the liquid from the sides of the tube or plate wells before placing on the magnetic stand.
- After 00:03:00 (or when the solution is clear), carefully remove and discard the supernatant.

 Be careful not to disturb the beads that contain DNA targets.

3m

Note

Caution: do not discard the beads.

- to colle
- Place the tube on an appropriate magnetic stand for 00:03:00 3 minutes (or until the solution is clear) to separate the beads from the supernatant. Remove the supernatant.

3m

27 Repeat Step 26 and 27 once for a total of two washes:

3m 3s



Be sure to remove all visible liquid after the second wash. If necessary, briefly spin the tube, place back on the magnetic stand and remove traces of SFB with a p10 pipette tip.

Add \perp 500 µL 80% freshly prepared ethanol to the tube while on the magnetic stand. Incubate at \parallel Room temperature for \bigcirc 00:00:30 , and then carefully remove and discard the supernatant. Be careful not to disturb the beads that contain DNA targets.

30s

29

Repeat the previous step once to make it a total of 2 washes.

- Perform a quick spin and place the sample tube on the magnetic stand, remove any residual ethanol.
- Air dry the beads for 00:00:30 while the tube is on the magnetic stand with the lid open.


30s

Remove the tube from the magnetic stand. Elute the DNA target from the beads by adding




 \perp 33 µL Nuclease-free water

Resuspend the pellet by flicking the tube or pipetting up and down 10 times to mix. Incubate for at least 2 minutes at Room temperature. If necessary, quickly spin the sample for



Place the tube on the magnetic stand. After 2 minutes (or when the solution is clear), transfer A 32 µL to a new 1.5 ml Eppendorf DNA LoBind Tube or PCR tube.



It is also recommend using a Qubit fluorometer for concentration assessment. (Nanodrop is **NOT** recommended since it may overestimate the DNA concentration).

Samples can be stored at \$\ \bigs_{-20 \circ}\$ if they are not used immediately.

Adapter Ligation

Use the Qubit readings from the previous Step to dilute purified Native barcoded DNA pool in nuclease-free water. Dilute the sample to a concentration of 60 ng total in a final volume of 30 μ l (or 2 ng/ μ l in 30 μ l). Add the following components into a 1.5 ml Eppendorf DNA LoBind Tube or

36

Note

nuclease-free PCR tube:

A	В
COMPONENT	VOLUME
Native barcoded and purified DNA (Step 35, up to 60 ng)	30 µl
(red) NEBNext Quick Ligation Reaction Buffer *	10 µl
Adapter Mix II (AMII)**	5 µl
(red) NEBNext Quick T4 Ligase	5 µl
Total Volume	50 µl

- * Mix the NEBNext Quick Ligation Reaction Buffer by pipetting up and down several times prior to adding to the reaction.
- ** Adapter Mix II is provided by Oxford Nanopore Technologies Native Barcoding Expansion 1-12 (EXP-NBD104), 13-24 (EXP-NBD114) and 1-96 (EXP-NBD-196) kits.

Flick the tube to mix solution. Perform a quick spin for 00:00:01 to collect all liquid from



Note

the sides of the tube.

Caution: The NEBNext Quick Ligation Buffer is viscous. Care should be taken to ensure adequate mixing of the ligation reaction, as incomplete mixing will result in reduced ligation efficiency. The presence of a small amount of bubbles will not interfere with performance.

38 Incubate at 3 25 °C for 00:20:00

20m

39 Proceed to Cleanup of Adapter-ligated DNA in the next section.

Cleanup of Adapter Ligated DNA

20m 3s

Vortex NEBNext Sample Purification Beads to resuspend.

41

Add \perp 50 μ L (1X) resuspended beads to the ligation mix. Mix well by flicking the tube followed by a quick spin for (5) 00:00:03



42 Incubate samples for (5) 00:10:00 at Room temperature




- - 43 Place the tube on an appropriate magnetic stand to separate the beads from the supernatant. If necessary, quickly spin the sample to collect the liquid from the sides of the tube or plate wells before placing on the magnetic stand.
 - 44 After 3 minutes (or when the solution is clear), carefully remove and discard the supernatant. Be careful not to disturb the beads that contain DNA targets.

Note

Caution: do not discard the beads.

45 Wash the beads by adding 🚨 250 µL Short Fragment Buffer (SFB) . Flick the tube to



46 Wait for 00:03:00 (or until the solution is clear) to separate the beads from the supernatant. Remove the supernatant.

3m

- 47
- Repeat Step 46 and 47 once for a total of two washes:

Wash the beads by adding 🚨 250 µL Short Fragment Buffer (SFB) . Flick the tube or pipet up and down to mix to resuspend pellet. If necessary, quickly spin the sample to collect the liquid from the sides of the tube or plate wells before placing back on the magnetic stand. Place the tube on

an appropriate magnetic stand.

Wait for 3 minutes (or when the solution is clear) to separate the beads from the supernatant. Remove the supernatant.

Be sure to remove all visible liquid after the second wash. If necessary, briefly spin the tube/plate, place back on the magnet and remove traces of SFB with a p10 pipette tip.

48

Remove the tube from the magnetic stand. Elute the DNA target from the beads by adding \pm 15 μ L Elution Buffer (EB) provided in SQK-LSK109 kit from Oxford Nanopore.



Resuspend the pellet well in EB buffer **by flicking**. Incubate for 00:10:00 at





Room temperature. If necessary, quickly spin the sample to collect the liquid from the sides of the tube or plate wells before placing back on the magnetic stand.

50

Place the tube/plate on the magnetic stand. After \bigcirc 00:03:00 (or when the solution is clear), transfer \bot 15 µL to a new DNA LoBind tube.

3m



Determine DNA concentration by quantifying 🗸 1 µL DNA sample



51

Loading Flongle Flow Cell

- Follow Oxford Nanopore Protocol SQK-LSK109 to prepare MinION[®] flow cell and DNA library sequencing mix using up to 20 ng adapter-ligated DNA sample (previous step).
- 52.1 Combine \underline{L} 117 μL of Flush Buffer + \underline{L} 3 μL Flush Tether in a LoBind tube and mix by pipetting

- **52.2** Prime the flongle flow cell by slowly pipetting the majority of the previous mix, avoid pushing too fast and bubbles

Based on what ONT recommends load \sim 20fmol of the adapter-ligated final pooled library on a flongle flow cell

52.4 Load ~30uL on the flongle flow cell, avoid bubbles.

Analysis

53

Used the EPI2ME Fastq + ARTIC + NextClade workflow for analyses.

Note

Raw files can be retrieved from MinKNOW and put through other pipelines.