
Pin Assignment



GND 19 GND GND 18 GND GPI01 17 3 GPIO₂ AREF/GPIO0 **GPIO3** 16 **FACTORY** GPIO4 15 RESET 14 GPIO5 13 +3V GPIO6 12 8 GND GND **EXT ANT (RFD22302)** 11 10 GND GND pins 1, 2, 8, Antenna Area 9 GND 9, 10, 18 and 19 are optional.