

2nd Proof

- ☐ APPROVED AS IS
☐ APPROVED WITH
CHANGES INDICATED

BY _____ DATE _____

85462-1238

~~TRS-80~~ *2*

Tandy 1000 Computer ~~Model XXX Portable Computer~~ *2*

WORKSTATION
Quick Reference Guide

Tandy Workstation™ Program:
© 1984 Microsoft Corp.
Licensed to Tandy Corporation
All Rights Reserved

Tandy Workstation™ Quick Reference Guide:
© 1984 Tandy Corporation
All Rights Reserved

Reproduction or use, without express written permission from Tandy Corporation, of any portion of this manual is prohibited. While reasonable efforts have been taken in the preparation of this manual to assure its accuracy, Tandy Corporation assumes no liability resulting from any errors or omissions in this manual, or from the use of the information contained herein.

10 9 8 7 6 5 4 3 2 1

GENERAL KEY USAGE

All Applications:

BACKSPACE	Backspaces; deletes character in front of marker
ALT	Toggles Subfunction label line on and off
END	Saves all data entered; exits to previous operation or menu
SHIFT F12	Cancels changes; returns to Main Menu (Text and Worksheet only)
BREAK	Cancels current request, prompt, or command
SHIFT F8/F9/F10	Prints everything on screen
ALT F1-F9	Selects desired subfunction

preceding the

Within an Application:

↑	Moves marker to previous line
↓	Moves marker to next line
←	Moves marker left one position
→	Moves marker right one position
SHIFT ↑	Moves marker to top line of screen
SHIFT ↓	Moves marker to bottom line of screen
SHIFT ←	Moves marker to left margin of screen
SHIFT →	Moves marker to right margin of screen
CTRL ↑	Displays first item in file
CTRL ↓	Displays last item in file
CTRL ←	Displays previous item in file
CTRL →	Displays next item in file

Q1—Q9 Selects desired function in application

Note: Arrow key usage may vary slightly in some applications. See the sections in the *Reference Manual* describing specific applications for exceptions to these key usages.

SUBFUNCTIONS

Help	Displays reference information on current application.
Calc	Displays Calculator mini-screen. Type each operand and operator (or choose operator from function line), and press ENTER .
Show Alarm	Displays previous and next Alarm events.
Alarm On/Off	Turns Alarm function on and off.
Phone	Displays Phone list. Enter up to 79 phone entries consisting of initials, names (last name first), and phone numbers (area code, then number).

ENTER **CD** to enter area code (Acode) and Prefix codes (1-3) for special codes to precede phone numbers. Phone functions are:

Find — Enter characters for which to search, then **CD** to find first match.

Call — Dials number at current marker position. Area code dialed only if different from local area code. All marked prefix codes are dialed (1, 2, 3 order).

Prefix1 — Marks and unmarks Prefix1 to be dialed before phone number.

Prefix2 — Marks and unmarks Prefix2 to be dialed before phone number.

Prefix3 — Marks and unmarks Prefix3 to be dialed before phone number.

Sort — Sorts entries alphabetically, according to first field entered.

Print — Prints phone list. First, check printer settings.

Delete — Clears data on current phone entry line.

Add — Displays blank line for adding new phone entry.

Printer Displays Printer Settings screen. Change or keep following default settings before printing:

Left Margin: 25

Printed Line Width: 70

Total Lines per Page: 66

Printed Lines per Page: 60

Pause between Pages (Y/N): N

Date Changes system date and time.
Date format — mm/dd/yyyy.
Time format — hh:mm(a or p).

MAIN MENU

- Date** Changes system date and time.
Format: mm/dd/yyyy hh:mm(a or p).
- Name** Renames file. Enter old name of file (or **ENTERED** for file under marker), then enter new name for file.
- Free** Displays amount of free space on current diskette.
- Alarm** Displays Alarm screen. On blank line, enter Remind@ time, Date, Begin and End times, and Description for each Alarm event. Alarm functions are:
- Merge** — Merges a Calendar file into Alarm file. Enter Calendar filename.
 - Select** — Defines block of events. Place marker on first event of block; Select, then move marker to last event of block. Copy or Delete block.
 - Copy** — Copies selected event block to a new Text file on disk. Enter Text filename.
 - Delete** — Events Selected: Deletes event block. No Events Selected: Deletes current event line.
 - Add** — Displays blank line for adding new event. Enter event Remind@ time, Date, Begin and End times, and Description.
- Host** Places Workstation in Host mode for remote job entry. Host computer can choose to use or not use security option. Remote-site computer can use the following functions:
- DIRECTORY** — Lists six options. Choose one file type, or press **Q** to see All Workstation files.
 - Read File From Host** — Retrieves file from Host. Enter filename. Follow directions on screen.
 - Send File To Host** — Sends file to Host. Enter filename. Follow directions on screen.

Read Mail -- Displays list of messages from Mail file. Type appropriate letter to read message contents. Press **(ENTER)** to view additional Read Mail screen. Press **(EXIT) (Q)** to return to REMOTE MENU.

Send Mail -- Places messages in Mail file. Enter Mail filename. Enter From and Description data. Type message, press **(EXIT) (Q)** to return to REMOTE MENU.

Disconnect From Host -- Ends hookup to Host Workstation.

Passwd Assigns password for restricting access to Workstation and Host. Enter password of up to 8 characters.

Select Defines more than one file for deletion.

Copy Duplicates selected file. Enter names for file from which to copy (or **(ENTER)** for file under marker) and for new file to which you are copying.

Delete Files Selected: Deletes selected files. **(ENTER)** to delete selected files.

No Files Selected: Deletes file. Enter name of file to delete, or **(ENTER)** for file under marker.

Swap Changes diskettes. Enter drive number for ~~swap~~. Change diskettes; press any key to continue.

TEXT

Find	Finds specific string. Enter text for which to search. Marker moves to first match.
Print	Prints text. First, check printer settings.
Add/Replace	Switches between Add mode (inserting characters) and Replace mode (replacing existing characters).
Format	Changes line width of displayed text. Enter new line width.
Merge	Merges another Text file into current document. Move marker to desired insert location; Merge, then enter name of file to merge.
Save	Stores document in its current form. Enter new name for file or ENTERED to save to current file.
Select	Defines text block. Place marker on first character of block; Select, then move marker to last character of block. Copy or Delete block.
Copy	Text Selected: Copies selected block to copy buffer. Insert the text at another location within document, or Copy again to copy buffer contents on disk. Enter new filename for copy buffer save. No Text Selected: Loads file from disk to copy buffer. Enter name of file to load. Position-marker; Insert new text into document.
Substitute	Finds and replaces specific text. Enter text for which to search and text to use as replacement. Marker moves to first match; press ENTER to replace string, ENTER to skip to next match.
Insert	Inserts copy buffer contents at current marker location.
DELETE	Text Selected: Deletes text block from document. No Text Selected: Deletes character under marker.

WORKSHEET

Functions:

Find Finds specific string or cell. Enter string for which to search or cell location (R#C#).

Calc Calculates and displays computed results. Enter any constants when prompted.

Formula Defines formula for cell or all selected cells. Use the following operators and functions:

- + Addition
- Subtraction
- * Multiplication
- / Division
- ! Power
- () Priority operation
- AVG Average of values
- MAX Maximum value
- MIN Minimum value
- SUM Sum of values
- CMT Column summation
- RMT Row summation
- ABS Absolute Value
- ATN Arctangent
- COS Cosine
- EXP Exponential
- INT Integer Truncation
- LOG Logarithm
- SGN Sign
- SIN Sine
- SQR Square Root
- TAN Tangent

Special formula symbols:

? — Indicates constant to be entered during calculation.

— Precedes cell location to mark it as "direct reference" for formula (does not change to current row or column when entered in more than one cell).

Text	Defines selected block of cells as text area. Select block, then Text. Type text, then BREAK to exit. Text editing functions include: CHDEL CHDEL — Deletes character in front of cursor. CHDEL CD — Deletes text from cursor to beginning of next word. CHDEL CD — Deletes text from cursor to end of text block. UNED — Cancels selection of newly marked block as text area; undoes changes to old text block; exits Text.
Format	Changes format or width for cell or selected cells. Cell: Default is \$. Format indicators are: L — Left justification R — Right justification D — Decimal format (enter number of decimal places) I — Integer format \$ — Dollar format (two decimal places) Column: CHCD CD to move to Column Label area. Change all columns (ALL,width), a specific column (Cnumber,width), or current column (width).
Merge	Cells Selected: Saves selected area to Worksheet file. Enter save filename. No Cells Selected: Loads and inserts Worksheet file at current marker location. Enter filename.
Select	Defines block of cells on which to perform another function. Place marker on first cell of block; Select, then use arrow keys to highlight block. Use Formula, Text, Format, Merge, Copy, or Delete.

- Copy** Copies cell or selected block to copy buffer. Insert block at another location, or Copy again to save contents of copy buffer on disk as new Text file. Enter Text filename.
- Delete** Cells: Deletes cell or selected block.

Row or Column Label: Deletes all data (except text) in row or column under marker. All following rows or columns, formulas, and text are adjusted.
- Insert** Cells: Inserts copy buffer contents at current marker location.

Row or Column Label: Inserts a new row or column at current marker location. All following rows or columns, formulas, and text are adjusted.
- Print** Prints selected area or current window. First, check printer settings.

FILER

Form:

Automatic if new file. Enter up to 21 lines of fields.
Type Label for each field, press **ENTER**. Press
ENTER twice to fill rest of line with dots or type dots
to specify field length (edit characters optional), press
ENTER. Form functions are:

Order Identifies field as sort "key." Press priority
number or **ENTER** for next available
number. Priority fields sort first; other
fields in order of appearance.

Back
Reform *Reforms*
Backs data in file after changing form or
deleting records; improves efficiency of
file.

Number Right justifies data in field.

Delete Label Area: Deletes label under marker
and associated data field.

Field Area: Deletes character under
marker.

Add Label Area: Inserts blank line at current
marker position.

Field Area: Inserts blank character at
current marker position.

After form setup, **END** to exit. Enter data on blank
form.

Find Finds specific data in file. Choose
relationship (default is Equal), and enter
data for which to search in appropriate
fields. **END** to start search. Find functions
are:

Equal — Specifies match Equal to Find
criteria.

Greater — Specifies match Greater than
or equal to Find criteria.

Less — Specifies match Less than or
equal to Find criteria.

Reset — Resets Find criteria.

Mark — Switches between marking and unmarking fields to Display or Print. Default is marked; * displays in Label area.

Special Find indicators are:

? — Ignores character in this position.

* — Ignores all characters preceding or following.

Call	Dials phone number under marker, using current Phone and Telecom voice dialing information.
Display	Displays, in horizontal format, all records matching current Find criteria.
Print	Prints all records matching current Find criteria. First, check printer settings.
Form	Displays Form screen. Change form if desired, then use Pack.
Merge	Merges another Filer file with same form into current file. Move marker to desired insert location; Merge, then enter filename to merge.
Select	Defines data in record for copying to Text file. Place marker on first data field of block; Select, then move marker to last field. Copy data block.
Copy	Copies selected data to a new Text file on disk. Enter Text filename.
Delete	Deletes currently displayed record.
Add	Displays blank form for adding new record.

TELECOM

- Reset** Changes parameters back to original settings (for Modem II-8).
- Select** Changes parameter to setting under the marker. Can also place marker on new setting; press **ENTERED** to select it.

If you select Yes for Auto Dialing Modem, define the following modem protocol (default modem definitions for Modem II-b):

- Voice** Selects voice dialing definition function. Voice dialing definition functions are:
- Number** — Sends phone number to modem.
 - Receive** — Receives text from modem. Enter text.
 - Send** — Sends text to modem. Enter text.
 - Pause** — Pauses during dialing sequence. Enter number of seconds to pause.
 - WaitNC** — Waits for No Carrier detect before continuing.
 - WaitC** — Waits for Carrier detect before continuing.
 - Delete** — Deletes line under marker.
 - Insert** — Inserts blank line under marker.
- Comp** Selects computer dialing definition function. Functions same as Voice dialing definition functions.
- Answer** Selects answer mode definition function. Functions same as above except no Number function.
- Autolog** Executes an autolog file. **ENTERED** for current autolog file, or enter name of another file.

Editlog Displays Editlog screen. Enter name of autolog file you are creating or editing. Use functions to create logon sequence, entering responses/prompts appropriate to Host. Editlog functions are:

Status — Displays Status screen. Set parameters; press **(F12)** to return.

Call — Places phone number in autolog sequence. Type number; select another function to end number.

Receive — Specifies response from Host. Type text, including any control codes; select another function to end prompt.

Send — Specifies response to Host prompt. Type text, including any control codes; select another function to end response.

Pause — Places pause in autolog sequence. Type number of seconds to pause; select another function to continue.

WaitNC — Waits for No Carrier detected before continuing rest of autolog sequence.

WaitC — Waits for Carrier detected before continuing rest of autolog sequence.

Delete — Deletes sequence item at current marker position.

Insert — Inserts blank line for adding new sequence item at current marker position.

(F12) to save completed autolog sequence; returns to original Status screen.

Term Enters interactive terminal mode. Term functions are:

Buffer — Opens/closes RAM buffer in which to capture text from Host, appending it to current buffer contents.

Clear — Empties RAM buffer.

Receive — Downloads file from Host.
Enter filename.

Send — Uploads, or sends, disk file to
Host. Enter filename.

Printer — Switches printer option on/off.
When on, text from Host is sent to printer
and screen.

Break — Generates Break sequence
(250ms null).

Disc — Disconnects phone line (on-
hook).

Call — Autodial phone number. Type
dialing sequence.

END to return to original Status screen.

RAM buffer-related functions on Status screen:

Clear — Empties RAM buffer.

Save — Saves contents of RAM buffer on disk as
Text file. Enter Text filename.

Print — Prints contents of RAM buffer.

Load — Loads file from disk to RAM buffer. Enter
filename.

Display — Displays contents of RAM buffer.

CALENDAR

Find Finds specific event(s). Choose relationship (default is Equal), and enter data for which to search in appropriate fields. **F10** to start search. Find functions are:

Equal — Specifies match Equal to Find criteria.

Greater — Specifies match Greater than or equal to Find criteria.

Less — Specifies match Less than or equal to Find criteria.

Reset — Resets Find criteria.

Special Find indicators are:

? — Ignores character in this position.

***** — Ignores all characters preceding or following.

Date Sets Calendar to specific date. Enter date in mm/dd/yyyy format. Displays month, week, and daily events for date entered.

Print Prints all events of current date or those matching Find criteria. First, check printer settings.

Alarm Copies and places all selected events into Alarm file. Alarm time is set for 30 minutes prior to event begin time.

Merge Events Selected: Merges all selected events into another Calendar file. Enter filename.

No Events Selected: Merges another Calendar file into current file. Enter filename.

Select Defines block of events on which to perform another function. Place marker on first event; **Select**, then move marker to last event. Then use Alarm, Merge, Copy, or Delete.

Copy Copies all selected events to copy buffer. Copy again to save copy buffer contents to new Text file on disk. Enter Text filename.

- Delete** Deletes all selected events or event under marker if none selected.
- Add** Displays blank line for adding new event.
Enter Date (**ENTER**) for current date).
Begin and End times, in HH:MM(a or p)
format, and Description.

MAIL

- Find** Finds specific message(s). Enter From, Date, and/or Description data for which to search. **(ENTER)** to skip fields. Displays all messages matching search criteria. **(EXIT)** to return to original Message Listing screen.
- Create** Displays Create Mail screen. Enter From, Description, and To data for message. **(ENTER)** to skip To and save to current file. Text screen displays for message entry. Type message, using Text functions. **(EXIT)** when finished.
- Display** Displays message under marker. If edit message, creates new, updated message. **(EXIT)** to exit.
- Print** Prints message under marker. First, check printer settings.
- Delete** Deletes message under marker.