

The Tandy® Z-PDA™

Zoomer Personal Digital Assistant

Try out the new technology that's as easy as pen and paper... with the logic power of a computer and the ability to connect to the world!


Startup

1. Open the Z-PDA by simply pulling down the cover latch and flipping the cover up and over the back of the unit—it folds completely out of the way.
2. You'll notice that there's not a traditional keyboard. At the lower-right corner of the unit, you'll find the socket where the telescoping pen is stored—you'll use this pen to interact with the Z-PDA's screen.
3. Turn the Z-PDA on by pulling down the spring-loaded on/off switch on the *right* side of the unit.
4. You're ready to go!

Using the Icons and Applications

1. First, try the "Notebook" function. To select Notebook, use the pen to tap its "Fixed Icon" at the bottom of the screen. The Notebook icon is fourth from the left.
2. A display will come up showing available pages. Tap one of the page numbers to access a blank page—when it comes up, you can use the pen to make notes.


Fixed Icons



3. Tap the Ink Input icon and you're ready to write. Jot a phone number, draw a map or make a note. PowerInk™ technology saves your information exactly as you write it, in your own handwriting.
4. If you would like to enter "formal" text, tap the Text Input & Recognition icon. You can tap the "Keyboard" Fixed Icon for an onscreen keyboard that lets you "type" with the pen, or let the Z-PDA's PalmPrint™ handwriting recognition translate your printed handwriting to type-written characters.
5. When you're ready to stop or to try something new, go ahead—the Z-PDA saves your notes automatically! Later, you can go back and edit your notes or drawings.

Choosing Different Icons and Applications

To choose a different application, simply tap one of the Fixed Icons at the bottom of the Z-PDA's display (shown above). Tapping the "Launcher" Icon gives you a menu of additional applications to choose from, including:



When you're finished, simply turn the Z-PDA off. When you turn it back on, it picks up right where you left off!

The Tandy Z-PDA includes GEOS® operating system software from GeoWorks and Palm Organizer from Palm Computing.

Z-PDA is a trademark of Tandy Corporation. GEOS and GeoWorks are registered trademarks of GeoWorks. Palm Computing, PowerInk, BackspaceInk and PalmPrint are trademarks of Palm Computing. America Online is a registered trademark of America Online, Inc. Pocket Quicken is a trademark of Intuit.