

PLASMA SPRAY PROCESSORS Works Instruction	QF/QMS/02/27	
	Rev. 00	
	Date : 21/07/2023	

Operations/Work/Job Activity covered by this assessment: Cleaning Of Plasma Powder Feeder

Required Personal Protective Equipment (PPE) :



Safety glasses must be worn at times.



Long and loose hair must be contained.



Appropriate footwear with substantial uppers must be worn.



Close fitting/protective clothing to cover arms and legs must be worn.



Respiratory protection devices required.



Oil free leather gloves and spats must be worn.



Hearing protection must be used when using this machine.

POWDER HANDLING

- Powder must be handled with care. Keep the powder dry and clean, and container covered tightly. If any powder is spilled, do not place it back in the container.
- Before it is used, the powder must be thoroughly mixed.
- Making sure the cap is on tight, roll the container back and forth on a bench several times, and turn it end-over-end.
- The same is true for any powder remaining in the hopper for more than eight hours without being used or vibrated. It is recommended that the remaining powder must be removed from the hopper into a clean container, mixed well, and then poured back into the hopper.

Using Same Powder

- Thorough cleaning of the hopper is not necessary if the powder is not being changed. However, if the powder feed unit is not being used for an extended period of time, powder must be drained.

Cleaning

- **CLEANING WILL PRODUCE DUST SO TURN ON EXHAUST AND WEAR PROTECTIVE CLOTHING.**
- **Filters.** The upper and lower filters located in each hopper are continuously exposed to powder and therefore, must be thoroughly cleaned between each powder refill.
- Should powder be present in the filter bowl, unscrew bowl and using filtered dry air, blow clean. During cleaning, prevent powder from entering powder feed cabinet.

Assesor:		Signature:		Date:	
Approved:		Signature:		Date:	

PLASMA SPRAY PROCESSORS Works Instruction	QF/QMS/02/27	
	Rev. 00	
	Date : 21/07/2023	

Changing Powder

- Thorough cleaning of the hopper, powder port shaft, upper and lower hopper filters and hoses is essential when changing to a different powder.
- Disconnect all quick release connections, powder hose connections and remove hopper cover.
- Lift hopper out of bracket and empty it.
- Using Air, blow clean the inside of the hopper, hopper cover, powder port shaft, filters and hoses. Take care not to lose O-rings.

Assesor:		Signature:		Date:	
Approved:		Signature:		Date:	