

Supplies

Scissors Cellophane tape

Assembly Instructions

Step 1: Cut out the frontal guideUsing scissors, carefully cut along the dotted line.
Do not cut any solid lines.

Step 2: Tape the notches

For each notch, align the A side edge with the B side line and place a piece of tape over the seam to secure it.

