
USER INSTRUCTIONS



To turn on and off please connect the plug and click on the switch on Camalele's back.



To access the mp3 slot simply lift the t-shirt, the cards can be changed easily on the bottom right corner. The 4 screws on the sides allow to detach the base and get access to the electronic components in it for maintenance.



Please always put Camalele in sleeping position when not turned on. He needs to be tilted first backwards and the tilt the neck towards the front until he is stable.