





e 835/e 835 S


Instruction manual



Delivery includes

- e 835 / e 835 S
- MZQ 800 microphone clamp
- pouch
- quick guide
- safety guide

Product overview



- 1. Sound inlet basket
- 2. XLR-3 connector
- 3. On/off switch (e 835 S only)
- 4. Screw (e 835 S only)


SENNHEISER e 835/e 835 S | 2/8



Installation


Attaching the microphone

- > Screw the microphone clamp to a stand.
- ▶ Place the microphone with its back end into the microphone clamp.
- ▷ Orient the microphone together with the microphone clamp.



Connecting the microphone

Connect the XLR-3 socket of the microphone cable (optional accessories) to the XLR-3 socket of the microphone.



Using the windshield

▶ Place the MZW 4032 (optional accessories) windshield over the microphone head.



SENNHEISER e 835/e 835 S | 3/8




Operation

Holding the microphone

If you cover the microphone head during transmission, this will change the pick-up pattern of the microphone and consequently the sound.


▷ Only hold the radio microphone by its body.



Positioning the microphone

▷ It is vital to observe the following notes:

Position	Resulting sound	Commentary
A	High proximity effect (large bass boost) Powerful, direct sound	Very little crosstalk from other sound sources
В	Less proximity effect (less bass boost) Some room ambience, natural, balanced sound	More crosstalk from other sound sources
С	Very little proximity effect (minimal bass boost) More room ambience, indirect sound	Higher crosstalk from other sound sources



If sibilance occurs:


▶ Position the microphone slightly to the side and not directly in front of the mouth.

SENNHEISER e 835/e 835 S | 4/8




Positioning the monitor loudspeakers

▶ To prevent feedback and crosstalk, postion your monitor loudspeakers in the angle area of the highest cancellation of the microphone (approx. 180°).



Switching the e 835 S on/off

- ▶ Use the on/off switch to switch the the e 835 S on or off.
- $\, igle \,$ If necessary, use the screw to lock the on/off switch in the "on" position.



SENNHEISER e 835/e 835 S | 5/8



Cleaning and maintaining the e 835 / e 835 S

CAUTION


LIQUIDS CAN DAMAGE THE ELECTRONICS OF THE PRODUCT!

Liquids entering the housing of the product can cause a short-circuit and damage the electronics.

- ▶ Do not use any solvents or cleansing agents.
- Disconnect the products from the power supply system and remove rechargeable batteries and batteries before you begin cleaning.
- ▷ Clean all products only with a soft, dry cloth.

Cleaning the sound inlet basket of the microphone module

- ▶ Unscrew the sound inlet basket.
- ▶ Remove the foam insert from the sound inlet basket.
- ▶ Use a slightly damp cloth to clean the sound inlet basket from the inside and ouside.
- ▶ If necessary, clean the foam insert with a mild detergent or replace the foam insert.
- Dry the foam insert.
- ▶ Reinsert the foam insert.
- ▶ Replace the sound inlet basket on the microphone head and screw it tight.




SENNHEISER e 835/e 835 S | 6/8




Specifications

Transducer principle	dynamic	
Frequency response	40 - 16,000 Hz	
Pick-up pattern	cardioid	
Sensitivity (free field, no load)	2.7 mV/Pa	
Nominal impedance (at 1 kHz)	350 Ω	
Min. terminating impedance	1 kΩ	
Connector	XLR-3	
Temperature range	0 °C to +40 °C	
Dimensions	ø 48 x 180 mm	
Weight	330 g	

Polar pattern




Frequency response



SENNHEISER e 835/e 835 S | 7/8




Connector assignment



Overview of applications

- Primary application
- Secondary application



SENNHEISER e 835/e 835 S | 8/8