

NOTADÜMBLË

It's NOTADÜMBLË 'til you build it.

CONTROLS

ORDER SWITCH - Front slide switch. Selects which channel is first in series when both sides are on.

OVERDRIVE CHANNEL - Left Footswitch

VOLUME - Controls the overall volume of the overdrive channel. Left is less, right is more.

DRIVE - Controls the amount of overdrive. Left is less, right is more.

EQ - Adjustable low-pass filter. Left cuts more high frequencies, right cuts less.

PRESENCE - Controls the upper-mid range and treble frequencies in the gain stage. Left is less, right is more.

CLEAN CHANNEL - Right Footswitch

OUTPUT - Controls the output volume of the clean channel for the effects loop send.

INPUT - Controls the volume of the incoming signal on the effects loop return. Not a standard gain control – changes impedance, which affects tone and feel.

JACKS

INPUT - 1/4" jack on the right side of the pedal.

OUTPUT - 1/4" jack on the left side of the pedal.

EFFECTS LOOP - 1/4" TRS jack to insert an effect into the clean channel loop.

POWER - Requires 9VDC center negative power and consumes 25mA. Do not use more than 9V DC. If you do, you will void your warranty.

JHS PEDALS