

NOTAKLÖN

It's NOTAKLÖN 'til you build it.

CONTROLS

OUTPUT - Controls the overall volume of the pedal. Left is less, right is more.

TREBLE - Controls the amount of treble boost or cut. Noon is neutral.

GAIN - Controls the amount of overdrive. Fully left is clean, which gives the ability to add up to +16dB of clean boost in conjunction with the output. Fully right is max overdrive. As the control is turned clockwise, there is an increase in the mid-frequency range.

SHAMROCK MOD SWITCH - Increases the overall gain +4dB for unmatched boost abilities with an increase in mid frequencies and an additional stage of hard-edge clipping.

JACKS

INPUT - 1/4" jack on the top right side of the pedal.

OUTPUT - 1/4" jack on the top left side of the pedal.

POWER - Requires 9V DC negative center power and consumes 30mA. Do not use more than 9V DC as the pedal internally converts 9V to 18V. If you do, you will void your warranty.