


1 2 3 4 5 6 7 8 9 10 11 12 13 14 15 16 17



1	2	3	4	5	6	7	8	9	10	11	12	13	14	15	16	17
---	---	---	---	---	---	---	---	---	----	----	----	----	----	----	----	----

A	Textual description	Article number	Manufacturer	Position
	Accelerator pedal, 5V			A15
B	Battery (18S3P configuration)	E63B	LG Chem	F11
C	Battery indicator			E11
D	Battery management system	JK-BD6A20S10P	JK-BMS	G9
E	Beacon light, 12V			A4
F	DC/DC, buck, 12VDC			C2
G	Emergency stop			C8
H	Fuse block, 12V			B4
	Fuse, ANL-style, 100A 80VDC			G13
	GPS Speedometer			A3
	Horn, 12V			B6
	Ignition switch			D8
	Motor controller	ND72450	FarDriver	C16
	Motor, 5000W	QS165	QS Motor	E14
	Switch			A13
	Switch			A16
	Switch			A5

Author: Brian McKenna

Launceston & North East Railway - Escort Vehicle - Parts list

File:

Date: 21/11/2025

Folio: 2/2