BAT	1	2	GND
BAT	3	4	GND
BAT	5	6	GND
BAT	7	8	GND
BAT	9	10	PWRON
TS	11	12	LOLN
GPIODV_0	13	14	LOLP
GPIODV_1	15	16	LORP
GPIODV_2	17	18	LORN
GPIODV_3	19	20	GPIOZ_0
GPIODV_4	21		GPIOZ_1
GPIODV_5	23		GPIOZ_2
GPIODV_8	25		GPIOZ_3
GPIODV_9	27		GPIOZ_4
GPIODV_10	29	30	GPIOZ_5
GPIODV_11	31		GPIOZ_6
GPIODV_12	33		GPIOZ_7
GPIODV_13	35		GPIOZ_8
GPIODV_16	37		GPIOZ_9
GPIODV_17	39		GPIOZ_10
GPIODV_18	41		GPIOZ_11
GPIODV_19	43		GPIOZ_12
GPIODV_20	45	46	GPIOZ_13
GPIODV_21	47	48	GPIOZ_14
GPIODV_24	49	50	GPIOZ_15
GPIODV_25	51	52	USBOTG_B_DP
GPIODV_26	53	54	USBOTG_B_DM
GPIODV_27	55	56	USBOTG_B_ID
GPIODV_28	57	58	RESET
GPIODV_29	59	60	HW_ID
USB_VBUS	61	62	GND
USB_VBUS	63	64	GND
USB_VBUS	65	66	GND
USB_VBUS	67	68	GND
USB_VBUS	69	70	GND