

## **Export Hardware**





## Run Debug Configuration





## Launch SDK








119

## Delete System Debugger

**NARLabs** 



21