

# Instructions for Installing a Panel on your PNR Model

Model:

Your product is designed to accept custom overlay panels on each door frame.

## Parts included in the PNR kit:


- (8) Screws to attach the custom panels
- (2) Replacement top hinges
- (2) Replacement bottom hinges
- (4) Longer screws for the replacement bottom hinges
- (4) Plastic bushing for panels

# Panel/Frame Dimensions (per door):

Exterior:  $11 \frac{3}{16}$  W x  $28 \frac{1}{8}$  H

Frame Width: at least 2 3/16"

Overlay panel thickness: minimum 3/4" thick



#### Remove the door from the unit

1. Remove the door from its chassis by unscrewing the top and bottom hinges from the cabinet and door. Save all of the screws from the top hinges for Step 11.

#### Attach the handle & panel

- 2. Attach your door handle to the panel.
- Pull out the rubber gasket located around the inner door frame to access the eight screw holes from the inside of the door.
- 4. Drill 2 holes in the frame on the opposite side of the handle.
- 5. Place your custom panel over the door pane.
- 6. Using the provided screws, attach the panel by holding it in place from the front and screwing it onto the door pane from the inside of the door.
- 7. Reinstall the gasket to its original position.

### Reattach the door

- 8. You will have to drill a hole into the top and bottom of the custom panel in order to connect it to the new provided hinges. To do this, line the door up in its final position, using the new hinges as a guide to mark where you will be drilling the holes. Drill a hole through the top and bottom of the custom panel using a  $^{23}/_{64}$  drill bit.
- 9. Insert the provided bushing into the top and bottom holes of the panel.
- 10. Remove the screw holding the kickplate in on the hinged side.
- 11. You can now reinstall the door using the replacement hinges.

### 12. Repeat step 1-11 for the other door.