

Multi-Channel Image


To load an image select - "File" – "Open" - If the bio-formats importer window opens then select "composite" to see the channels over-layed or "default" if you want the channels displayed separately (this can be changed after loading in "Channel Tools")




Channel select




The image will open with the channel bar along the bottom. In this image (displayed as composite mode) there are 3 positions, one for each channel with the colour displayed under the title. This image is composite so all channels are displayed together



Here the image is displayed as colour or default mode. There are still 3 positions, one for each channel along the bottom. However, this time only the selected channel will be displayed. The brightness and contrast can be changed by selecting the channel then run "Image" – "Adjust" - "Brightness & Contrast" for that channel








Setting Brightness and Contrast

Brightness and contrast can be set the same for multiple images so the cam be compared visually.

- Open up the images you want to set the brightness & contrast on.
- Select the brightest image and change the brightness and contrast for each channel by selecting the channel using "Image" – "Adjust" - "Brightness & Contrast".
- Then click "Set" and there is an option to select to propagate the settings to all other open images



Channel Tools

This tool allows you to change the way the image is displayed

To activate, select - "Image" – "Colour" – "Channel Tools"

In "Colour" mode – it can be used to select the channel







Channel 1 selected

In "Composite" mode it does NOT select the channel but allows the display of selected channels

- The channel is only selected by the bar at the bottom of the image






Channels 1 & 3 displayed
But only channel 1 selected

Lookup Tables


Each channel can be assigned different colours (or a range of colours if you want to study intensities.) Either select the channel to change then select "Image" – "Lookup tables" – select colour or for a multichannel use the LUT macro


>> Presentation Tool Set



LUT Spectrum – for single channel intensity display

select "Image" – "Lookup tables" – "Spectrum" Adjust the brightness and contrast to change the colour range displayed ("Image" – "Adjust" - "Brightness & Contrast"





Multi channel images cannot be imported into PowerPoint, Word, illustrator etc.

They have to be converted to "RGB" format

Multi - channels


Use the Channel Tools window:


In "Composite" mode, select the channels you want displayed then select "More" – " Convert to RGB"

This will create a new window in RGB format that can be used in powerPoint

Use the "File" – "Save As" commands to export. (TIFF format in preference)

To copy and paste – use "Edit" – "Copy to System" – then paste in PowerPoint





RGB Image - No channels

Scale Bar

To add a scale bar:

Either

use "Analyse" - "Tools" – "Scale Bar"

or


- Download the FIJI macros from the FILM website
- Open your image
- Select the Presentation Tool Bar >>
- Select Add Scale Bar
- Opening the original file format image will usually bring in the correct scale information so adding a scale bar will have the correct dimensions
- An exported TIFF image when opened may not have the dimensions set. Use "Analyse" – "Set Scale" to add back the dimensions before adding the scale bar

Add scale bar



Scale bar options


- Length
- Height
- Colour
- With/without Text
- Location




Annotated Gallery View

To create a Gallery view:

- Download the FIJI macros from the FILM website
- Open your image
- Select the Presentation Tool Bar >>
- Select Annotated Gallery









Options to Select:

- Format
- Individual channels in colour or black & white
- Add titles and figure numbers
- Add a scale bar










Split Channels

To split apart the separate channels select - "Image" – "Colour" – "Split Channels"




To merge channels select - "Image" – "Colour" – "Merge Channels"






OK Cancel


Multi Dimensional images





Multi Dimensional images - Annotating a series




Z- Stacks










Montage View


To create a montage view:

- Open your image
- Select "Image" "Stacks" "Make Montage"
- Change options if required
- Convert to "RGB" using "Channel Tools" for PowerPoint.



Output options


- Number of rows/columns
- Scale factor
- Border width (size of separating line)




Maximum Projection View

To create a maximum projection view:

- Open your image
- Select "Image" "Stacks" "Z Project"
- Change the option from Average Intensity to Max Intensity
- Convert to "RGB" using "Channel Tools" for PowerPoint.






Orthogonal View

To create a Orthogonal view:

Either


- Open your image
- Select "Image" "Stacks" "Orthogonal Views"
- Select the required X,Y and Z positions
- Save the individual images
- Convert to "RGB" using "Channel Tools" for PowerPoint.


Or



- Open your image
- Select the Presentation Tool Bar >>
- Select Orthoview Gallery tool
- Select border width and scale bar if required
- Select the required X,Y and Z positions










Intensity Plots

- Open your image
- Select the Intensity Tool Bar >>
- Select Intensity Line plot tool
- Select Plot output options
- · Draw line when requested
- Result is a plot and data table









<u>Time Series – multi Channel plot</u>

- Open your image
- Select the Intensity Tool Bar >>
- Select Intensity Time plot tool
- Select Plot output options
- Draw ROI when requested
- Result is a plot and data table





∭ Re	sults	- 11			-	<u> </u>
File	Edit	Font	Results			
	Frame	Interv	al (sec)	Channel 1	Channel 2	Channel 3
1	0			36.280	29.360	29.376
2	240.01	11		34.515	26.885	25.743
3	480.02	21		33.044	22.898	22.552
4	720.03	32		33.147	20.866	20.955
5	960.04	13		33.625	20.175	19.712
6	1200.0	053		37.391	19.236	19.018
7	1440.0	064		42.369	19.853	19.057
8	1680.0	075		47.862	19.653	17.961
9	1920.0	085		54.445	22.105	16.149
10	2160.0	196		65.539	24.816	15.855
11	2400.107			84.535	31.160	15.313
12	2640.117			100.885	38.998	16.264
13	2880.128			105.900	38.231	15.535
14	3120.139			98.690	35.419	14.136
15	3360.1	150		84.939	30.284	14.186
16	9600 f	ien.		70 701	04.766	10 700

<u>Time Series – multi intensity plots</u>

- Open your image
- Select the Intensity Tool Bar >>
- Select Multi ROI Time plot tool
- Select Plot output options
- Draw ROI's and add to Roi manager when requested
- Result is a list of ROI's, which are also displayed on the image, a plot and data table

