Global CMD-WORD Generation State Machine



STOP : udc_flt < threshold (unconstrained)
STANDBY : udc_flt > threshold (unconstrained)
RUN : (duty_flt > threshold) & (udc_flt > threshold)
STANDBY : (duty_flt < threshold) & (udc_flt > threshold)

Global CMD-WORD Generation State Machine

```
#define GLOBAL_CMD_WORD_GENERATION_WAIT          7
#define GLOBAL_CMD_WORD_GENERATION_RESET         5
#define GLOBAL_CMD_WORD_GENERATION_STOP          1
#define GLOBAL_CMD_WORD_GENERATION_STANDBY       2
#define GLOBAL_CMD_WORD_GENERATION_RUN           3
```