

4.1.10 Lab: Configure BIOS/UEFI Security

Time Spent: 32:05

Score: 100%

Task Summary

Required Actions

- ✓ Add an admin password of t67xab1
- ✓ Add a hard disk password of dog8b0b for Disk 0
- ✓ Enable chassis intrusion detection to show a message during POST
- ✓ Enable the TPM

Explanation

Complete this lab as follows:

1. Set the admin password.
 - a. From the taskbar, select **Start**.
The Start window is shown.
 - b. From the bottom right of the Start window, select the **power icon**.
 - c. Select **Restart**.
 - d. When the *Restart* text disappears, press **F2** (or **Delete**) to access the BIOS settings.
 - e. From the left pane, expand **Security**.
 - f. Select **Admin Password** to set the admin password.
 - g. Type **t67xab1** in the *Enter new password* field.
 - h. Type **t67xab1** in the *Confirm new password* field.
 - i. Select **OK**.
2. Set the hard disk password.
 - a. From the left pane, under **Security**, select **Internal HDD-1 Password** to configure a hard drive password.
 - b. Type **dog8b0b** in the *Enter new password* field. (0 is a zero.)
 - c. Type **dog8b0b** in the *Confirm new password* field. (0 is a zero.)
 - d. Select **OK**.
 - e. Read the warning message on the screen and then select **Yes**.
3. Enable TPM.
 - a. From the left pane, under **Security**, select **TPM Security**.
 - b. From the right pane, select **TPM Security**.
 - c. Select **Apply**.
 - d. Select **Activate**.
 - e. Select **Apply**.
4. Enable intrusion detection.

- a. From the left pane, under Security, select **Chassis Intrusion**.
 - b. Select **Enable**.
 - c. Select **Apply**.
 - d. Select **Exit** to exit and save your changes.
The system automatically reboots.
5. Verify the changes made.
- a. Press **F2** (or **Delete**) during the BIOS load to test the admin password.

If you do not press the Delete key in time, select the **Send Ctrl + Alt + Del** button at the bottom of the screen.

- b. Enter **t67xab1** when you are prompted for the administrative password.
- c. Select **OK**.
Notice that the admin password was set correctly.
- d. Select **Exit** to exit the BIOS.
- e. Type **dog8b0b** when prompted for the hard drive password. (0 is a zero.)
- f. Press **Enter**.

Note that the hard drive password was set correctly. The system loads the operating system.

Copyright © 2025 CompTIA, Inc. All rights reserved.