
JALSAMPADA PORTAL

User Manual

Water Resources Department
Government of Maharashtra

Version 1.0 | Draft
March 2026

Developed and Maintained by
Quanbit Technologies Pvt. Ltd.

Chapter 1

General Portal Navigation

This chapter explains the core navigation elements of the Jalsampada Portal — the top bar, the left-hand navigation sidebar, module workspaces, and the theme toggle. These mechanics apply consistently across all modules and are referenced throughout this manual.

1.1 Understanding the Portal Layout

When you log in to the Jalsampada Portal, the screen is divided into two main areas:

- **Left-Hand Navigation Sidebar** — A fixed vertical panel on the left side of the screen. It displays the **JALSAMPADA** logo at the top, followed by all available module links (**Dashboard**, **Asset**, **Tender**, etc.), and the logged-in user name at the bottom.
- **Main Content Area** — The large panel to the right of the sidebar. This area displays the active page — the **Dashboard Overview**, a **Module Workspace**, or a **List View** depending on what you have selected.




Figure 1.1 — Portal layout: left-hand navigation sidebar and Dashboard Overview (Light Mode)

1.2 Toggling the Display Theme

The Jalsampada Portal supports two display themes: **Light Mode** and **Dark Mode**. You can switch between them at any time without affecting your data or session.

Step 1 Locate the Theme Toggle button

In the **top-right corner** of the screen, next to the **Welcome. Administrator** greeting, locate the circular icon displaying a **sun symbol** (☀️). This is the **Theme Toggle** button.

Step 2 Click the Theme Toggle button

Click the **Theme Toggle** button once. The portal interface will immediately switch from **Light Mode** to **Dark Mode**. The button icon updates to a **moon symbol** to reflect the active theme.




Figure 1.2 — Dashboard displayed in Dark Mode

Step 3 Switch back to Light Mode

Click the **Theme Toggle** button again to return to **Light Mode**. The portal background and all panels revert to the light colour scheme.

Note: Your theme preference is applied for your current session. The portal defaults to Light Mode on the next login unless your preference has been saved in your profile settings.

1.3 Collapsing and Expanding the Sidebar

The left-hand navigation sidebar can be collapsed to a narrow icon-only strip, giving you more horizontal space in the **Main Content Area**. This is useful when working with wide list views or detailed forms.

Step 1 Collapse the sidebar

Click the **JALSAMPADA** logo or the wavy-lines icon (≈) at the top-left of the sidebar. The sidebar collapses to display only the module icons, without text labels.




Figure 1.3 — Sidebar collapsed to icon-only view

Step 2 Expand the sidebar

Click the same icon again. The sidebar expands and restores all module text labels alongside their icons.




Figure 1.4 — Sidebar expanded, showing full module labels

1.4 Navigating to a Module Workspace

The left-hand sidebar lists all the portal's functional **modules**. Clicking a module name navigates you to that module's **Workspace** — the central landing page for all activities within that module.

Each **Workspace** organises its contents into clearly labelled category groups. The most common categories you will encounter are:

- **Master** — Reference data and configuration records (e.g., Asset, Lift Irrigation Scheme, District).
- **Transactions** — Day-to-day operational records (e.g., Asset Interchange, Prapan Suchi).
- **Reports** — Pre-built reports for viewing summarised data (e.g., Asset Register Report, Logsheet Report).

The table below summarises all available modules and their purpose:

Module	Purpose
Dashboard	Returns to the main Dashboard Overview with real-time system metrics.
Asset	Asset Management — manage LIS assets, equipment registers, and asset interchange transactions.
Tender	Tender Management — manage work orders, fund heads, expenditures, and Prapan Suchi.
Operations	Operations Workspace — manage logsheets, gate operations, temperature records, and stock.
Maintenance	Maintenance Workspace — manage maintenance schedules, checklists, and service records.
Attendance	Attendance Workspace — manage employee records, designations, and attendance sheets.
Reports	LIS Management and Operations Reports — access the Asset Register Report, Logsheet Report, and more.
Admin	Admin Workspace — manage users, roles, and role profiles for the portal.

Example: Opening the Asset Management Workspace

Step 1 Click Asset in the sidebar

In the left-hand navigation sidebar, click **Asset**. The **Asset Management Workspace** loads in the main content area. The workspace heading reads "**Asset Management Workspace**" with the sub-title "**Manage Lift Irrigation Scheme assets and transactions**".




Figure 1.5 — Asset Management Workspace, organised into Transactions, Reports, and Master categories

Tip: Clicking **Dashboard** in the sidebar, or clicking the **JALSAMPADA** logo, will always return you to the main **Dashboard Overview** from any screen in the portal.

1.5 Opening a List View

Inside any Workspace, the category groups display individual links — one for each record type managed by that module. Clicking any of these links opens the **List View** for that record type, where you can search, filter, sort, and open individual records.

Step 1 Navigate to a Workspace

Click a module in the sidebar (e.g., **Asset**) to open its Workspace.

Step 2 Click a record type link

Under the **Master** category, click **Asset**. The **Asset List View** opens, displaying all asset records with columns for **ID**, **Status**, **Category**, **LIS**, **Stage**, and **Location**. The record counter in the top-right of the list (e.g., **25 / 1064**) shows the number of records currently visible out of the total.

ID	Status	Category	LIS	Stage	Location	25 / 1064
TEM00STAGE 1APU45	Submitted	Pump	Tembhu LIS	Tembhu LIS-Stage 1A	wakurde	3d
TAKSTAGE 2STP5	Submitted	Starter	Takari LIS	Takari LIS-Stage 2	takari	6d
TEM00STAGE 1ACOTET12	Submitted	Pump	Tembhu LIS	Tembhu LIS-Stage 1A	takari	4 Mar
MHA00JAKHAPURCRSO10	Submitted	Crane	Mhaishal LIS	Mhaishal LIS-Agalgaon- Jakhapur	mhaishal	2 Mar
TAK00STAGE 1PU122	Submitted	Pump	Takari LIS	Takari LIS-Stage 2	mhaishal	2 Mar
TEM00STAGE 1AMOTET12	Draft	Motor	Tembhu LIS	Tembhu LIS-Stage 1A	takari	2 Mar
TAK00STAGE 2PU12	Draft	Pump	Takari LIS	Takari LIS-Stage 2	mhaishal	2 Mar
TAK00STAGE 1PU12	Submitted	Pump	Takari LIS	Takari LIS-Stage 1	mhaishal	2 Mar
TAKSTAGE 1MOPI	Draft	Motor	Takari LIS	Takari LIS-Stage 1	takari	26 Feb
WAK01WAKURDE LIS-PART 1-STAGE 1PUP1 M1	Work In Progress	Pump	Wakurde LIS	Wakurde LIS-Part 1-Stage 1	wakurde	23 Feb
WAK00STAGE 1PU12	Work In Progress	Pump	Wakurde LIS	Wakurde LIS-Part 1-Stage 1	mhaishal	23 Feb
WAK00STAGE 1MO12	Work In Progress	Motor	Wakurde LIS	Wakurde LIS-Part 1-Stage 1	mhaishal	23 Feb
MHA00STAGE 1PUP23	Draft	Pump	Mhaishal LIS	Mhaishal LIS-Stage 1	mhaishal	23 Feb
TAK01STAGE 1PU12	Submitted	Pump	Takari LIS	Takari LIS-Stage 1	mhaishal	23 Feb
TAKSTAGE 1MOPI0	Submitted	Motor	Takari LIS	Takari LIS-Stage 1	takari	19 Feb
MHASTAGE 4PUP1	Draft	Pump	Mhaishal LIS	Mhaishal LIS-Stage 4	mhaishal	18 Feb
PUN00STAGE 1MOPU/223	Draft	Motor	Pundi LIS	Pundi LIS-Stage 1	takari	16 Feb
TAKSTAGE 1MOPI2	Draft	Motor	Takari LIS	Takari LIS-Stage 1	takari	16 Feb
PUN00STAGE 1MOPU/2	Submitted	Motor	Pundi LIS	Pundi LIS-Stage 1	takari	16 Feb
MHA02STAGE 1PU1232	Draft	Pump	Mhaishal LIS	Mhaishal LIS-Stage 1	mhaishal	14 Feb
MHA00STAGE 1PUP2322	Submitted	Pump	Mhaishal LIS	Mhaishal LIS-Stage 1	mhaishal	14 Feb

Figure 1.6 — Asset List View. The counter (25 / 1064) shows records currently loaded out of total matching records.

1.6 Using Filters in a List View

Each List View provides a row of **filter dropdowns** directly above the record list. These allow you to narrow down the displayed records by one or more criteria simultaneously. Applied filters are displayed as labelled tags with an × (remove) button, making it easy to see what is active and clear individual filters.

Step 1 Open a filter dropdown

At the top of the **Asset** list, click the **Select LIS** dropdown. A list of all available Lift Irrigation Schemes appears.

ID	Status	Category	LIS	Stage	Location	25 / 1064
TEM00STAGE 1APU45	Submitted	Pump	Tembhu LIS	Tembhu LIS-Stage 1A	wakurde	3d
TAKSTAGE 2STP5	Submitted	Starter	Takari LIS	Takari LIS-Stage 2	takari	6d
TEM00STAGE 1ACOTET12	Submitted	Pump	Tembhu LIS	Tembhu LIS-Stage 1A	takari	4 Mar
MHA00JAKHAPURCRSO10	Submitted	Crane	Mhaishal LIS	Mhaishal LIS-Agalgaon- Jakhapur	mhaishal	2 Mar
TAK00STAGE 1PU122	Submitted	Pump	Takari LIS	Takari LIS-Stage 2	mhaishal	2 Mar
TEM00STAGE 1AMOTET12	Draft	Motor	Tembhu LIS	Tembhu LIS-Stage 1A	takari	2 Mar
TAK00STAGE 2PU12	Draft	Pump	Takari LIS	Takari LIS-Stage 2	mhaishal	2 Mar
TAK00STAGE 1PU12	Submitted	Pump	Takari LIS	Takari LIS-Stage 1	mhaishal	2 Mar
TAKSTAGE 1MOPI	Draft	Motor	Takari LIS	Takari LIS-Stage 1	takari	26 Feb
WAK01WAKURDE LIS-PART 1-STAGE 1PUP1 M1	Work In Progress	Pump	Wakurde LIS	Wakurde LIS-Part 1-Stage 1	wakurde	23 Feb
WAK00STAGE 1PU12	Work In Progress	Pump	Wakurde LIS	Wakurde LIS-Part 1-Stage 1	mhaishal	23 Feb
WAK00STAGE 1MO12	Work In Progress	Motor	Wakurde LIS	Wakurde LIS-Part 1-Stage 1	mhaishal	23 Feb
MHA00STAGE 1PUP23	Draft	Pump	Mhaishal LIS	Mhaishal LIS-Stage 1	mhaishal	23 Feb
TAK01STAGE 1PU12	Submitted	Pump	Takari LIS	Takari LIS-Stage 1	mhaishal	23 Feb
TAKSTAGE 1MOPI0	Submitted	Motor	Takari LIS	Takari LIS-Stage 1	takari	19 Feb
MHASTAGE 4PUP1	Draft	Pump	Mhaishal LIS	Mhaishal LIS-Stage 4	mhaishal	18 Feb
PUN00STAGE 1MOPU/223	Draft	Motor	Pundi LIS	Pundi LIS-Stage 1	takari	16 Feb
TAKSTAGE 1MOPI2	Draft	Motor	Takari LIS	Takari LIS-Stage 1	takari	16 Feb
PUN00STAGE 1MOPU/2	Submitted	Motor	Pundi LIS	Pundi LIS-Stage 1	takari	16 Feb
MHA02STAGE 1PU1232	Draft	Pump	Mhaishal LIS	Mhaishal LIS-Stage 1	mhaishal	14 Feb
MHA00STAGE 1PUP2322	Submitted	Pump	Mhaishal LIS	Mhaishal LIS-Stage 1	mhaishal	14 Feb

Figure 1.7 — Select LIS dropdown open, displaying available Lift Irrigation Scheme options

Step 2 Select a filter value

Click **Mhaishal LIS** from the list. The dropdown closes and the filter is applied. You can continue adding more filters — click **Select Stage** and choose **Mhaishal LIS-Stage 1**, then click **Select Category** and choose **Motor**.

Step 3 Review filtered results

The list updates automatically to display only the records that match all active filters. Each applied filter appears as a tag at the top of the list (e.g., **Mhaishal LIS** ×, **Mhaishal LIS-Stage 1** ×, **Motor** ×). The record counter updates to reflect the new result count.

The screenshot shows the JALSAMPADA Asset list interface. At the top, there are filter tags: "Mhaishal LIS", "Mhaishal LIS-Stage 1", and "Motor". Below the filters is a table with columns: ID, Status, Category, LIS, Stage, Location, and a date column. The table contains 25 rows of asset records, all with a status of "Draft" and a date of "24 Dec".

ID	Status	Category	LIS	Stage	Location	25 / 30
MHASTAGE 1MOM9	Draft	Motor	Mhaishal LIS	Mhaishal LIS-Stage 1	mhaishal	24 Dec
MHASTAGE 1MOM8	Draft	Motor	Mhaishal LIS	Mhaishal LIS-Stage 1	mhaishal	24 Dec
MHASTAGE 1MOM7	Draft	Motor	Mhaishal LIS	Mhaishal LIS-Stage 1	mhaishal	24 Dec
MHASTAGE 1MOM6	Draft	Motor	Mhaishal LIS	Mhaishal LIS-Stage 1	mhaishal	24 Dec
MHASTAGE 1MOM5	Draft	Motor	Mhaishal LIS	Mhaishal LIS-Stage 1	mhaishal	24 Dec
MHASTAGE 1MOM4	Draft	Motor	Mhaishal LIS	Mhaishal LIS-Stage 1	mhaishal	24 Dec
MHASTAGE 1MOM30	Draft	Motor	Mhaishal LIS	Mhaishal LIS-Stage 1	mhaishal	24 Dec
MHASTAGE 1MOM3	Draft	Motor	Mhaishal LIS	Mhaishal LIS-Stage 1	mhaishal	24 Dec
MHASTAGE 1MOM29	Draft	Motor	Mhaishal LIS	Mhaishal LIS-Stage 1	mhaishal	24 Dec
MHASTAGE 1MOM28	Draft	Motor	Mhaishal LIS	Mhaishal LIS-Stage 1	mhaishal	24 Dec
MHASTAGE 1MOM27	Draft	Motor	Mhaishal LIS	Mhaishal LIS-Stage 1	mhaishal	24 Dec
MHASTAGE 1MOM26	Draft	Motor	Mhaishal LIS	Mhaishal LIS-Stage 1	mhaishal	24 Dec
MHASTAGE 1MOM25	Draft	Motor	Mhaishal LIS	Mhaishal LIS-Stage 1	mhaishal	24 Dec
MHASTAGE 1MOM24	Draft	Motor	Mhaishal LIS	Mhaishal LIS-Stage 1	mhaishal	24 Dec
MHASTAGE 1MOM23	Draft	Motor	Mhaishal LIS	Mhaishal LIS-Stage 1	mhaishal	24 Dec
MHASTAGE 1MOM22	Draft	Motor	Mhaishal LIS	Mhaishal LIS-Stage 1	mhaishal	24 Dec
MHASTAGE 1MOM21	Draft	Motor	Mhaishal LIS	Mhaishal LIS-Stage 1	mhaishal	24 Dec
MHASTAGE 1MOM20	Draft	Motor	Mhaishal LIS	Mhaishal LIS-Stage 1	mhaishal	24 Dec
MHASTAGE 1MOM2	Draft	Motor	Mhaishal LIS	Mhaishal LIS-Stage 1	mhaishal	24 Dec
MHASTAGE 1MOM19	Draft	Motor	Mhaishal LIS	Mhaishal LIS-Stage 1	mhaishal	24 Dec
MHASTAGE 1MOM18	Draft	Motor	Mhaishal LIS	Mhaishal LIS-Stage 1	mhaishal	24 Dec

Figure 1.8 — Asset list filtered by LIS, Stage, and Category. Active filters appear as removable tags.

Step 4 Remove a filter

To remove a single filter, click the × on that filter's tag. To clear all filters, remove each tag individually or navigate away and return to the List View.

1.7 Sorting the List View

Records in a List View are sorted by **Last Updated On** (most recently updated first) by default. You can change the sort field at any time using the **Sort By** dropdown located in the top-right area of the list, to the left of the layout toggle buttons.

Step 1 Open the Sort By menu

Click the **Last Updated On** button at the top-right of the list. A dropdown menu labelled **SORT BY** appears, listing the available sort fields: **Last Updated On**, **ID**, **Status**, **Asset Category**, **Location**, and **LIS**. A checkmark (✓) indicates the currently active sort field.

ID	Status	Category	LIS	Stage	
MHA00JAKHAPURCSO10	Submitted	Crane	Mhaishal LIS	Mhaishal LIS-Agalgaon- Jakhapur	2 Mar
MHA00STAGE 1PUP23	Draft	Pump	Mhaishal LIS	Mhaishal LIS-Stage 1	23 Feb
MHA2STAGE 4PUP1	Draft	Pump	Mhaishal LIS	Mhaishal LIS-Stage 4	18 Feb
MHA02STAGE 1PUI232	Draft	Pump	Mhaishal LIS	Mhaishal LIS-Stage 1	14 Feb
MHA00STAGE 1PUP2322	Submitted	Pump	Mhaishal LIS	Mhaishal LIS-Stage 1	14 Feb
MHA00STAGE 1PUP18	Submitted	Pump	Mhaishal LIS	Mhaishal LIS-Stage 1	14 Feb
MHA02STAGE 2PUI232	Submitted	Pump	Mhaishal LIS	Mhaishal LIS-Stage 2	14 Feb
MHA00STAGE 1PUP232	Draft	Pump	Mhaishal LIS	Mhaishal LIS-Stage 1	3 Feb
MHA2STAGE 1PUP23	Draft	Pump	Mhaishal LIS	Mhaishal LIS-Stage 1	2 Feb
MHA2STAGE 1COS1 1	Draft	Cooling System	Mhaishal LIS	Mhaishal LIS-Stage 1	31 Jan
MHAMHAISHAL LIS-STAGE 2MOMO1200	Draft	Motor	Mhaishal LIS	Mhaishal LIS-Stage 2	31 Jan
MHA2STAGE 1PUI10	Draft	Pump	Mhaishal LIS	Mhaishal LIS-Stage 1	31 Jan
MHA00MHAISHAL LIS-STAGE 1PUP11	Draft	Pump	Mhaishal LIS	Mhaishal LIS-Stage 1	31 Jan
MHAMHAISHAL LIS-STAGE 2PUP11	Draft	Pump	Mhaishal LIS	Mhaishal LIS-Stage 2	31 Jan
MHAMHAISHAL LIS-STAGE 1PUP11	Draft	Pump	Mhaishal LIS	Mhaishal LIS-Stage 1	31 Jan
MHAMHAISHAL LIS-STAGE 1PUP11	Draft	Pump	Mhaishal LIS	Mhaishal LIS-Stage 1	31 Jan
MHAMHAISHAL LIS-EXTENDED GAVANCOP11456	Draft	Control System	Mhaishal LIS	Mhaishal LIS-Extended Gavan	31 Jan
MHAMHAISHAL LIS-EXTENDED GAVANCOP1145678	Draft	Control System	Mhaishal LIS	Mhaishal LIS-Extended Gavan	31 Jan
MHAMHAISHAL LIS-EXTENDED GAVANCOP1145678678	Draft	Control System	Mhaishal LIS	Mhaishal LIS-Extended Gavan	31 Jan
MHAMHAISHAL LIS-EXTENDED GAVANCOP1145678678ert	Draft	Control System	Mhaishal LIS	Mhaishal LIS-Extended Gavan	31 Jan
MHAMHAISHAL LIS-EXTENDED GAVANCOP11	Draft	Control System	Mhaishal LIS	Mhaishal LIS-Extended Gavan	31 Jan

Figure 1.9 — Sort By dropdown. The active sort field is marked with a checkmark.

Step 2 Select a sort field

Click **ID** to sort the list alphabetically by Asset ID. The list re-orders immediately and the button label updates to **ID** to indicate the active sort.

1.8 Loading More Records

List Views display records in pages of 25 at a time. The record counter (e.g., **25 / 875**) at the top-right of the list shows the number of records currently visible out of the total matching records. When there are more records to display, a **Load More** button appears at the bottom of the list.

Step 1 Scroll to the bottom of the list

Scroll down to the last record in the current list. Below the final row, the **Load More** button is displayed.

Step 2 Click Load More

Click **Load More**. The next batch of records (up to 25 more) appends to the current list, and the counter updates (e.g., from **25 / 875** to **35 / 875**). Continue clicking **Load More** to progressively load additional records.

<

Figure 1.10 — The Load More button at the bottom of the list, with the footer showing the total record count

1.9 Switching Between List View and Card View

List Views can be displayed in two layouts. You can toggle between them using the **layout switch buttons** located at the far right of the filter/sort bar:

- **List View** (☰) — The default tabular view, displaying records as rows with column headings. Best for scanning many records quickly.
- **Card View** (田) — Displays each record as an individual card showing key field values. Best for seeing more detail per record at a glance.

Step 1 Switch to Card View

Click the **Card View** icon (a grid of four squares, 田) at the top-right of the list. The display changes from rows to cards. Each card shows the record ID, status badge, and key metadata fields such as **Category**, **LIS**, **Stage**, and **Location**.




Figure 1.11 — Asset records displayed in Card View. Each card shows the record ID, status badge, and key metadata.

Step 2 Return to List View

Click the **List View** icon (the three-line list icon, ≡) to return to the standard tabular layout.

Key Terms — Quick Reference

- **Module** — A functional area of the portal accessible from the left-hand sidebar (e.g., Asset, Tender, Maintenance).
- **Workspace** — The landing page for a module, organising all related record types into categories (Master, Transactions, Reports).
- **List View** — A tabular view of all records for a given record type. Supports search, filter, and sort.
- **Card View** — An alternative display for List Views, showing each record as a summary card.
- **Filter Tag** — A removable label that appears in the filter bar when a filter is active. Click × on the tag to remove that filter.


Log In and Out of the Jalsampada Portal

Portal access and session management

Logging In


Step 1 Open the Portal Login Page

In your web browser, navigate to: **http://103.219.3.169:2225/login**. The Portal Login screen will appear.




Step 2 Enter Your Credentials

In the **Username** field, type your assigned official username. Then click the **Password** field and type your password.



Step 3 Sign In


Click **Sign In to Portal**. Upon successful authentication, the **Dashboard Overview** page will load.



Logging Out


Step 4 Open the User Menu

In the bottom-left corner of the sidebar, click the **Administrator** dropdown trigger to expand the user menu.



Step 5 Click Logout

Click **Logout**. The system will end your session and redirect you back to the Portal Login page.



Chapter 2

Generic Document Actions

This chapter describes the standard actions and controls that apply across **most record types (Doctypes)** in the Jalsampada Portal. The patterns described here — selecting records in a List View, navigating between forms, saving and submitting data, and reviewing activity — are consistent throughout all modules and should be treated as foundational skills before working within any specific module.

2.1 List View Actions (Bulk Management)


The Asset List View — and all other List Views in the portal — displays records as rows, each with a checkbox on the far left. These checkboxes enable bulk operations on multiple records simultaneously, without having to open each record individually.

2.1.1 Bulk Deleting Records

You can select and delete multiple records at once directly from a List View. This is useful when removing a batch of draft or obsolete entries.

Step 1 Select the records to delete

In the List View, click the **checkbox** on the left of each row you wish to delete. A blue tick appears inside the checkbox to confirm selection. To select **all records** currently displayed, click the **header checkbox** at the very top of the checkbox column — this selects all 25 visible records at once.



The screenshot shows the JALSAMPADA Asset List View. The interface includes a sidebar with navigation options: Dashboard, Asset (selected), Tender, Operations, Maintenance, Attendance, Reports, and Admin. The main area displays a table of assets with columns: ID, Status, Category, LIS, Stage, Location, and a selection column. The selection column has a header checkbox and 25 row checkboxes, all of which are checked. The table shows various assets with different statuses (Submitted, Draft, Work In Progress) and categories (Pump, Motor, Starter, Crane). The top right of the table has buttons for '25 Selected', 'Cancel', and 'Delete'.

ID	Status	Category	LIS	Stage	Location	Selection
TEM00STAGE 1APU45	Submitted	Pump	Tembhu LIS	Tembhu LIS-Stage 1A	wakurde	☒
TAKSTAGE 2STP5	Submitted	Starter	Takari LIS	Takari LIS-Stage 2	takari	☒
TEM00STAGE 1ACOTET12	Submitted	Pump	Tembhu LIS	Tembhu LIS-Stage 1A	takari	☒
MHA00JAKHAPURCRS010	Submitted	Crane	Mhaishal LIS	Mhaishal LIS-Agalgaon- Jakhapur	mhaishal	☒
TAK00STAGE 2PU122	Submitted	Pump	Takari LIS	Takari LIS-Stage 2	mhaishal	☒
TEM00STAGE 1AMOTET12	Draft	Motor	Tembhu LIS	Tembhu LIS-Stage 1A	takari	☒
TAK00STAGE 2PU12	Draft	Pump	Takari LIS	Takari LIS-Stage 2	mhaishal	☒
TAK00STAGE 1PU12	Submitted	Pump	Takari LIS	Takari LIS-Stage 1	mhaishal	☒
TAKSTAGE 1MOPI	Draft	Motor	Takari LIS	Takari LIS-Stage 1	takari	☒
WAK01WAKURDE LIS-PART 1-STAGE 1PUPI M1	Work In Progress	Pump	Wakurde LIS	Wakurde LIS-Part 1-Stage 1	wakurde	☒
WAK00STAGE 1PU12	Work In Progress	Pump	Wakurde LIS	Wakurde LIS-Part 1-Stage 1	mhaishal	☒
WAK00STAGE 1MO12	Work In Progress	Motor	Wakurde LIS	Wakurde LIS-Part 1-Stage 1	mhaishal	☒
MHA00STAGE 1PUP23	Draft	Pump	Mhaishal LIS	Mhaishal LIS-Stage 1	mhaishal	☒
TAK01STAGE 1PU12	Submitted	Pump	Takari LIS	Takari LIS-Stage 1	mhaishal	☒
TAKSTAGE 1MOPI0	Submitted	Motor	Takari LIS	Takari LIS-Stage 1	takari	☒
MHASTAGE 4PUP1	Draft	Pump	Mhaishal LIS	Mhaishal LIS-Stage 4	mhaishal	☒
PUN00STAGE 1MOPI/223	Draft	Motor	Pundi LIS	Pundi LIS-Stage 1	takari	☒
TAKSTAGE 1MOPI2	Draft	Motor	Takari LIS	Takari LIS-Stage 1	takari	☒
PUN00STAGE 1MOPI/2	Submitted	Motor	Pundi LIS	Pundi LIS-Stage 1	takari	☒
MHA02STAGE 1PU1232	Draft	Pump	Mhaishal LIS	Mhaishal LIS-Stage 1	mhaishal	☒
MHA00STAGE 101ID2222	Submitted	Pump	Mhaishal LIS	Mhaishal LIS-Stage 1	mhaishal	☒

Figure 2.1 — Selecting multiple records using row checkboxes in the Asset List View

Step 2 Open the bulk action bar

Once one or more records are selected, a **bulk action bar** appears at the top right of the list, replacing the standard **+ Add Asset** button. The bar displays the number of selected records (e.g., **1 Selected**) alongside **Cancel** and **Delete** buttons.




Figure 2.2 — Bulk action bar appears when one or more records are selected

Step 3 Click Delete

Click the red **Delete** button in the bulk action bar. A confirmation prompt may appear. Confirm the deletion. All selected records are removed from the system simultaneously.

Important — Linked Records Cannot Be Deleted

The system blocks deletion of any record linked elsewhere (e.g., an Asset with an active **Asset Interchange**). You will receive a **"Failed To Delete Records"** error specifying the IDs of both the record to be deleted and the specific linked record (e.g., **INTER-00064**) preventing the action. To delete the original record, you must first resolve or remove the linked record.

TIP: Clicking the linked record ID in the error message takes you to the relevant form.




Figure 2.3 — Deletion blocked when the selected Asset is linked to another record (e.g., an Asset Interchange)

Step 4 Cancel the selection

To deselect all records without deleting, click **Cancel** in the bulk action bar. The checkboxes clear and the standard list controls are restored.

2.1.2 Opening a Record (Accessing the Form View)

Each row in a List View represents one record. To view or edit a record's full details, click its **ID** or primary link (the first column value, shown in blue). The portal navigates away from the list and opens the **Form View** for that specific record.

JALSAMPADA Welcome, Administrator

Tender / Expenditure / Expenditure EXP-0142 Not Saved Save < > ⊞ :

Details

Fiscal Year *
2025-2026

Bill Date: 25/02/2026
Tender Number *: TE/WAKURDE/P34
Tender Amount: 50000
Lift Irrigation Scheme: Wakurde LIS

Previous Bill Number: RA2
Previous Bill Amount: 20000
Previous MB No: 2
Previous Page No: 2

Bill Number: RA3
Bill Amount *: 20000.00
MB No: 3
Page No: 3

Bill Upto Amount: 50000
Bill Remaining Amount: 0
Bill Type: Final

Stage/ Sub Scheme
Wakurde LIS-Part 1-Stage 1 X Wakurde LIS-Part 1-Stage 12 X Clear all
Search Stage/ Sub Scheme...

Expenditure Details

Name of Work	Stage	Work Type	Work Subtype	Expenditure Amount	Have Asset	Asset	Asset Name	Actions
TESTING Entry	Wakurde LIS-Part 1-Stage 1	Auxiliary	Battery Charger	20000	☒		Search...	⬆

Figure 2.4 — Clicking a record ID in the List View opens the full Form View for that record

Tip: You can also open a record in a new browser tab by right-clicking its ID link and selecting "Open link in new tab". This allows you to reference the list while working on a record.

2.2 Form Navigation & Header Actions

Once a Form View is open, a consistent set of navigation and action controls appears across the top of the page. These controls are the same for all record types.

2.2.1 Breadcrumb Navigation

The **breadcrumb trail** is displayed at the top left of every Form View. It shows the full path to the current record — for example:

LIS Management / Asset / TEMO0STAGE1AMOTET12

Each segment of the breadcrumb is a clickable link. Use the breadcrumbs to jump back to any parent level without using the browser's Back button:

- Click the **module name** (e.g., **LIS Management**) to return to the module's Workspace.
- Click the **record type name** (e.g., **Asset**) to return to the List View for that record type.




Figure 2.5 — Breadcrumb navigation at the top of a Form View, allowing quick return to the Workspace or List View

2.2.2 Record Flipping (Next / Previous)

Located in the top-right area of every Form View, the < > arrow buttons allow you to navigate directly to the previous or next record of the same type — without returning to the List View first.

- Click < (left arrow) to move to the **previous record** in the current list order.
- Click > (right arrow) to advance to the **next record** in the current list order.

The list order is determined by whatever sort and filters were active when you opened the form. Record flipping is especially useful when reviewing or updating a sequence of related records (for example, all Draft assets in a particular LIS Stage).




Figure 2.6 — Previous / Next (< >) record navigation buttons in the top-right of the Form View

2.2.3 Kebab Menu (Advanced Record Actions)

The **kebab menu** — represented by a vertical three-dot icon (⋮) — is located at the top right of the Form View, next to the < > navigation arrows. It provides access to advanced actions for the currently open record.

Click the three-dot icon to expand the menu. The most common options available are:

- **Duplicate** — Creates a new record pre-populated with the data from the current record. Useful for quickly registering multiple similar assets or configurations without re-entering shared fields.
- **Delete** — Permanently removes the record currently being viewed. This acts on the single open record only; it is not a bulk action.

Additional options may appear in the kebab menu depending on the record type and its current status.




Figure 2.7 — Kebab menu expanded, showing Duplicate and Delete actions for the current record

Note:

The **Delete** option in the kebab menu is subject to the same linking restrictions as bulk deletion. If the record is linked to another document, the deletion will be blocked and an error message will be shown (see Section 2.1.1).

2.2.4 Save and Submit

Most record types in the portal follow a two-stage confirmation workflow: Save and Submit. Understanding the difference between these two actions is important for managing the lifecycle of records correctly.

- **Save** — Writes the current field values to the database and keeps the record in **Draft** status. A saved record remains editable and is not yet considered final. Use Save frequently while entering data to prevent loss of work.
- **Submit** — Transitions the record from **Draft** to **Submitted** status. Once submitted, a record is locked for editing and becomes a permanent, read-only entry in the system. Submission is used to signal that data has been reviewed and approved for use.

Both buttons are located in the bottom-right area of the Form View (or in the top action bar for some record types). Save is always available while the form is in edit mode; the Submit button only appears once all required fields have been completed.

The screenshot displays the JALSAMPADA portal interface. At the top, there's a blue header with the portal name and a user welcome message. The main content area is divided into sections: 'Interchange Details' with fields for 'Current Linked Motor/Pump' (TAKSTAGE 1MOP12), 'Linked Asset No' (P12), and 'Interchange Date' (17/02/2026); 'Purchase Details' with 'Net Purchase Amount' (1) and 'Asset Quantity' (1); and 'Expenditure Information' showing an empty 'Expenditure History' table. At the bottom right, there are two buttons: 'Save' and 'Submit'. A red arrow points to the 'Save' button.

Figure 2.8 — Save and Submit buttons on a record form. Submit locks the record as read-only.

Note:


Not all record types have a Submit step. For simpler reference data (e.g., Asset Category), saving is sufficient. For operational records such as Assets and Asset Interchanges, submission is required before the record is treated as confirmed.

2.2.5 Creating a New Record

A **+ New [Record Type]** button (for example, **+ Add Asset**) is available in two locations:

- At the **top right of the List View** — always visible, even when no records are selected.
- Within the **Workspace** — as a shortcut link within the relevant category group (Master, Transactions, etc.).

Clicking this button opens a blank Form View for the selected record type, with all fields empty and the status set to Not Saved. Required fields (marked with a red asterisk *) must be completed before the record can be saved.



ID	Status	Category	LIS	Stage	Location	25 / 1064
TEM00STAGE 1APU45	Submitted	Pump	Tembhu LIS	Tembhu LIS-Stage 1A	wakurde	4d
TAKSTAGE 2STP6	Submitted	Starter	Takari LIS	Takari LIS-Stage 2	takari	4 Mar
TEM00STAGE 1ACOTET12	Submitted	Pump	Tembhu LIS	Tembhu LIS-Stage 1A	takari	4 Mar
MHA00JAKHAPURCRS010	Submitted	Crane	Mhaishal LIS	Mhaishal LIS-Agalgaon- Jakhapur	mhaishal	23 Mar
TAK00STAGE 2PU122	Submitted	Pump	Takari LIS	Takari LIS-Stage 2	mhaishal	2 Mar
TEM00STAGE 1AMOTET12	Draft	Motor	Tembhu LIS	Tembhu LIS-Stage 1A	takari	2 Mar
TAK00STAGE 2PU12	Draft	Pump	Takari LIS	Takari LIS-Stage 2	mhaishal	2 Mar
TAK00STAGE 1PU12	Submitted	Pump	Takari LIS	Takari LIS-Stage 1	mhaishal	2 Mar
TAKSTAGE 1MOP1	Draft	Motor	Takari LIS	Takari LIS-Stage 1	takari	26 Feb
WAK01WAKURDE LIS-PART 1-STAGE 1PU1 M1	Work In Progress	Pump	Wakurde LIS	Wakurde LIS-Part 1-Stage 1	wakurde	23 Feb
WAK00STAGE 1PU12	Work In Progress	Pump	Wakurde LIS	Wakurde LIS-Part 1-Stage 1	mhaishal	23 Feb
WAK00STAGE 1MO12	Work In Progress	Motor	Wakurde LIS	Wakurde LIS-Part 1-Stage 1	mhaishal	23 Feb
MHA00STAGE 1PUP23	Draft	Pump	Mhaishal LIS	Mhaishal LIS-Stage 1	mhaishal	23 Feb
TAK01STAGE 1PU12	Submitted	Pump	Takari LIS	Takari LIS-Stage 1	mhaishal	23 Feb
TAKSTAGE 1MOP10	Submitted	Motor	Takari LIS	Takari LIS-Stage 1	takari	19 Feb
MHASTAGE 4PUP1	Draft	Pump	Mhaishal LIS	Mhaishal LIS-Stage 4	mhaishal	18 Feb
PUN00STAGE 1MOPU/223	Draft	Motor	Pundi LIS	Pundi LIS-Stage 1	takari	16 Feb
TAKSTAGE 1MOP12	Draft	Motor	Takari LIS	Takari LIS-Stage 1	takari	16 Feb
PUN00STAGE 1MOPU/2	Submitted	Motor	Pundi LIS	Pundi LIS-Stage 1	takari	16 Feb
MHA02STAGE 1PU1232	Draft	Pump	Mhaishal LIS	Mhaishal LIS-Stage 1	mhaishal	14 Feb
MHA00STAGE 1PUP2322	Submitted	Pump	Mhaishal LIS	Mhaishal LIS-Stage 1	mhaishal	14 Feb

Figure 2.9 — The '+ Add Asset' button at the top right of the List View opens a blank new asset Form View

2.3 Advanced Form Features

2.3.1 Tab Navigation

Complex forms organise their fields into tabs to reduce visual clutter and group related information logically. The tab bar is displayed horizontally beneath the form title and breadcrumb, and remains visible as you scroll through the form.

Common tab groupings you will encounter across the portal include:

- **Details** — Core identifying fields: names, IDs, categories, dates, and primary configuration.
- **Insurance** — Insurance policy details and coverage dates (Asset module).
- **Other Info** — Supplementary attributes and reference data.
- **Drawing Attachment** — Technical drawings, diagrams, or scanned documents relevant to the record.
- **Connections** — Linked or related records from other modules (where applicable).

Click a tab label to switch to that section. The active tab is underlined or highlighted to indicate which section is currently displayed.

The screenshot shows the 'Asset Form View' for 'TEM00STAGE 1APU45'. The status is 'Submitted'. The navigation bar at the top has four tabs: 'Details', 'Insurance', 'Other Info', and 'Drawing Attachment'. The 'Insurance' tab is currently active and highlighted with a red underline. Below the tabs, the form contains several input fields: 'Policy number', 'Insurance Start Date' (11/03/2026), 'Insurer', 'Insurance End Date' (11/03/2026), 'Insured value' (0), and a toggle for 'Comprehensive Insurance' which is turned on. At the bottom right, there are 'Cancel' and 'Back' buttons.

Figure 2.10 — Tab navigation bar on the Asset Form View, with the 'Details' tab currently active

2.3.2 Comment and Activity Section

Every form in the portal includes a Comment and Activity section at the bottom of the page, below all the data fields. This section serves two purposes: enabling internal communication between team members, and providing a full audit trail of all changes made to the record.

Adding a Comment

To add an internal note to a record, scroll to the bottom of the Form View and locate the **Add a comment...** text area.

Step 1 Click the comment input area

Click inside the comment text area. The field expands and a Submit button appears.

Step 2 Type your comment

Enter your note or message. Comments support plain text. They are visible to all users who have access to the record.

Step 3 Submit the comment

Click the **Submit** button beneath the comment field. The comment is saved and appears in the Activity log with your username and a timestamp.

The screenshot shows the 'Activity' section of the portal. At the top, there's a header 'JALSAMPADA' and 'Welcome, Administrator'. Below this, the 'Activity' section has a 'Show all activity' toggle. The main area contains a large text input field for adding a comment, with a 'Post Comment' button to its right. Below the input field, there's a list of activities. The first activity is 'You commented - about 1 hour ago' with the text 'test'. Below this, there are several 'updated this - 4 days ago' entries from 'vaibhav.magdum@erpdata.in'. At the bottom right, there is an upward arrow button.

Figure 2.11 — Comment input area at the bottom of a Form View

Viewing the Activity Log

The Activity section, immediately below the comment input, displays a chronological list of all events related to the record. Each entry shows:

- The **action taken** (e.g., Record Created, Field Updated, Comment Added, Status Changed).
- The **user name** of the person who performed the action.
- The **date and time** the action occurred.

This log provides a complete audit trail and is read-only; it cannot be edited or deleted. Use the Activity section to understand the history of a record, identify who last modified a field, or trace how a record has progressed through its workflow stages.




Figure 2.12 — Activity log at the bottom of a Form View, showing the record's full change history

2.4 Asset Module Exception — Edit Sub-Page

The sections above describe behaviour that is consistent across nearly all record types in the portal. The Asset module, however, includes one important deviation from this standard pattern.

Asset Module Exception

Unlike most other modules where opening a record from the List View takes you directly to an editable Form View, the **Asset module** uses a unique **Asset Overview page** as the default view for each Asset record.

The Asset Overview page displays a summary of the asset's key data, linked records, and current status — but **it is not directly editable**. To modify the asset's details, you must specifically navigate to the **Edit sub-page** by clicking the **Edit** link or button within the Asset Overview.

All standard form controls (Save, Submit, tab navigation, comment section, kebab menu) are available once the **Edit sub-page** is open.

The screenshot displays the 'Asset Overview' page in the JALSAMPADA PORTAL. The page header shows the portal name and a user welcome message. The main content area is titled 'TESTING RUNNING HOURS' and includes a 'Submitted' status. Below the title, there are several input fields for asset details: Category (Pump), LIS Name (Tembhu LIS), Stage No (Tembhu LIS-Stage 1A), Make (—), Model (—), and Status (Stopped). A red box highlights the 'Edit' button in the top right corner. Below the details, there is a section for 'Attached Drawings & Files' with a red box around the 'Drawings' tab and a message 'No drawings attached'.

Figure 2.13 — Asset Overview page (read-only summary). Click 'Edit' to open the editable Asset form.

Key Terms — Quick Reference

Bulk Action Bar	The control strip that appears at the top of a List View when one or more records are selected, providing Delete and Cancel options.
Form View	The full detail page for a single record, opened by clicking the record ID in a List View.
Breadcrumb	The clickable navigation trail at the top of a Form View showing the path back to the Workspace and List View.
Record Flipping	Navigating between consecutive records of the same type using the < > arrow buttons in the Form View header.
Kebab Menu	The vertical three-dot (⋮) menu in the Form View header, providing advanced actions such as Duplicate and Delete.
Draft	The initial status of a newly created or saved record. Draft records remain editable.
Submitted	The locked, read-only status of a record after the Submit action has been taken. Submitted records are treated as confirmed.
Activity Log	The read-only audit trail at the bottom of every Form View, recording all changes, submissions, and comments with user names and timestamps.
Asset Overview	The Asset module's unique landing page for an individual Asset record, which displays summary information only. The Edit sub-page must be accessed to modify asset data.

Chapter 3

Form Data Entry, Tables & Attachments

This chapter explains three specific interaction patterns that appear throughout the Jalsampada Portal: entering data into **Child Tables** (internal line-item grids within forms), selecting values from **Searchable Dropdown fields** (Link Fields), and uploading and managing **file attachments**. These patterns are consistent across all modules — mastering them here means you can apply the same skills wherever they appear.

3.1 Working with Form Tables (Child Tables)

Some forms in the portal require you to capture **multiple line items** of the same type within a single record — for example, a list of expenditure line items on a Tender record, or a set of tasks on a Maintenance Checklist. These are managed using **Child Tables**: embedded grids that appear within the body of the form, each with their own rows, columns, and controls.

Child Tables always appear below a clearly labelled section header (e.g., **Expenditure Details** or **Checklist Items**). All row-level actions — adding, editing, and deleting — are performed directly inside the table, without leaving the form.

3.1.1 Adding a Row

Each Child Table starts empty (or with any previously saved rows) and grows as you add new line items. Rows are added one at a time from the bottom of the table.

Step 1 Scroll to the Child Table


Scroll down through the form until you reach the required table section. The table heading (e.g., **Expenditure Details**) is displayed in bold above the column headers. The table may already contain rows if data was previously saved.

The screenshot shows a form with a child table titled "Expenditure Details". The table has the following columns: Name of Work, Stage, Work Type, Work Subtype, Expenditure Amount, Have Asset, Asset, Asset Name, Asset No, and Actions. A red arrow points to the "+ Add Row" button at the bottom left of the table. The table contains one row with the following data: Name of Work: TESTING Entry, Stage: Wakurde LIS-Part 1-Stage, Work Type: Auxiliary, Work Subtype: Battery Charger, Expenditure Amount: 30000, Have Asset: Yes, Asset: Search..., Asset Name: Asset Name, Asset No: Asset No, and Actions: Edit.

Expenditure Details child table inside a Tender / Expenditure form, showing existing rows and the column headers (Name of Work, Stage, Work Type, Work Subtype, Expenditure Amount, Have Asset, Asset, Asset Name, Amount).

Step 2 Click + Add Row

At the bottom-left of the table, click the **+ Add Row** button. A new empty row is appended to the end of the table, ready for data entry. Each cell in the new row is blank.



The screenshot shows a table titled 'Expenditure Details' with columns: Name of Work, Stage, Work Type, Work Subtype, Expenditure Amount, Have Asset, Asset, Asset Name, Asset No, and Actions. The first row contains 'TESTING Entry', 'Wakurde LIS-Part 1-Stage', 'Auxiliary', 'Battery Charger', '30000', and a red toggle switch. A second row is partially visible with search filters. At the bottom-left, a red box highlights the '+ Add Row' button.

Child table with the '+ Add Row' button visible at the bottom-left of the Expenditure Details table. A new blank row has been appended as the last row.


Tip: You can click + Add Row multiple times to create several blank rows in advance, then fill them in one by one.

3.1.2 Entering Data in a Row

Once a new row exists, you can enter data in two ways depending on the table's complexity: directly in the cell (Inline Editing), or through a dedicated row pop-up (Edit Row view).

Inline Editing

For simple fields, click directly into any cell in the new row. The cell becomes active (highlighted with a border) and accepts input. For text fields, type the value directly. For dropdown fields, a list of options appears — type to search or scroll to select (see **Section 3.2** for searchable dropdowns).



The screenshot shows the same table as before, but the second row is in inline editing mode. The 'Expenditure Amount' cell is highlighted with a blue border and contains a dropdown arrow. A red arrow points to this dropdown arrow.

A child table row in inline editing mode — one cell is active/highlighted showing a cursor ready for input, and an adjacent cell shows a dropdown list open with filtered options.

Note:


Press **Tab** on your keyboard to move to the next cell in the row without clicking. Press **Shift + Tab** to move back to the previous cell.

Edit Row View (Row Pop-Up)

When a table has many columns that do not fit comfortably on screen, or when a field requires more space to fill in, use the **Edit Row** view. This opens a dedicated pop-up panel that shows all fields for that row in a structured layout, making data entry easier and reducing horizontal scrolling.

Step 1 Click the Edit Row icon

On the far left (or right) of any table row, locate the **Edit Row icon** — a small pencil or expand arrow icon (✎). Click it. A pop-up panel slides in from the right side of the screen (or appears as a modal), displaying all fields for that row individually.




The screenshot shows a table titled 'Expenditure Details' with the following columns: Name of Work, Stage, Work Type, Work Subtype, Expenditure Amount, Have Asset, Asset, Asset Name, Asset No, and Actions. The first row contains the following data: TESTING Entry, Wakurde LIS-Part 1-Stage1, Auxiliary, Battery Charger, 30000, a red toggle switch, Search..., Q, Asset Name, Asset No, and a pencil icon. The second row contains: Wakurde LIS-Part 1-Stage1, Miscellaneous, Battery Charger, 344, a red toggle switch, Search..., Q, Asset Name, Asset No, and a pencil icon. The pencil icon in the first row is highlighted with a red box. At the bottom of the table, there is an 'Add Row' button and 'Download' and 'Upload' buttons.

A child table row with the Edit Row icon (pencil/expand arrow) highlighted on the far right of the row, showing where to click to open the row pop-up panel.

Step 2 Fill in the row fields

In the pop-up panel, each field is displayed with its label and an input control. Fill in all required fields. Searchable dropdown fields work the same way as in the main form — click the field and start typing to filter options (see **Section 3.2**).



The screenshot shows the 'Edit Row 1' pop-up panel. It contains the following fields: Name of Work (TESTING Entry), Stage (Wakurde LIS-Part 1-Stage 1), Work Type (Auxiliary), Work Subtype (Battery Charger), Expenditure Amount (30000), Asset (Select Asset...), Asset Name, Asset No, Tax Amount, Invoice Number, Invoice Date (DD/MM/YYYY), Work Details, and an Attach button. At the bottom, there are 'Cancel' and 'Save' buttons. The background shows a blurred view of the main form.

The Edit Row pop-up panel open on the right side of the screen, showing all fields for one Expenditure Details row (e.g., Name of Work, Stage, Work Type, Work Subtype, Expenditure Amount, Have Asset toggle, Asset Name) with some fields already filled in.

Step 3 Close the Edit Row pop-up

Click anywhere outside the pop-up panel, or click the **Close** or **×** button on the panel, to return to the main form. Your entered data is retained in the row.

3.1.3 Deleting Rows from a Child Table

You can remove one or more rows from a Child Table at any time before saving. Deleted rows are removed from the record permanently once you save the form.

Step 1 Select the rows to delete

Each row in the Child Table has a **checkbox** on its far left. Click the checkbox on any row you want to delete — a blue tick confirms selection. To select **all rows** in the table simultaneously, click the **header checkbox** at the top of the checkbox column.

Expenditure Details

☒	Name of Work	Stage	Work Type	Work Subtype	Expenditure Amount	Have Asset	Asset	Asset Name	Asset No	Actions			
☒	TESTING Entry	Wakurde LIS-Part 1-StageK	Auxiliary	×	Battery Charger	×	30000	☐	Search...	Q	Asset Name	Asset No	
☒		Wakurde LIS-Part 1-StageK	Miscellaneous	×	Battery Charger	×	344	☐	Search...	Q	Asset Name	Asset No	

+ Add Row

Delete (2)

Download

Upload

Child table (Expenditure Details) with two rows selected using their checkboxes (blue ticks visible). The header checkbox at the top of the column is also shown for reference.

Step 2 Click the Delete button

Once one or more rows are selected, a **Delete** button appears below the table (or in the table's action bar). Click **Delete**. The selected rows are immediately removed from the table.

Expenditure Details

☒	Name of Work	Stage	Work Type	Work Subtype	Expenditure Amount	Have Asset	Asset	Asset Name	Asset No	Actions			
☒	TESTING Entry	Wakurde LIS-Part 1-StageK	Auxiliary	×	Battery Charger	×	30000		Search...	Q	Asset Name	Asset No	
☒		Wakurde LIS-Part 1-StageK	Miscellaneous	×	Battery Charger	×	344		Search...	Q	Asset Name	Asset No	

+ Add Row

Delete (2)

Download

Upload

Child table showing the Delete button appearing below the table after rows have been selected, ready to be clicked to remove the selected rows.

Step 3 Save the form

Row deletions are not written to the database until you save. Click **Save** in the form's action bar to confirm all changes — both additions and deletions.

Important: If you navigate away from the form without saving, any unsaved row changes (additions or deletions) will be lost. Always save after modifying a Child Table.

3.1.4 Bulk Uploading and Downloading Rows

If you need to enter a large number of line items, adding them one by one can be time-consuming. To speed up data entry, Child Tables feature Download and Upload buttons that allow you to manage table data using spreadsheet files (like Excel or CSV)

Step 1 Download the table template

Locate the **Download** button, usually found at the top-right or bottom edge of the Child Table. Clicking this will download a spreadsheet file to your computer containing the exact column headers required by the table. (If the table already has rows, those rows will be included in the downloaded file).

Expenditure Details							
☐	Name of Work	Stage	Work Type	Work Subtype	Expenditure Amount	Have Asset	Asset Actions
☐	TESTING Entry	Wakurde LIS-Part 1-Stage	Auxiliary	× Battery Charger	× 20000	☐	See
+ Add Row Download Upload							


Child table (Expenditure Details) with two rows selected using their checkboxes (blue ticks visible). The header checkbox at the top of the column is also shown for reference.

Step 2 Fill in your data externally

Open the downloaded file in a spreadsheet application (like Microsoft Excel). Fill in your line items row by row, ensuring you do not change the column headers. Once finished, save the file.

Step 3 Upload the populated file

Return to the portal and click the **Upload** button next to the table. A file picker will open. Select the spreadsheet you just saved.



The file picker dialog open, or the child table instantly populated with multiple rows after a successful upload

Step 4 Review the populated rows

The system will automatically process the file and instantly populate the Child Table with all your rows. Review the grid to ensure all data imported correctly. As always, click Save on the main form to write these new rows to the database.

3.2 Using Searchable Dropdowns (Link Fields)

Throughout the portal — both in main forms and inside Child Table rows — many fields are **Link Fields**: dropdown selectors that are connected to lists of records stored elsewhere in the system. Examples include **Work Type**, **Stage**, **Name of Work**, **Lift Irrigation Scheme**, and **Asset Category**.

These lists can contain hundreds of options. Rather than requiring you to scroll through all of them, Link Fields are **searchable**: you type a keyword and the list filters in real time, showing only the matching options. This makes selection fast and accurate even in large datasets.

Step 1 Click the Link Field

Click inside the field (e.g., the **Work Type** cell in a table row, or the **Select LIS** dropdown in the main form). The field becomes active and a dropdown list appears, initially showing all available options.

The screenshot shows a table titled 'Expenditure Details' with columns: Name of Work, Stage, Work Type, Work Subtype, Expenditure Amount, Have Asset, Asset, Asset Name, and Actions. The first row is 'TESTING Entry' with 'Wakurde LIS-Part 1-StageK' as the Stage and 'Auxiliary' as the Work Type. The second row is a new entry with 'Search...' in the Stage and 'Search...' in the Work Type field. The 'Work Type' dropdown menu is open, showing a list of options: Auxiliary, Miscellaneous, Operation, Repair, Security, TEST RE, and Test Work Type. The 'Add Row' button is visible at the bottom left, and 'Download' and 'Upload' buttons are at the bottom right.

A Link Field (e.g., Work Type) clicked and active in a child table row, showing the full dropdown list of options appearing below the cell — options visible include 'Auxiliary', 'Repair', 'New Work', etc.

Step 2 Type a search keyword

Begin typing a keyword related to the option you need. For example, type **"re"** to filter for options containing those letters (e.g., **Repair**, **Replacement**). The list updates instantly to show only matching results.

The screenshot shows the same table as before, but the 'Work Type' dropdown menu is now filtered to show only 'Repair' and 'TEST RE'. The 'Add Row' button is visible at the bottom left, and 'Download' and 'Upload' buttons are at the bottom right.

The same Work Type Link Field with 're' typed into it — the dropdown list is now filtered, showing only options matching the keyword (e.g., 'Repair', 'Replacement') while non-matching options are hidden.

Step 3 Select the correct option

Click the correct option from the filtered list. The field closes and the selected value is populated into the cell or field. The dropdown dismisses automatically.

The screenshot shows the same table as before, but the 'Work Type' dropdown menu is now closed, and the selected value 'Auxiliary' is populated into the cell. The 'Add Row' button is visible at the bottom left, and 'Download' and 'Upload' buttons are at the bottom right.

The Work Type field after selection — the cell now shows the chosen value (e.g., 'Auxiliary') and the dropdown has closed. The next cell in the row is now active.

Step 4 Repeat for other Link Fields

Repeat Steps 1–3 for any other Link Fields in the form or row (e.g., **Work Subtype**, **Stage**, **Asset**). Each field is independently searchable.

Tip:

If the option you are looking for does not appear in the dropdown, it may not yet exist as a record in the system. Contact your system administrator to have the required record created before proceeding.

3.3 Uploading Attachments

Many records in the portal support **file attachments** — documents, scanned invoices, PDF reports, or images that provide supporting evidence or context for the record. Attachment fields appear in the main form body (e.g., in the **Drawing Attachment** tab of an Asset) or as upload controls within individual Child Table rows (e.g., an invoice PDF against an expenditure line item).

3.3.1 Uploading a File

Step 1 Locate the attachment field

On the form or within an Edit Row pop-up, locate the attachment control. It is typically labelled **Upload** or **Attach File**, and may display a document icon or a dotted upload area.

The screenshot shows the JALSAMPADA portal interface. On the left is a sidebar with navigation links: Dashboard, Asset, Tender (highlighted), Operations, Maintenance, Attendance, Reports, and Admin. The main area displays the 'Edit Row 2' pop-up form. The form has a title bar with 'Edit Row 2' and a close button. It contains several sections of fields: 'Name of Work' and 'Stage' (with a search dropdown); 'Work Type' (set to 'Auxiliary') and 'Work Subtype' (with a search dropdown); 'Expenditure Amount'; 'Asset' (with a search dropdown), 'Asset Name', and 'Asset No'; 'Tax Amount', 'Invoice Number', and 'Invoice Date' (with a date picker); and 'Work Details'. A red box highlights the 'Attach' button, which is labeled 'Attach' and has an upload icon. At the bottom of the form are 'Cancel' and 'Save' buttons. The user's name 'Vaibhav' is visible in the top right corner of the portal.


An attachment field in a form or Edit Row pop-up — showing an 'Upload' button or dotted drop-zone area labelled 'Attach File', before any file has been selected.

Step 2 Click Upload / Attach

Click the **Upload** button or the attachment area. Your operating system's standard **file picker dialog** will open.

Step 3 Select the file

Navigate to the location of the file on your computer (e.g., **login and log out.pdf**). Click the file to select it, then click **Open** (or the equivalent button in your operating system's dialog).




The operating system file picker dialog open, with a PDF file selected (e.g., 'login and log out.pdf') ready to be attached to the form record.

Step 4 Confirm the upload

After selecting the file, the portal uploads it and displays the **file name** in the attachment field alongside two action icons:

- Preview icon (👁️ **Eye icon**) — Click to open the attached file in a new browser tab or preview panel, allowing you to confirm the correct document has been uploaded.
- Clear icon (✕ **X icon**) — Click to remove the uploaded file. The attachment field returns to its empty state, and you can upload a different file if needed.



The attachment field after a file has been successfully uploaded — the field now shows the file name (e.g., 'login and log out.pdf') with a small Eye (preview) icon and an X (clear) icon to its right.

Note:

Uploading a file does not save it to the record permanently. You must click **Save** on the main form after uploading to ensure the attachment is stored. If you navigate away without saving, the uploaded file will be lost.

3.3.2 Previewing an Attachment

To verify an uploaded file before saving, click the **Eye icon** next to the file name. The file opens in a new browser tab (for PDFs and images) or is downloaded, depending on your browser settings and file type. Review the content to confirm the correct file has been attached.

3.3.3 Removing an Attachment

To remove an uploaded file and replace it with a different one — or simply to clear the field — click the **X (Clear) icon** next to the file name. The file is disassociated from the field. The attachment area returns to its empty state, ready for a new upload. Click **Save** to confirm the removal.

Tip: If you need to replace an attachment, always clear the existing file first using the X icon before uploading the new one. This ensures only one file is attached to the field at a time.

Key Terms — Quick Reference

Child Table	An embedded row-based grid inside a form, used to capture multiple line items of the same type (e.g., expenditure lines, checklist tasks). Each row represents one item.
+ Add Row	The button at the bottom-left of a Child Table that appends a new blank row for data entry.
Inline Editing	Clicking directly into a table cell to enter or edit data without opening a separate panel.
Edit Row View	A pop-up or side panel that opens when the Edit Row icon (pencil/expand) is clicked, showing all fields for a single Child Table row in a structured, easy-to-read layout.
Link Field	A dropdown selector that is connected to records stored in another list in the system. Link fields are searchable: typing a keyword filters the available options in real time.
Searchable Dropdown	Another term for a Link Field. Users type a keyword to filter the dropdown list instead of scrolling through all available options.
Attachment	An external file (PDF, image, document) uploaded to a form field or table row as supporting evidence. Attachments must be saved to persist with the record.
Preview (Eye icon)	A control next to an uploaded attachment that opens the file for viewing in a new browser tab, confirming the correct document is attached.

Clear (X icon)	A control next to an uploaded attachment that removes the file from the field, returning it to an empty state ready for a new upload.
----------------	---

Chapter 4

User Administration & Permissions

This chapter is intended for **System Administrators**. It explains how to create and configure user accounts in the Jalsampada Portal, and how to control what each user can see and do through the portal's permission system. Access control in the portal is managed through three building blocks that must be set up in sequence: **Roles**, **Role Profiles**, and **Users**.

A **Role** defines a specific set of permissions — what a user of that type can create, read, update, or delete. A **Role Profile** is a named template that bundles one or more Roles together, making it easy to assign a standard permission set to many users at once. A **User** is an individual login account, which is assigned a Role Profile to inherit the relevant permissions.

The full setup sequence for a new user is as follows:


Step	Action	Where
1	Create a Role	Admin Workspace → Role → + Add Role
2	Create a Role Profile	Admin Workspace → Role Profile → + Add Role Profile
3	Create a User	Admin Workspace → User → + Add User
4	Assign the Role Profile to the User	User form → Roles tab
5	Verify the account	Log out and log in as the new user

4.1 Creating a System Role

A **Role** is the fundamental unit of the permission system. Each Role represents a specific job function or access level — for example, **Operator**, **Field Engineer**, or **LIS Manager**. Roles are created first and then bundled into Role Profiles. The system administrator decides which actions (create, view, edit, delete) are associated with each role.

Step 1 Navigate to the Admin Workspace


In the left-hand navigation sidebar, click **Admin**. The Admin Workspace loads, displaying links for managing Users, Roles, Role Profiles, and related configuration records.



Admin Workspace page showing the module categories with links for 'User', 'Role', and 'Role Profile' visible under the Master category.

Step 2 Open the Role List View

In the Admin Workspace, click **Role**. The Role List View opens, displaying all existing system roles.




Role List View showing existing roles in a tabular list, with the '+ Add Role' button visible in the top-right corner of the list.

Step 3 Click + Add Role

Click the **+ Add Role** button at the top right of the list. A blank Role form opens with the status set to **Not Saved**.

Step 4 Enter the Role Name


In the **Role Name** field, type a clear, descriptive name that reflects the job function this role represents — for example, **Operator Test** or **LIS Field Operator**. Use a consistent naming convention across all roles so they are easy to identify in lists.



Blank Role form (New Role / Not Saved status) with the Role Name field active and filled in with a sample name such as 'Operator Test'.

Step 5 Save the Role

Click **Save**. The Role is created and appears in the Role List View. Its status changes from **Not Saved** to saved. The new Role is now available to be added to a Role Profile.



Saved Role record showing the Role Name (e.g., 'Operator Test') confirmed and the status no longer showing 'Not Saved'. The breadcrumb reads 'Admin / Role / Operator Test'.

Tip: Role names cannot be changed after they have been assigned to users. Choose descriptive, future-proof names from the outset.

4.2 Creating a Role Profile

A **Role Profile** acts as a named permission template — a container that groups one or more Roles together. Rather than manually assigning individual Roles to every user, the administrator assigns a Role Profile. All users with the same Role Profile automatically inherit the same set of permissions, making bulk user management straightforward.


For example, a **Field Operator Profile** might contain the **Operator** and **Read-Only Reports** roles. Any user assigned this profile will automatically have both roles active.

Step 1 Navigate to the Admin Workspace

Click **Admin** in the left-hand sidebar to return to the Admin Workspace, or use the breadcrumb to navigate back.

Step 2 Open the Role Profile List View

Click **Role Profile** in the Admin Workspace. The Role Profile List View opens.



Role Profile List View showing existing role profiles in a list, with the '+ Add Role Profile' button visible at the top right.

Step 3 Click + Add Role Profile

Click the **+ Add Role Profile** button. A blank Role Profile form opens.

Step 4 Enter the Profile Name

In the **Profile Name** field, enter a name that describes the type of user or department this profile is intended for — for example, **Operator Test** or **Mhaisal LIS Operators**.

New Role Profile
Create a template to group multiple roles

Admin / Role Profile / Draft

Profile Details

Role Profile Name *

Operator

Operator

Operator Test

Assigned Roles

☐ Academics User	☐ Accounts Manager	☐ Accounts User	☐ Administrator
☐ Agriculture Manager	☐ Agriculture User	☐ All	☐ Analytics
☐ Asset and Stock User	☐ Auditor	☐ Blogger	☐ Customer
☐ Dashboard Manager	☐ Delivery Manager	☐ Delivery User	☐ Departmental Sectional Engineer
☐ Deputy Engineer	☐ Desk User	☐ Employee	☐ Executive Engineer
☐ Fleet Manager	☐ Fulfillment User	☐ Guest	☐ HR Manager
☐ HR User	☐ Inbox User	☐ Irrigation Admin	☐ Item Manager
☐ Knowledge Base Contributor	☐ Knowledge Base Editor	☐ Maintenance Manager	☐ Maintenance User

Role Profile form with the Profile Name field filled in (e.g., 'Operator Test'). Below the name field, the Roles section of the form is visible showing a table or checklist of available roles.

Step 5 Select the Role(s) to include

In the **Roles** section of the form, locate the Role you created in Section 4.1 (e.g., **Operator Test**). Check its checkbox (or use the search field to find it if the list is long). You may add multiple Roles to a single profile if needed.

JALSAMPADA Welcome, Vaibhav

☐ Dashboard Manager	☐ Delivery Manager	☐ Delivery User	☐ Departmental Sectional Engineer
☐ Deputy Engineer	☐ Desk User	☐ Employee	☐ Executive Engineer
☐ Fleet Manager	☐ Fulfillment User	☐ Guest	☐ HR Manager
☐ HR User	☐ Inbox User	☐ Irrigation Admin	☐ Item Manager
☐ Knowledge Base Contributor	☐ Knowledge Base Editor	☐ Maintenance Manager	☐ Maintenance User
☐ Manufacturing Manager	☐ Manufacturing User	☐ Marketing Manager	☐ Newsletter Manager
☐ Operator	☒ Operator Test	☐ Prepared Report User	☐ Projects Manager
☐ Projects User	☐ Purchase Manager	☐ Purchase Master Manager	☐ Purchase User
☐ Quality Manager	☐ Report Manager	☐ Sales Manager	☐ Sales Master Manager
☐ Sales User	☐ Script Manager	☐ Site Engineer	☐ Stock Manager
☐ Stock User	☐ Superintending Engineer	☐ Supplier	☐ Support Team
☐ System Manager	☐ TESTING ROLE	☐ Tender Clerk	☐ Tendora Asset Role
☐ Translator	☐ Website Manager	☐ Workspace Manager	☐ system con

Save Role Profile Back

Role Profile form with the Roles section visible — the checkbox next to 'Operator Test' (or similar) is ticked/checked, confirming it has been added to this profile. Other roles in the list remain unchecked.

Step 6 Save the Role Profile

Click **Save**. The Role Profile is created and saved. It now appears in the Role Profile List View and is ready to be assigned to users.

Admin / Role Profile / Edit Role Profile: Operator Test Draft

Profile Details

Role Profile Name *

Operator Test

Assigned Roles

☐ Academics User	☐ Accounts Manager	☒ Accounts User	☒ Administrator
☐ Agriculture Manager	☐ Agriculture User	☒ All	☐ Analytics
☒ Asset and Stock User	☒ Auditor	☐ Blogger	☒ Customer
☐ Dashboard Manager	☐ Delivery Manager	☐ Delivery User	☐ Departmental Sectional Engineer
☐ Deputy Engineer	☐ Desk User	☒ Employee	☒ Executive Engineer
☐ Fleet Manager	☐ Fulfillment User	☒ Guest	☒ HR Manager
☐ HR User	☒ Inbox User	☒ Irrigation Admin	☒ Item Manager
☐ Knowledge Base Contributor	☒ Knowledge Base Editor	☐ Maintenance Manager	☒ Maintenance User
☒ Manufacturing Manager	☒ Manufacturing User	☒ Marketing Manager	☐ Newsletter Manager
☒ Operator	☒ Operator Test	☒ Prepared Report User	☒ Projects Manager

Saved Role Profile record with the Profile Name confirmed and the included Role(s) shown as checked in the Roles section. Breadcrumb reads 'Admin / Role Profile / Operator Test'.

4.3 Creating a New User & Setting a Password

With the Role and Role Profile in place, the administrator can now create the individual user account. Each user account stores the person's identity information and login credentials, and will be linked to a Role Profile to define their access level.

Step 1 Navigate to the User List View

From the Admin Workspace, click **User**. The User List View opens, showing all existing user accounts.

User
Manage system users and their permissions

+ Add User


Search by name, email...

Username	Full Name	Email	User Type	Status	25 / 46
☐ operator.test@erpdata.in	Operator Test	operator.test@erpdata.in	System User	Active	32m
☐ shripad.sutar2026@gmail.com	Shripad Sutar	shripad.sutar2026@gmail.com	System User	Active	19h
☐ ts1takari@gmail.com	TS 1 Takari	ts1takari@gmail.com	System User	Active	4d
☐ ts1wakrude@gmail.com	TS 1 Wakurde	ts1wakrude@gmail.com	System User	Active	4d
☐ tender.clerk@gmail.com	Tender Clerk	tender.clerk@gmail.com	System User	Active	6d
☐ john.mary.doe@gmail.com	JOHN DOE	john.mary.doe@gmail.com	System User	Active	6d
☐ sonali.kadam@erpdata.in	Sonali Kadam	sonali.kadam@erpdata.in	System User	Active	6d
☐ operator1@gmail.com	WAKIST1 Operator1	operator1@gmail.com	System User	Active	5 Mar
☐ test@gmail.com	test	test@gmail.com	System User	Disabled	4 Mar
☐ akshay.m@erpdata.in	Akshay Mahadadalkar	akshay.m@erpdata.in	System User	Active	2 Mar
☐ john.doe@erpdata.in	John Doe	john.doe@erpdata.in	System User	Disabled	2 Mar
☐ vaibhav.magdum@erpdata.in	Vaibhav	vaibhav.magdum@erpdata.in	System User	Active	2 Mar
☐ vishal.dhayarkar@erpdata.in	Vishal	vishal.dhayarkar@erpdata.in	System User	Active	2 Mar
☐ test2@gmail.com	Test ERP Guest	test2@gmail.com	Website User	Disabled	26 Feb
☐ magdum@erpdata.in	Vaibhav Magdum	magdum@erpdata.in	System User	Disabled	26 Feb
☐ test.user@erpdata.in	TEST USER	test.user@erpdata.in	Website User	Active	26 Feb
☐ rakesh.chougule@erpdata.in	Rakesh Chougule	rakesh.chougule@erpdata.in	System User	Active	12 Feb

User List View in the Admin Workspace showing existing user accounts (e.g., 'Administrator') in a table, with the '+ Add User' button in the top-right corner.

Step 2 Click + Add User

Click the **+ Add User** button. A blank User form opens with two tabs visible: **Basic Details** and **Roles**. The form opens on the **Basic Details** tab by default.



Blank User form (New User / Not Saved status) showing the Basic Details tab active, with empty fields for First Name, Last Name, Email, and Password.

Step 3 Enter the user's First Name

In the **First Name** field, type the user's given name. The Last Name field is optional but recommended for clarity in multi-user deployments.

Step 4 Enter the Email address

In the **Email** field, enter the user's official email address (e.g., **operator.test@erpdata.in**).

Critical — The Email Address is the User ID

The **Email** field serves as the user's **primary login identifier** for the Jalsampada Portal. When this user logs in at the Portal Login screen, they must enter this exact email address in the **Username** field. Ensure the address is typed correctly — a typo will prevent the user from logging in.

Email addresses cannot be changed after the account is saved. If an incorrect email is saved, the account must be deleted and recreated.

Step 5 Set a Password

In the **Password** field, type a secure temporary password for this user. The password must meet the portal's minimum security requirements (typically a mix of uppercase letters, lowercase letters, numbers, and special characters — consult your system administrator for the exact policy).

Communicate the temporary password to the user through a secure channel. If the portal supports forced password change on first login, the user will be prompted to set their own password immediately after signing in for the first time.

New User
Create a new system or website user

Admin / User / **Draft**

Basic Details | Contact & Profile | Settings & Preferences | Roles

Personal Information

First Name * Last Name Email *

Username User Type Password * ☒ Send Welcome Email

Back

User form Basic Details tab showing the First Name field filled in, the Email field filled in with a sample address (e.g., 'operator.test@erpdata.in'), and the Password field filled with masked characters (dots/asterisks). The Roles tab is visible but not yet active.

4.4 Assigning Roles to the User

Once the user's basic details are entered, the next step is to define what they can access in the portal. This is done in the **Roles** tab of the User form, where a **Role Profile** is assigned to the account.

Step 1 Click the Roles tab

At the top of the User form, click the **Roles** tab. The tab switches to display the permissions configuration section, which includes a **Role Profile** search field and a list of individual role checkboxes below it.

JALSAMPADA | Welcome, Vaibhav

New User
Create a new system or website user

Admin / User / **Draft**

Basic Details | Contact & Profile | Settings & Preferences | **Roles**

Assign Roles

Role Profile

- ☒ Accounts
- ☒ Inventory
- ☒ Manufacturing
- ☒ Operator Test
- ☒ Patbandhare Sub Adhikari
- ☒ Purchase
- ☒ Sales
- ☒ Employee
- ☒ Guest
- ☒ Irrigation Admin
- ☒ Maintenance Manager
- ☒ Administrator
- ☒ Analytics
- ☒ Customer
- ☒ Departmental Sectional Engineer
- ☒ Executive Engineer
- ☒ HR Manager
- ☒ Item Manager
- ☒ Maintenance User
- ☒ Academics User
- ☒ Agriculture Manager
- ☒ Asset and Stock User
- ☒ Dashboard Manager
- ☒ Deputy Engineer
- ☒ Fleet Manager
- ☒ HR User
- ☒ Knowledge Base Contributor
- ☒ Manufacturing Manager
- ☒ Accounts Manager
- ☒ Agriculture User
- ☒ Auditor
- ☒ Delivery Manager
- ☒ Desk User
- ☒ Fulfillment User
- ☒ Inbox User
- ☒ Knowledge Base Editor
- ☒ Manufacturing User

User form with the Roles tab active. The tab shows a 'Role Profile' search/dropdown field at the top, and below it a list of individual role checkboxes (all unchecked at this stage).

Step 2 Select the Role Profile

Click inside the **Role Profile** search field. Type the name of the Role Profile created in Section 4.2 (e.g., **Operator Test**) or scroll to find it in the dropdown list. Click the profile name to select it.

The screenshot shows the 'New User' form with the 'Roles' tab active. The breadcrumb is 'Admin / User / Not Saved'. The 'Assign Roles' section has a 'Role Profile' dropdown set to 'Operator Test'. Below it, a grid of roles is shown with checkboxes. Roles like 'Accounts User', 'All', 'Blogger', 'Delivery User', 'Employee', 'Guest', 'Irrigation Admin', 'Maintenance Manager', 'Administrator', 'Analytics', 'Customer', 'Departmental Sectional Engineer', 'Executive Engineer', 'HR Manager', 'Item Manager', 'Maintenance User', 'Academics User', 'Accounts Manager', 'Agriculture Manager', 'Agriculture User', 'Asset and Stock User', 'Auditor', 'Dashboard Manager', 'Delivery Manager', 'Deputy Engineer', 'Desk User', 'Fleet Manager', 'Fulfillment User', 'HR User', 'Inbox User', 'Knowledge Base Contributor', 'Knowledge Base Editor', 'Manufacturing Manager', and 'Manufacturing User' are listed. Many of these checkboxes are turned on (green), indicating they are assigned to the 'Operator Test' profile.

User form Roles tab with the Role Profile dropdown open and 'Operator Test' (or similar) highlighted/selected from the dropdown list.

Step 3 Confirm automatic role selection

Once the Role Profile is selected, the portal automatically checks all Role checkboxes that are included in that profile. You do not need to check them manually.

Pro Tip — Role Profiles Save Time

By assigning a **Role Profile** rather than individual roles, all the correct permission checkboxes are selected automatically. This eliminates the risk of accidentally missing a role or granting an incorrect one.

If you need to grant a user access to an **additional role** beyond their profile (e.g., a temporary elevated permission), you can manually check individual role boxes alongside the assigned profile. Remove those manual selections when the temporary access is no longer required.

Step 4 Save the User

Click **Save**. The user account is created with the assigned Role Profile and its associated permissions. The new user now appears in the User List View and can log into the portal using their email address and password.

The screenshot shows the 'Edit User' form for 'Operator Test' with the 'Basic Details' tab active. The breadcrumb is 'Admin / User / Edit User: Operator Test'. The 'Basic Details' tab shows the user's email address and other details. The 'Roles' tab is also visible, showing the assigned role profile and selected checkboxes.


Saved User record with the breadcrumb reading 'Admin / User / [User's Email or Name]'. The Basic Details tab confirms the email address, and the Roles tab shows the Role Profile assigned and role checkboxes selected.

4.5 Verifying the Account

After saving a new user account, it is good practice to verify that the credentials and permissions are working correctly before notifying the user. This is done by logging out of the Administrator account and signing in with the new user's credentials.

Step 1 Log out of the Administrator account

In the bottom-left corner of the sidebar, click the **Administrator** username label to expand the user menu. From the menu, click **Logout**. The portal ends the current session and returns to the Portal Login screen. (Refer to the Login/Logout section of this manual for full details.)



Bottom-left corner of the sidebar with the Administrator user menu expanded, showing the 'Logout' option highlighted/ready to click.

Step 2 Sign in as the new user

On the Portal Login screen, enter the new user's **email address** in the **Username** field and their **password** in the **Password** field. Click **Sign In to Portal**.




Portal Login screen with the new user's email address entered in the Username field and masked characters in the Password field, with the 'Sign In to Portal' button ready to be clicked.

Step 3 Confirm access and permissions

After signing in, verify that:

- The Dashboard Overview loads correctly for the new user's session.
- The left-hand sidebar displays only the modules and actions permitted by the assigned Role Profile — restricted modules should not be visible.
- Attempting to access a restricted area (if applicable) shows an appropriate access-denied message rather than the content.



Dashboard Overview loaded under the new user's session — the top-right greeting shows the new user's name (e.g., 'Welcome, Operator Test') and the sidebar shows only the modules permitted by the assigned Role Profile.

Step 4 Log back in as Administrator

Once verification is complete, log out of the test session and log back in using the **Administrator** credentials to resume system management.

Note: If the new user cannot log in or sees incorrect permissions, return to the User record in the Admin Workspace, review the Role Profile assignment on the Roles tab, and re-save.

Key Terms — Quick Reference

Role	A named set of system permissions that defines what actions a user of a given type can perform (e.g., create, view, edit, delete records in specific modules).
Role Profile	A named template that groups one or more Roles together. Assigning a Role Profile to a user automatically grants all the permissions of the Roles it contains.

User	An individual login account in the portal, identified by an email address. Each user is assigned a Role Profile that controls their access.
Email (User ID)	The email address entered in the User form's Basic Details tab. This address is used as the login Username on the Portal Login screen and cannot be changed after saving.
Basic Details tab	The first tab on the User form, containing the user's First Name, Last Name, Email (User ID), and Password fields.
Roles tab	The second tab on the User form, where the administrator assigns a Role Profile and can optionally check individual role boxes for additional access.
Admin Workspace	The module workspace accessible from the Admin link in the sidebar, containing links to manage Users, Roles, Role Profiles, and other system configuration records.