

Parts List

HF6V

NOTE Code A	Part No 00278SZV 00111BAV	ons are in inches(millimeter) unless otherwise noted Description TUBE A W/INSULATOR 1.125(29) X 24(606) TUBE A TUBE A INSULATOR	Oty 1	J 25(635) 13 1/2(343)
B1		TUBE B1 W/INSULATOR 1.125(29) x 12(302) TUBE B1 INSULATOR TUBE B1	1	н 11 FT 3(3429)
С	00147BAV	COIL ASSEMBLY 80/40 METER COIL 80 METER COIL 40 METER HF6V	1	G N
D		CAPACITOR ASSEMBLY 80/40 METER CAPACITOR 200PF CAPACITOR 67PF	1	K K
D1	00150BAV	CAPACITOR BRACKET 80 METER	1	E
D2	00220BAV	CAPACITOR BRACKET 40 METER	1	E
B E F G H I	00115BAV 00123BAV 00124BAV 00125BAV 00126BAV 00127BAV 00175BAV	TUBE PACKAGE HF6V TUBE 1.125(29) X 48(1216) TUBE 1.000(25) X 48(1216) TUBE 0.875(22) X 48(1216) TUBE 0.750(19) X 48(1216) TUBE 0.625(16) X 48(1216) TUBE 0.500(13) X 48(1216) TUBE 0.375(10) X 36(911)	1 1 1 1 1 1	9 7/8(251) P B1 D2 9 3/8(238) C 13(330) D1
L M N K	00280RZV 00281RZV 00282RZV	15 METER KIT WIRE CLAMP 0.500(13) 15M W/WIRE WIRE CLAMP 0.625(16) 15M W/INSULATOR WIRE CLAMP 0.750(19) 15M W/INSULATOR WIRE CLAMP 0.875(22) 15M W/INSULATOR	1 1 1	B
0	00204SZV	COIL SUPPORT TUBE 30 METER 1.125(29) X 9(225) 1	3(76) A 3(76)

Code 01	Part No 00176BAV	Description COIL SUPPORT TUBE 30 METER L BRACKET	Oty 1
Р	00249SZV 00268BAV 00711TZV	COIL 30 METER	1
Q	00137SZV	COIL Q BASE MATCHING	1
R	290-08	COAX 75 OHM MATCHING	1
	00077JZV 00078JZV 00079JZV 00080JZV 00081JZV 00083JZV 00109JZV 00114JZV 00131JZV 00132JZV 00133JZV	# 8-32 X 1.000(25) SCREW # 8-32 X 1.250(32) SCREW # 8 LOCK WASHER # 8-32 HEX NUT # 8 FLAT WASHER # 8-32 X 2.000(51) SCREW # 8-32 X 1.500(38) SCREW # 10-24 X 1.000(25) SCREW # 10 FLAT WASHER # 10 LOCK WASHER # 110 LOCK WASHER	3 5 3 18 18 7 2 3 2 8 8 8 4 5
	00089FZV	KONNEKTOR-KOTE 1(25) X 8(203) PROTECTIVE CAP 0.375 CAPACITOR BRACKET CLAMP	.05 1 2 1
	00061SZV	BUTTER-IT'S-NOT	1
	00366IZV	INSTRUCTIONS HF6V	1