


X55C Repair Guide




POWER FLOW



POWER ON SEQUENCE



Voltage& Signal Measure Point TOP



Voltage& Signal Measure Point Bottom

