

FORD F-250/350/450 TAILGATE ASSIST

QUICK INSTALLATION GUIDE



IMPORTANT Park on level ground, switch off the ignition, fully open the tailgate, and never remove both lower bolts at the same time.

1 Disconnect support cable on driver side

Lift the eyelet, align its slot with the post, and slide it off.



2 Remove upper mounting bolt

Use the supplied Torx key. Retain the factory bolt.



3 Install upper bracket

Position the black upper bracket; reinstall and tighten the factory bolt.



4 Remove first lower bolt

Remove the upper/left bolt only; leave the second bolt installed.



5 Position lower bracket

Install lower bracket with the supplied bolt finger-tight so the bracket can pivot.



6 Secure lower bracket

Loosen the second bolt, align the bracket, then tighten both bolts.



7 Attach damper

Snap the lower socket onto the lower ball stud, then attach the upper socket.



8 Reconnect and test

Reconnect the cable. Slowly close and reopen; check clearance and fasteners.

