

F-250 / F-350 TAILGATE ASSIST INSTALLATION GUIDE | FORD SUPER DUTY 1999-2016



IMPORTANT Park on level ground, switch off the ignition, fully open the tailgate.

PART 1 HOW TO SET THE THREADED ANCHOR | Tightening the nut pulls the sleeve tight behind the sheet metal, creating a threaded mounting point.

1 INSERT



Push the anchor fully into the lower factory hole. Keep the flange flat against the panel.

2 LOCK



Hold the setting bolt stationary and tighten the hex nut **approximately nine full turns**, or until the anchor is securely locked. Do not overtighten.

3 REMOVE TOOL



Unscrew and remove the setting bolt, nut, and washers. Leave the anchor in place.

4 CHECK



Confirm the flange is flush and the anchor does not spin. It is ready for the lower ball stud.

PART 2 INSTALL THE TAILGATE ASSIST | Driver-side installation - complete Steps 1-8 in order.

1 DISCONNECT CABLE



Lift the driver-side eyelet, align its slot with the post, and slide it off.

2 REMOVE UPPER BOLT



Remove the factory upper bolt with the supplied Torx key. Keep the bolt.

3 INSTALL BRACKET



Position the black bracket; reinstall and securely tighten the factory bolt.

4 SET ANCHOR



Install the threaded anchor in the lower factory hole following Part 1.

5 INSTALL LOWER STUD



Thread the lower ball stud into the installed anchor and tighten securely.

6 ATTACH DAMPER



Snap on the lower socket first, then the upper socket. Confirm both clips are seated.

7 RECONNECT CABLE



Refit the support-cable eyelet onto the factory post.

8 FIT CABLE PROTECTOR



Install the cable protector using pliers.

FINAL CHECK Open and close the tailgate slowly. Confirm smooth movement, secure fasteners, and no cable or damper interference.