

Dodge Ram 1500 TAILGATE ASSIST INSTALLATION GUIDE



IMPORTANT Park on level ground, switch off the ignition, and fully open the tailgate before installation.

PART 1 SET THE THREADED ANCHOR | Tightening the nut expands the sleeve behind the sheet metal to create a secure threaded mounting point.

1 INSERT ANCHOR



Insert the threaded anchor fully into the lower factory hole, keeping the flange flat against the panel.

2 LOCK ANCHOR



Hold the setting bolt stationary. Tighten only the hex nut **approximately nine full turns**, or until the anchor is locked. Do not overtighten.

3 REMOVE SETTING TOOL



Remove the setting bolt, hex nut, and washers. Leave the threaded anchor installed.

4 VERIFY ANCHOR



Verify that the flange sits flush and the anchor does not rotate. The anchor is now ready for the lower-bracket bolt.

PART 2 INSTALL THE TAILGATE ASSIST | Driver-side installation - complete Steps 1-8 in sequence.

1 DISCONNECT CABLE



Lift the driver-side cable eyelet, align its slot with the post, and slide the eyelet off.

2 REMOVE UPPER BOLT



Remove the factory upper bolt with the supplied hex key. Retain the bolt for reuse.

3 INSTALL UPPER BRACKET



Position the upper bracket, reinstall the factory bolt, and tighten it securely.

4 SET THREADED ANCHOR



Install the threaded anchor in the lower factory hole by following Part 1.

5 INSTALL LOWER BRACKET



Align the lower bracket with the threaded anchor, then install and tighten the provided bolt.

6 ATTACH DAMPER



Attach the lower damper socket first, followed by the upper socket. Confirm both sockets are fully seated.

7 RECONNECT CABLE



Slide the support-cable eyelet back onto the factory post and confirm it is fully seated.

8 INSTALL CABLE PROTECTOR



Use pliers to install the cable protector securely in place.

FINAL CHECK Slowly open and close the tailgate. Verify smooth operation, secure fasteners, and adequate clearance around the cable and damper.