



F-150 2004-2014 / Lincoln Mark LT 2006-2008 TAILGATE ASSIST

INSTALLATION GUIDE

IMPORTANT Park on level ground, turn off the ignition, and fully open the tailgate.

PART 1 HOW TO SET THE THREADED ANCHOR | Tightening the nut draws the sleeve tight behind the sheet metal, creating a secure threaded mounting point.

1 INSERT



Insert the anchor fully into the lower factory hole. Keep the flange flat against the panel.

2 LOCK



Hold the setting bolt stationary and tighten the hex nut **approximately nine full turns**, or until the anchor is firmly locked. Do not overtighten.

3 REMOVE TOOL



Remove the setting bolt, nut, and washers. Leave the threaded anchor installed.

4 CHECK



Confirm that the flange sits flush and the anchor does not rotate. It is ready for the lower ball stud.

PART 2 INSTALL THE TAILGATE ASSIST | Driver-side installation. Complete Steps 1-8 in order.

1 DISCONNECT CABLE



Lift the driver-side cable eyelet, align its slot with the post, and slide it off.

2 REMOVE UPPER BOLT



Remove the upper factory bolt with the supplied Torx key. Retain the bolt.

3 INSTALL BRACKET



Position the upper bracket, reinstall the factory bolt, and tighten it securely.

4 SET ANCHOR



Install the threaded anchor in the lower factory hole by following Part 1.

5 INSTALL LOWER STUD



Thread the lower ball stud into the anchor and tighten it securely.

6 ATTACH DAMPER



Attach the lower socket first, then the upper. Confirm both retaining clips are fully seated.

7 RECONNECT CABLE



Reinstall the support cable eyelet on the factory post.

8 VERIFY INSTALLATION



Confirm the installation matches the image. Ensure both damper sockets and the cable eyelet are fully seated.

FINAL CHECK Slowly open and close the tailgate several times. Confirm smooth damping, tight fasteners, and no cable or damper interference.