

Nissan Frontier 2005 to 2021 Tailgate Assist

QUICK INSTALLATION GUIDE



IMPORTANT Park on level ground, switch off the ignition, and fully open the tailgate.

1 Remove the upper cable bolt

On the driver side, remove the bolt.



2 Install the upper ball stud

Fasten the aluminum upper ball stud with the supplied long black bolt.



3 Reattach the support cable

Reattach the support cable over the new upper ball stud.



4 Install the supplied flat bolt

Replace the original bolt shown with the supplied flat-head bolt.



5 Remove the lower hinge bolt

Remove only the driver-side lower hinge bolt shown.



6 Install the lower bracket

Install the supplied lower bracket, bolt and C-shaped bushing.



7 Attach the damper at the top

Attach the upper damper part onto the ball stud until it snaps into place.



8 Attach the damper at the bottom

Attach the damper onto the bracket stud. Install the C-clip with pliers.



FINAL CHECK Open and close the tailgate slowly. Confirm smooth movement, secure fasteners, and no interference.

HARDWARE NOTE Extra bolts, nuts, and one C-clip are included as spares.