



RAM1500 2002-2008 RAM2500/3500 2003-2009 TAILGATE ASSIST

INSTALLATION GUIDE

IMPORTANT Park on level ground, switch off the ignition, and support the fully opened tailgate.

PART 1 HOW TO SET THE THREADED ANCHOR | Tighten the setting nut to expand the anchor sleeve behind the sheet metal.

1 INSERT



Push the threaded anchor fully into the lower factory hole. Keep its flange flat against the panel.

2 LOCK



Hold the setting bolt still and turn the hex nut about nine full turns, until the anchor grips the panel. Do not overtighten.

3 REMOVE TOOL



Remove the setting bolt, nut, and washers. Leave the threaded anchor in the panel.

4 CHECK



Check that the flange sits flush and the anchor cannot spin. The lower mounting point is ready.

PART 2 INSTALL THE TAILGATE ASSIST | Install on the driver side. Complete Steps 1-8 in order.

1 DISCONNECT CABLE



Lift the driver-side support-cable eyelet, align its slot with the post, and slide it off.

2 REMOVE UPPER BOLT



Use the supplied Torx key to remove the factory upper bolt. Set the bolt aside.

3 INSTALL UPPER STUD



Install the upper ball stud and washer at the factory bolt location. Tighten securely.

4 SET ANCHOR



Set the threaded anchor in the lower factory hole as shown in Part 1.

5 INSTALL LOWER STUD



Thread the lower ball stud into the installed anchor and tighten it securely.

6 ATTACH DAMPER



Snap the damper onto the lower ball stud, then the upper ball stud. Check that both sockets are seated.

7 RECONNECT CABLE



Slide the support-cable eyelet back onto its factory post and check that it is seated.

8 FIT CABLE PROTECTOR



Use pliers to fit the supplied cable protector around the support cable.

FINAL CHECK Open and close the tailgate slowly. Check that both support cables are attached, the damper moves freely, and all fasteners are secure.