

Silverado and Sierra 1500 Tailgate Assist



INSTALLATION GUIDE

IMPORTANT Park on level ground, switch off the ignition, fully open the tailgate.

1 Remove the upper cable bolt

On the driver side, support the tailgate. Remove the factory bolt and washer securing the support cable.



2 Install the upper bracket

Place the upper bracket as shown. Reinstall the cable, washer, and factory bolt; tighten securely.



3 Remove lower bolts.

Remove one highlighted lower bolts. Position the lower bracket and reinstall that bolts.



4 Install the lower bracket

Align the lower bracket, reinstall the factory bolts, then tighten both bolts securely.



5 Attach the upper socket

Press the tailgate-assist socket onto the upper ball stud until it snaps fully into place.



6 Attach the lower socket and test

Snap the lower socket onto the ball stud. Move the tailgate slowly and confirm smooth, clear operation.



FINAL CHECK Both sockets fully seated | Both brackets tight | No contact or binding